



EDS1100/2100 User Guide

Copyright & Trademark

© 2010 Lantronix. All rights reserved. No part of the contents of this book may be transmitted or reproduced in any form or by any means without the written permission of Lantronix. Printed in the United States of America.

Ethernet is a trademark of XEROX Corporation. UNIX is a registered trademark of The Open Group. Windows 95, Windows 98, Windows 2000, and Windows NT are trademarks of Microsoft Corp.

Warranty

For details on the Lantronix warranty replacement policy, please go to our web site at www.lantronix.com/support/warranty.

Contacts

Lantronix Corporate Headquarters

167 Technology Drive
Irvine, CA 92618, USA
Phone: 949-453-3990
Fax: 949-450-7249

Technical Support

Online: www.lantronix.com/support

Sales Offices

For a current list of our domestic and international sales offices, go to the Lantronix web site at www.lantronix.com/about/contact.

Disclaimer

Note: *This product has been designed to comply with the limits for a Class A digital device pursuant to Part 15 of FCC Subpart B and EN55024:1998 +A2:2003 Rules when properly enclosed and grounded. These limits are designed to provide reasonable protection against radio interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with this guide, may cause interference to radio communications. See "Appendix - Compliance" on page 146 for additional information.*

The information in this guide may change without notice. The manufacturer assumes no responsibility for any errors that may appear in this guide. For the latest revision of this product document, please check our online documentation at www.lantronix.com/support/documentation.html.

Revision History

Date	Rev.	Comments
March 2010	A	Initial Document
December 2010	B	Updated for firmware version 5.2.0.0R20. Added support for Modbus protocol, configurable MTU, and additional VIP tunnel connect protocols; as well as improvements to SNMP, logging, and SSL.

Table of Contents

List of Figures	9
List of Tables	11
1: About This Guide	13
Chapter and Appendix Summaries	13
Additional Documentation	14
2: Introduction	15
Key Features	15
Applications	15
Protocol Support	16
Evolution OS™	16
Additional Features	16
Modem Emulation	16
Web-Based Configuration and Troubleshooting	16
Command-Line Interface (CLI)	17
VIP Access	17
SNMP Management	17
XML-Based Architecture and Device Control	17
Really Simple Syndication (RSS)	17
Enterprise-Grade Security	17
Terminal Server/Device Management	18
Troubleshooting Capabilities	18
Configuration Methods	18
Addresses and Port Numbers	19
Hardware Address	19
IP Address	19
Port Numbers	19
Product Information Label	19
3: Installation of EDS1100	21
Package Contents	21
User-Supplied Items	21
Hardware Components	22
Back Panel	23
Reset Button	23
Top LEDs	24
Installing the EDS1100	24

4: Installation of EDS2100	26
Package Contents	26
User-Supplied Items	26
Hardware Components	26
Back Panel	28
Reset Button	28
Top LEDs	28
Installing the EDS2100	29
5: Using DeviceInstaller	31
Accessing EDS1100/2100 Using DeviceInstaller	31
Device Details Summary	31
6: Configuration Using Web Manager	33
Accessing Web Manager	33
Device Status Page	34
Web Manager Page Components	35
Navigating the Web Manager	36
7: Network Settings	38
Network 1 (eth0) Interface Status	38
Network 1 (eth0) Interface Configuration	39
Network 1 Ethernet Link	41
8: Line and Tunnel Settings	42
Line Settings	42
Line Statistics	42
Line Configuration	43
Line Command Mode	45
Tunnel Settings	46
Tunnel – Statistics	47
Tunnel – Serial Settings	49
Tunnel – Packing Mode	50
Tunnel – Accept Mode	53
Tunnel – Connect Mode	56
Connecting Multiple Hosts	60
Host List Promotion	60
Tunnel – Disconnect Mode	61
Tunnel – Modem Emulation	62

9: Terminal and Host Settings 65

Terminal Settings	65
Line Terminal Configuration	65
Network Terminal Configuration	67
Host Configuration	68

10: Service Settings 69

DNS Settings	69
PPP Settings	70
SNMP Settings	72
FTP Settings	73
TFTP Settings	74
Syslog Settings	75
HTTP Settings	76
HTTP Statistics	76
HTTP Configuration	77
HTTP Authentication	79
RSS Settings	80
LPD Settings	81
LPD Statistics	81
LPD Configuration	82

11: Security Settings 84

SSH Settings	84
SSH Server Host Keys	85
SSH Server Authorized Users	86
SSH Client Known Hosts	88
SSH Client User	89
SSL Settings	91
SSL Cipher Suites	91
SSL Certificates	92
SSL RSA or DSA	92
SSL Certificates and Private Keys	92
SSL Utilities	93
OpenSSL	93
Steel Belted Radius	93
FreeRadius	93
SSL Configuration	94

12: Modbus 97

Serial Transmission Mode	97
Modbus Statistics	98

Modbus Configuration	99
13: Maintenance and Diagnostics Settings	100
Filesystem Settings	100
Filesystem Statistics	100
Filesystem Browser	101
Protocol Stack Settings	104
TCP Settings	104
IP Settings	105
ICMP Settings	105
ARP Settings	107
SMTP Settings	108
IP Address Filter	109
Query Port	110
Diagnostics	111
Hardware	111
MIB-II Statistics	112
IP Sockets	113
Ping	113
Traceroute	115
Log	116
Memory	118
Buffer Pools	118
Processes	119
System Settings	121
14: Advanced Settings	123
Email Settings	123
Email Statistics	123
Email Configuration	124
Command Line Interface Settings	126
CLI Statistics	126
CLI Configuration	126
XML Settings	128
XML: Export Configuration	128
XML: Export Status	130
XML: Import Configuration	131
Import Configuration from External File	132
Import Configuration from the Filesystem	133
Import Line(s) from Single Line Settings on the Filesystem	135

15: VIP Settings	137
Obtaining a Bootstrap File _____	137
Importing the Bootstrap File _____	137
Enabling VIP _____	138
Configuring Tunnels to Use VIP _____	138
Virtual IP (VIP) Statistics _____	138
Virtual IP (VIP) Counters _____	139
Virtual IP (VIP) Configuration _____	139
16: Branding the EDS1100/2100	140
Web Manager Customization _____	140
Short and Long Name Customization _____	140
17: Updating Firmware	142
Obtaining Firmware _____	142
Loading New Firmware _____	142
Appendix - Technical Support	143
Technical Support US _____	143
Technical Support Europe, Middle East, Africa _____	143
Appendix - Binary to Hexadecimal Conversions	144
Converting Binary to Hexadecimal _____	144
Conversion Table _____	144
Scientific Calculator _____	145
Appendix - Compliance	146
Index	148

List of Figures

Figure 2-1 Sample Hardware Address	19
Figure 2-2 Product Label	20
Figure 3-1 EDS1100 DB25 (Female) Serial Port	22
Figure 3-2 EDS1100 RS-232 Pinouts	22
Figure 3-3 EDS1100 RS-422 (4-wire) Pinouts	22
Figure 3-4 EDS1100 RS-485 (2-wire) Pinouts	23
Figure 3-5 EDS1100 Back Panel	23
Figure 3-6 EDS1100 Top LEDs	24
Figure 3-8 EDS1100 Connections	25
Figure 4-1 EDS2100 Male DB9 DTE Serial Ports	27
Figure 4-2 EDS2100 Pinout Configuration for RS-232	27
Figure 4-3 EDS2100 Pinout Configuration for RS-422 (4-wire)	27
Figure 4-4 EDS2100 Pinout Configuration for RS-485 (2-wire)	27
Figure 4-5 EDS2100 Ethernet RJ45 Port, Reset Button, and Power Plug	28
Figure 4-6 EDS2100 Top LEDs	29
Figure 4-8 EDS2100 Connections	30
Figure 6-1 Web Manager Home Page	34
Figure 6-2 Components of the Web Manager Page	35
Figure 7-1 Network 1 (eth0) Interface Status	38
Figure 7-2 Network 1 (eth0) Interface Configuration	39
Figure 7-4 Network 1 Ethernet Link	41
Figure 8-1 Line 1 Statistics	42
Figure 8-4 Line 1 Command Mode	45
Figure 8-6 Tunnel 1 Statistics	48
Figure 8-7 Tunnel 1 Serial Settings	49
Figure 8-8 Tunnel 1 Packing Mode (Mode = Disable)	50
Figure 8-9 Tunnel 1 Packing Mode (Mode = Timeout)	51
Figure 8-10 Tunnel 1 Packing Mode (Mode = Send Character)	51
Figure 8-12 Tunnel 1 Accept Mode	54
Figure 8-14 Tunnel 1 Connect Mode	57
Figure 8-16 Host 1, Host 2, Host 3 Exchanged	60
Figure 8-17 Tunnel 1 Disconnect Mode	61
Figure 8-20 Tunnel 1 Modem Emulation	63
Figure 9-1 Terminal on Line 1 Configuration	65
Figure 9-3 Terminal on Network Configuration	67
Figure 9-5 Host Configuration	68
Figure 10-1 DNS Settings	69
Figure 10-2 PPP Configuration Settings	71
Figure 10-4 SNMP Configuration	72
Figure 10-6 FTP Configuration	73
Figure 10-7 TFTP Configuration	74
Figure 10-9 Syslog	75
Figure 10-11 HTTP Statistics	76
Figure 10-12 HTTP Configuration	77
Figure 10-14 HTTP Authentication	79
Figure 10-16 RSS	81

Figure 10-18 LPD Statistics	82
Figure 10-19 LPD Configuration	82
Figure 11-1 SSH Server: Host Keys	85
Figure 11-3 SSH Server: Authorized Users	87
Figure 11-5 SSH Client: Known Hosts	88
Figure 11-7 SSH Client: Users	89
Figure 11-10 SSL	94
Figure 12-3 Modbus Statistics	98
Figure 12-4 Modbus Configuration	99
Figure 13-1 Filesystem Statistics	100
Figure 13-2 Filesystem Browser	102
Figure 13-4 TCP Protocol	104
Figure 13-6 IP Protocol	105
Figure 13-8 ICMP Protocol	106
Figure 13-10 ARP Protocol Page	107
Figure 13-12 SMTP	108
Figure 13-14 IP Address Filter Configuration	109
Figure 13-16 Query Port Configuration	110
Figure 13-17 Diagnostics: Hardware	111
Figure 13-18 MIB-II Network Statistics	112
Figure 13-20 IP Sockets	113
Figure 13-21 Diagnostics: Ping	113
Figure 13-23 Diagnostics: Traceroute	115
Figure 13-25 Diagnostics: Log	116
Figure 13-26 Diagnostics: Log (Filesystem)	116
Figure 13-27 Diagnostics: Log (Line 1)	117
Figure 13-28 Diagnostics: Memory	118
Figure 13-29 Diagnostics: Buffer Pools	119
Figure 13-30 Diagnostics: Processes	120
Figure 13-31 System	121
Figure 14-1 Email Statistics	123
Figure 14-2 Email Configuration	124
Figure 14-4 CLI Statistics	126
Figure 14-5 CLI Configuration	127
Figure 14-7 XML: Export Configuration	129
Figure 14-9 XML: Export Status	130
Figure 14-11 XML: Import Configuration	131
Figure 14-12 XML: Import Configuration from External File	132
Figure 14-13 XML: Import from Filesystem	133
Figure 14-14 XML: Import Configuration from Filesystem	134
Figure 14-15 XML: Import Line(s) from Single Line Settings on the Filesystem	135
Figure 15-1 VIP Status	138
Figure 15-2 VIP Counters	139
Figure 15-4 VIP Configuration Page	139
Figure 16-1 System Branding	141
Figure 17-1 Update Firmware	142

List of Tables

Table 3-7 EDS1100 LEDs and Descriptions	24
Table 4-7 EDS2100 LEDs and Descriptions	29
Table 6-3 Summary of Web Manager Pages	36
Table 7-3 Network 1 (eth0) Interface Configuration	39
Table 7-5 Network 1 Ethernet Link	41
Table 8-2 Line 1 Configuration	43
Table 8-3 Line 1 Configuration	43
Table 8-5 Line 1 Command Mode	45
Table 8-11 Tunnel Packing Mode	51
Table 8-13 Tunnel Accept Mode	54
Table 8-15 Tunnel Connect Mode	58
Table 8-18 Tunnel Disconnect Mode	61
Table 8-19 Modem Emulation Commands and Descriptions	62
Table 8-21 Tunnel Modem Emulation	64
Table 9-2 Terminal on Line 1 Configuration	66
Table 9-4 Terminal on Network Configuration	67
Table 9-6 Host Configuration	68
Table 10-3 PPP Configuration	71
Table 10-5 SNMP	72
Table 10-8 TFTP Server	74
Table 10-10 Syslog	75
Table 10-13 HTTP Configuration	77
Table 10-15 HTTP Authentication	79
Table 10-17 RSS	81
Table 10-20 LPD Configuration	83
Table 11-2 SSH Server Host Keys Settings	85
Table 11-4 SSH Server Authorized User Settings	87
Table 11-6 SSH Client Known Hosts	88
Table 11-8 SSH Client Users	90
Table 11-9 Supported Cipher Suites	91
Table 11-11 SSL	95
Table 12-1 6 Byte Header of Modbus Application Protocol	97
Table 12-2 Modbus Transmission Modes	97
Table 12-5 Modbus Configuration	99
Table 13-3 Filesystem Browser	103
Table 13-5 TCP Settings	104
Table 13-7 IP Settings	105
Table 13-9 ICMP Settings	106
Table 13-11 ARP Settings	107
Table 13-13 SMTP Settings	108
Table 13-15 IP Address Filter Settings	109
Table 13-19 Requests for Comments (RFCs)	112
Table 13-22 Diagnostics: Ping	114
Table 13-24 Diagnostics: Traceroute	115
Table 13-32 System	121
Table 14-3 Email Configuration	124

Table 14-6 CLI Configuration _____	127
Table 14-8 XML Export Configuration _____	129
Table 14-10 XML Export Status _____	131
Table 14-16 XML: Import Line(s) from Single Line Settings _____	136
Table 15-3 VIP Counters _____	139
Table 19-1 Binary to Hexadecimal Conversion Table _____	144

1: About This Guide

This guide provides the information needed to configure, use, and update the EDS1100/2100™. It is intended for software developers and system integrators who are installing the EDS1100/2100 in their designs.

Chapter and Appendix Summaries

A summary of each chapter is provided below.

Chapter	Description
Chapter 2: Introduction	Main features of the product and the protocols it supports. Includes technical specifications.
Chapter 3: Installation of EDS1100	Instructions for installing the EDS1100.
Chapter 4: Installation of EDS2100	Instructions for installing the EDS2100.
Chapter 5: Using DeviceInstaller	Instructions for viewing the current configuration using DeviceInstaller.
Chapter 6: Configuration Using Web Manager	Instructions for accessing Web Manager and using it to configure settings for the device.
Chapter 7: Network Settings	Instructions for using the web interface to configure Ethernet settings.
Chapter 8: Line and Tunnel Settings	Instructions for using the web interface to configure line and tunnel settings.
Chapter 9: Terminal and Host Settings	Instructions for using the web interface to configure terminal and host settings.
Chapter 10: Service Settings	Instructions for using the web interface to configure settings for DNS, SNMP, FTP, and other services.
Chapter 11: Security Settings	Instructions for using the web interface to configure SSH and SSL security settings.
Chapter 12: Modbus	Instructions for using the web interface to configure Modbus.
Chapter 13: Maintenance and Diagnostics Settings	Instructions for using the web interface to maintain the device, view statistics, files, and logs, and diagnose problems.
Chapter 14: Advanced Settings	Instructions for using the web interface to configure email, CLI, and XML settings.
Chapter 15: VIP Settings	Information about Virtual IP (VIP) features available on the device and instructions for using the web interface to configure the VIP settings.
Chapter 16: Branding the EDS1100/2100	Instructions for customizing the device.
Chapter 17: Updating Firmware	Instructions for obtaining the latest firmware and updating the device.
Appendix - Technical Support	Instructions for contacting Lantronix Technical Support.
Appendix - Binary to Hexadecimal Conversions	Instructions for converting binary values to hexadecimal.
Appendix - Compliance	Lantronix compliance information.

Additional Documentation

Visit the Lantronix web site at www.lantronix.com/support/documentation for the latest documentation and the following additional documentation.

Document	Description
EDS1100/2100 Quick Start Guide	Instructions for getting the EDS1100/2100 configured and up and running.
EDS1100/2100 Command Reference	Instructions for accessing Command Mode (the command line interface) using a Telnet connection or through the serial port. Detailed information about the commands. Also provides details for XML configuration and status.
DeviceInstaller Online Help	Instructions for using the Lantronix Windows-based utility to locate the device and to view its current settings.
Com Port Redirector Quick Start and Online Help	Instructions for using the Lantronix Windows-based utility to create virtual com ports.
Secure Com Port Redirector User Guide	Instructions for using the Lantronix Windows-based utility to create secure virtual com ports.

2: Introduction

The EDS1100/2100 Ethernet Device Server is a complete network-enabling solution. It empowers original equipment manufacturers (OEMs) to go to market quickly and easily with Ethernet networking and web page capabilities built into the products.

The EDS1100 and EDS2100 provide the same solution and differ only in the number of serial ports. The EDS1100 has one serial port supported via a DB25 connector. The EDS2100 has two serial ports supported via 2 DB9 connectors.

This chapter contains the following sections:

- ◆ [Key Features](#)
- ◆ [Applications](#)
- ◆ [Evolution OS™](#)
- ◆ [Additional Features](#)
- ◆ [Configuration Methods](#)
- ◆ [Addresses and Port Numbers](#)
- ◆ [Product Information Label](#)

Key Features

- ◆ Power Supply: Regulated 9 - 30 Vdc input required. There is a step-down converter to 1.5 volts for the processor core. All voltages have LC filtering to minimize noises and emissions.
- ◆ Controller: A Lantronix DSTni-FX 32-bit microprocessor, running at 166 MHz internal bus and 83 MHz external bus.
- ◆ Memory: 8MB Flash and 8 MB SDRAM. Please contact your sales representative if you need larger memory sizes.
- ◆ Ethernet: 10/100 Mbps Ethernet transceiver
- ◆ Serial Ports: RS232/422/485 high-speed serial ports with all hardware handshaking signals. Baud rate is software selectable (300 bps to 921600 bps).
- ◆ Temperature Range: Operates over an extended temperature range of -40°C to +85°C.

Applications

The EDS1100/2100 device server connects serial devices such as those listed below to Ethernet networks using the IP protocol family.

- ◆ ATM machines
- ◆ Data display devices
- ◆ Security alarms and access control devices
- ◆ Modems
- ◆ Time/attendance clocks and terminals
- ◆ Patient monitoring equipment

- ◆ Medical instrumentation
- ◆ Industrial Manufacturing/Automation systems
- ◆ Building Automation equipment
- ◆ Point of Sale Systems

Protocol Support

The EDS1100/2100 device server contains a full-featured TCP/IP stack. Supported protocols include:

- ◆ ARP, IP, UDP, TCP, ICMP, BOOTP, DHCP, AutoIP, Telnet, DNS, FTP, TFTP, HTTP/HTTPS, SSH, SSL/TLS, SNMP, SMTP, RSS, PPP and Syslog for network communications and management.
- ◆ TCP, UDP, TCP/AES, UDP/AES, Telnet, SSH and SSL/TLS for tunneling to the serial port.
- ◆ TFTP, FTP, and HTTP for firmware upgrades and uploading files.

Evolution OS™

The EDS1100/2100 incorporates The Lantronix Evolution OS™. Key features of the Evolution OS™ include:

- ◆ Built-in Web server for configuration and troubleshooting from Web-based browsers
- ◆ CLI configurability
- ◆ SNMP management
- ◆ XML data transport and configurability
- ◆ Really Simple Syndication (RSS) information feeds
- ◆ Enterprise-grade security with SSL and SSH
- ◆ Comprehensive troubleshooting tools

Additional Features

Modem Emulation

In modem emulation mode, the EDS1100/2100 can replace dial-up modems. The unit accepts modem AT commands on the serial port, and then establishes a network connection to the end device, leveraging network connections and bandwidth to eliminate dedicated modems and phone lines.

Web-Based Configuration and Troubleshooting

Built upon Internet-based standards, the EDS1100/2100 enables you to configure, manage, and troubleshoot through a browser-based interface accessible anytime from anywhere. All configuration and troubleshooting options are launched from a web interface. You can access all functions via a Web browser, for remote access. As a result, you decrease downtime (using the troubleshooting tools) and implement configuration changes (using the configuration tools).

Command-Line Interface (CLI)

Making the edge-to-enterprise vision a reality, the EDS1100/2100 with the Evolution OS™ uses industry-standard tools for configuration, communication, and control. For example, the Evolution OS™ uses a Command Line Interface (CLI) whose syntax is very similar to that used by data center equipment such as routers and hubs.

VIP Access

Virtual IP Access is the Lantronix technology that solves the access-through-firewall problem. With VIP Access, the EDS1100/2100 can act as a ManageLinux DSC and provide direct access to your equipment behind a firewall.

SNMP Management

The EDS1100/2100 supports full SNMP management, making it ideal for applications where device management and monitoring are critical. These features allow networks with SNMP capabilities to correctly diagnose and monitor EDS1100/2100.

XML-Based Architecture and Device Control

XML is a fundamental building block for the future growth of M2M networks. The EDS1100/2100 supports XML-based configuration setup records that make device configuration transparent to users and administrators. The XML is easily editable with a standard text or XML editor.

Really Simple Syndication (RSS)

The EDS1100/2100 supports Really Simple Syndication (RSS) for streaming and managing on-line content. RSS feeds all the configuration changes that occur on the device. An RSS aggregator then reads (polls) the feed. More powerful than simple email alerts, RSS uses XML as an underlying Web page transport and adds intelligence to the networked device, while not taxing already overloaded email systems.

Enterprise-Grade Security

Evolution OS™ provides the EDS1100/2100 the highest level of networking security possible. This 'data center grade' protection ensures that each device on the M2M network carries the same level of security as traditional IT networking equipment in the corporate data center.

By protecting the privacy of serial data transmitted across public networks, users can maintain their existing investment in serial technology, while taking advantage of the highest data-protection levels possible.

SSH and SSL are able to do the following:

- ◆ Verify the data received came from the proper source
- ◆ Validate that the data transferred from the source over the network has not changed when it arrives at its destination (shared secret and hashing)
- ◆ Encrypt data to protect it from prying eyes and nefarious individuals

- ◆ Provide the ability to run popular M2M protocols over a secure SSH or SSL connection

In addition to keeping data safe and accessible, the EDS1100/2100 has robust defenses to hostile Internet attacks such as denial of service (DoS), which can be used to take down the network. Moreover, the EDS1100/2100 cannot be used to bring down other devices on the network.

You can use the EDS1100/2100 with the Lantronix Secure Com Port Redirector (SCPR) to encrypt COM port-based communications between PCs and virtually any electronic device. SCPR is a Windows application that creates a secure communications path over a network between the computer and serial-based devices that are traditionally controlled via a COM port. With SCPR installed at each computer, computers that were formerly “hard-wired” by serial cabling for security purposes or to accommodate applications that only understood serial data can instead communicate over an Ethernet network or the Internet.

Terminal Server/Device Management

Remote offices can have routers, PBXs, servers and other networking equipment that require remote management from the corporate facility. The EDS1100/2100 easily attaches to the serial ports on a server, Private Branch Exchange (PBX), or other networking equipment to deliver central, remote monitoring and management capability.

Troubleshooting Capabilities

The EDS1100/2100 offers a comprehensive diagnostic toolset that lets you troubleshoot problems quickly and easily. Available from the Web Manager, CLI, and XML interfaces, the diagnostic tools let you:

- ◆ View critical hardware, memory, MIB-II, buffer pool, and IP socket information.
- ◆ Perform ping and traceroute operations.
- ◆ Conduct forward or backup DNS lookup operations.
- ◆ View all processes currently running on the EDS1100/2100, including CPU utilization and total stack space available.

Configuration Methods

After installation, the EDS1100/2100 requires configuration. For the unit to operate correctly on a network, it must have a unique IP address on the network. There are four basic methods for logging into the EDS1100/2100 and assigning IP addresses and other configurable settings:

DeviceInstaller: Configure the IP address and related settings and view current settings on the EDS1100/2100 using a Graphical User Interface (GUI) on a PC attached to a network. See [Using DeviceInstaller \(on page 31\)](#).

Web Manager: Through a web browser, configure the EDS1100/2100 settings using the Lantronix Web Manager. See [Configuration Using Web Manager \(on page 33\)](#).

Command Mode: There are two methods for accessing Command Mode (CLI): making a Telnet connection or connecting a terminal (or a PC running a terminal emulation program) to the unit's serial port. (See the EDS1100/2100 Command Reference Guide for instructions and available commands.)

XML: The EDS1100/2100 supports XML-based configuration and setup records that make device configuration transparent to users and administrators. XML is easily editable with a standard text

or XML editor. (See the EDS1100/2100 Command Reference Guide for instructions and commands.)

Addresses and Port Numbers

Hardware Address

The hardware address is also referred to as the Ethernet address or MAC address. The first three bytes of the Ethernet address are fixed and read 00-20-4A, identifying the unit as a Lantronix product. The fourth, fifth, and sixth bytes are unique numbers assigned to each unit.

Figure 2-1 Sample Hardware Address

00-20-4A-14-01-18 **or** 00:20:4A:14:01:18

IP Address

Every device connected to an IP network must have a unique IP address. This address references the specific unit.

Port Numbers

Every TCP connection and every UDP datagram is defined by a destination and source IP address, and a destination and source port number. For example, a Telnet server commonly uses port number 23.

The following is a list of the default server port numbers running on the EDS1100/2100:

- ◆ TCP Port 22: SSH Server (Command Mode configuration)
- ◆ TCP Port 23: Telnet Server (Command Mode configuration)
- ◆ TCP Port 80: HTTP (Web Manager configuration)
- ◆ TCP Port 443: HTTPS (Web Manager configuration)
- ◆ UDP Port 161: SNMP
- ◆ TCP Port 21: FTP
- ◆ UDP Port 69: TFTP
- ◆ UDP Port 30718: LDP (Lantronix Discovery Protocol) port
- ◆ TCP/UDP Port 10001: Tunnel 1
- ◆ TCP/UDP Port 10002: Tunnel 2

Product Information Label

The product information label on the unit contains the following information about the specific unit:

- ◆ Bar Code
- ◆ Product Revision
- ◆ Part Number

- ◆ Hardware Address (MAC Address or Serial Number)

Figure 2-2 Product Label



3: *Installation of EDS1100*

This chapter describes how to install the EDS1100 device server. It contains the following sections:

- ◆ *Package Contents*
- ◆ *User-Supplied Items*
- ◆ *Hardware Components*
- ◆ *Installing the EDS1100*

Package Contents

The EDS1100 package includes the following items:

- ◆ One EDS1100 device
- ◆ One DB25M-to-DB9F serial cable
- ◆ Power Cube, 100-240 VAC with international adapters
- ◆ Power cord restraint
- ◆ Printed *Quick Start Guide*

User-Supplied Items

To complete your installation, you need the following items:

- ◆ RS-232/422/485 serial device that requires network connectivity.
- ◆ A serial cable, as in the following list, for your serial device. One end of the cable must have a male DB25 connector for the serial port.
 - A null modem cable to connect the serial port to a DCE device.
 - A straight-through modem cable, such as the one supplied in the package, to connect the serial port to a DTE device.
- ◆ An available connection to your Ethernet network and an Ethernet cable.
- ◆ A working power outlet if the unit will be powered from an AC outlet.

Hardware Components


The EDS1100 has a female DB25 serial port that supports RS-232, RS-422, and RS-485 serial devices. The default serial port settings are 9600 baud, 8 bits, no parity, 1 stop bit, no flow control. [Figure 3-1](#) shows the front panel.

Figure 3-1 EDS1100 DB25 (Female) Serial Port




[Figure 3-2](#) shows the RS-232 pinout configuration.

Figure 3-2 EDS1100 RS-232 Pinouts




[Figure 3-3](#) shows the RS-422 (4-wire) pinout configuration.

Figure 3-3 EDS1100 RS-422 (4-wire) Pinouts




[Figure 3-4](#) shows the RS-485 (2-wire) pinout configuration.

Figure 3-4 EDS1100 RS-485 (2-wire) Pinouts

Back Panel

On the EDS1100 back panel, there is a power plug, reset button, and an RJ45 (10/100) Ethernet port as shown in [Figure 3-5](#).

Figure 3-5 EDS1100 Back Panel

The Ethernet port has two LEDs that indicate the status of the connection.

◆ Left LED

- Green ON 100Mbps Link
- Green Blink 100Mbps Activity
- Orange ON 10Mbps Link
- Orange Blink 10Mbps Activity

◆ Right LED

- Green ON Full Duplex
- OFF Half Duplex

The Ethernet port can connect to an Ethernet (10 Mbps) or Fast Ethernet (100 Mbps) network.

Reset Button

You can reset the EDS1100 to factory defaults, including clearing the network settings. The IP address, gateway, and netmask are set to 00s.

To reset the unit to factory defaults, perform the following steps.

1. Place the end of a paper clip or similar object into the reset opening (back panel) and press for a minimum of 3 seconds.
2. Remove the paper clip to release the button. The firmware restores factory default settings to the configuration and reboots the unit.

Top LEDs

Figure 3-6 shows the top of the EDS1100 and Table 3-7 lists and describes the LEDs that are on the top of the device.

Figure 3-6 EDS1100 Top LEDs



Table 3-7 EDS1100 LEDs and Descriptions

LED	Description
Power (blue)	ON—EDS is receiving power
TX Serial (green)	Blinking—EDS is transmitting data on the serial port
RX Serial (yellow)	Blinking—EDS is receiving data on the serial port
Diagnostic	ON—EDS firmware has completed booting Blinking 1x/sec—EDS firmware is booting Blinking 2x/sec—EDS is writing a file to flash Blinking 4x/sec—EDS is compacting the file system Blinking 5x/sec—EDS is restoring factory defaults

Installing the EDS1100

Be sure to place the device on a flat horizontal or vertical surface. The device comes with mounting brackets for mounting the device vertically, for example on a wall. If using AC power, avoid outlets controlled by a wall switch.

Observe the following guidelines when connecting the serial devices:

- ♦ The EDS1100 serial ports support RS-232/422/485 devices.


- ◆ The null modem cable is the best cable to connect the serial port to a DCE device. The straight-through (modem) cable is the best cable to connect the serial port to a DTE device.
- ◆ Power-up the device by using the barrel-power connector only. The barrel-power connector supports a power range of 9 to 30 VDC.

Note: As soon as you plug the device into power, the device powers up automatically, the self-test begins, and Evolution OS™ starts.

Perform the following steps to install your device. The steps are shown in [Figure 3-8](#).

1. Connect a serial device to your unit.
2. Connect an Ethernet cable between the EDS1100 RJ45 port and your Ethernet network.
3. Plug the EDS1100 into the power outlet by using the power supply that was included in the packaging. The required input voltage is 9-30 VDC (center +) with 1.5W maximum power required.
4. Power up the serial device.

Figure 3-8 EDS1100 Connections



4: Installation of EDS2100

This chapter describes how to install the EDS2100 device server. It contains the following sections:

- ◆ [Package Contents](#)
- ◆ [User-Supplied Items](#)
- ◆ [Hardware Components](#)
- ◆ [Installing the EDS2100](#)

Package Contents

The EDS2100 package includes the following items:

- ◆ One EDS2100 device
- ◆ One DB9F-to-DB9F serial null modem cable
- ◆ Power Cube, 100-240 VAC with international adapters
- ◆ Power cord restraint
- ◆ Printed *Quick Start Guide*

User-Supplied Items

To complete your installation, you need the following items:


- ◆ RS-232/422/485 serial devices that require network connectivity.
- ◆ A serial cable, as listed below, for each serial device. One end of the cable must have a female DB9 connector for the serial port.
 - A null modem cable, such as the one supplied in your EDS2100 package, to connect the serial port to another DTE device.
 - A straight-through modem cable to connect the serial port to a DCE device.
- ◆ An available connection to your Ethernet network and an Ethernet cable.
- ◆ A working power outlet if the unit will be powered from an AC outlet.

Hardware Components


The EDS2100 has two male DB9 serial ports that support RS-232/422/485. [Figure 4-1](#) shows the front of the device. The default serial port settings are 9600 baud, 8 bits, no parity, 1 stop bit, no flow control.

Figure 4-1 EDS2100 Male DB9 DTE Serial Ports


The RS-232 pinout configuration is shown in [Figure 4-2](#).

Figure 4-2 EDS2100 Pinout Configuration for RS-232

[Figure 4-3](#) shows the pinout configuration for RS-422 (4-wire).

Figure 4-3 EDS2100 Pinout Configuration for RS-422 (4-wire)


[Figure 4-4](#) shows the pinout configuration for RS-485 (2-wire).

Figure 4-4 EDS2100 Pinout Configuration for RS-485 (2-wire)

Back Panel

On the EDS2100 back panel, there is a power plug, reset button, and an RJ45 (10/100) Ethernet port as shown in [Figure 4-5](#).

Figure 4-5 EDS2100 Ethernet RJ45 Port, Reset Button, and Power Plug



The Ethernet port has two LEDs that indicate the status of the connection as follows:

◆ Left LED

- Green ON 100Mbps Link
- Green Blink 100Mbps Activity
- Orange ON 10Mbps Link
- Orange Blink 10Mbps Activity.

◆ Right LED

- Green ON Full Duplex.
- OFF Half Duplex

The Ethernet port can connect to an Ethernet (10 Mbps) or Fast Ethernet (100 Mbps) network.

Reset Button

You can reset the EDS2100 to factory defaults, including clearing the network settings. The IP address, gateway, and netmask are set to 00s. To reset the unit to factory defaults, perform the following steps.

1. Place the end of a paper clip or similar object into the reset opening and press for a minimum of 3 seconds.
2. Remove the paper clip to release the button. The firmware restores factory default settings to the configuration and reboots the unit.

Top LEDs

[Figure 4-6](#) shows the top of the EDS2100. [Table 4-7](#) lists and describes the LEDs.

Figure 4-6 EDS2100 Top LEDs



Table 4-7 EDS2100 LEDs and Descriptions

LED	Description
Power (blue)	ON—EDS is receiving power
TX Serial 1 (green)	Blinking—EDS is transmitting data on serial port 1
RX Serial 1 (yellow)	Blinking—EDS is receiving data on serial port 1
TX Serial 2 (green)	Blinking—EDS is transmitting data on serial port 2
RX Serial 2 (yellow)	Blinking—EDS is receiving data on serial port 2
Diagnostic	ON—EDS firmware has completed booting Blinking 1x/sec—EDS firmware is booting Blinking 2x/sec—EDS is writing a file to flash Blinking 4x/sec—EDS is compacting the file system Blinking 5x/sec—EDS is restoring factory defaults

Installing the EDS2100

Be sure to place the device on a flat horizontal or vertical surface. The device comes with mounting brackets for mounting the device vertically, for example on a wall. If using AC power, avoid outlets controlled by a wall switch.

Observe the following guidelines when connecting the serial devices:

- ♦ The EDS2100 serial ports support RS-232/422/485 devices.


- ◆ The null modem cable is the best cable to connect the serial port to another DTE device. The straight-through (modem) cable is the best cable to connect the serial port to a DCE device.
- ◆ Power-up the device by using the Barrel-power connector only. The barrel-power connector supports a power range of 9 to 30 VDC.

Note: As soon as you plug the device into power, the device powers up automatically, the self-test begins, and Evolution OS™ starts.

Perform the following steps to install your device which are numbered in [Figure 4-8](#) also.

1. Connect a serial device to your unit.
2. Connect an Ethernet cable between the EDS2100 RJ45 port and your Ethernet network.
3. Plug the EDS2100 into the power outlet by using the power supply that was included in the packaging. The required input voltage is 9-30 VDC (center +) with 1.5W maximum power required.
4. Power up the serial devices.

Figure 4-8 EDS2100 Connections



5: Using DeviceInstaller

This chapter covers the steps for locating a device and viewing its properties and details. DeviceInstaller is a free utility program provided by Lantronix that discovers, configures, upgrades and manages Lantronix Device Servers. It can be downloaded from the Lantronix website at www.lantronix.com/support/downloads.html. For instructions on using DeviceInstaller to configure the IP address, related settings or for more advanced features, see the DeviceInstaller online help.

Note: AutoIP generates a random IP address in the range of 169.254.0.1 to 169.254.255.254 if no BOOTP or DHCP server is found.

Accessing EDS1100/2100 Using DeviceInstaller

Note: Make note of the MAC address. It is needed to locate the EDS1100/2100 using DeviceInstaller.

1. Click **Start > All Programs > Lantronix > DeviceInstaller > DeviceInstaller**.
When DeviceInstaller starts, it will perform a network device search. To perform another search, click the "Search" button.
2. Expand the EDS1100/2100 folder by clicking the + symbol next to the EDS1100/2100 folder icon. The list of available Lantronix EDS1100/2100 devices appears.
3. Select the EDS1100/2100 unit by expanding its entry and clicking on its hardware (MAC) address to view its configuration.
4. On the right page, click the **Device Details** tab. The current EDS1100/2100 configuration appears. This is only a subset of the full configuration; the complete configuration may be accessed via Web Manager, CLI, or XML.

Device Details Summary

Note: The settings are Display Only in this table unless otherwise noted.

Current Settings	Description
Name	Name identifying the EDS1100/2100.
DHCP Device Name	Shows the name associated with the EDS1100/2100's current IP address, if the IP address was obtained dynamically.
Group	Configurable field. Enter a group to categorize the EDS1100/2100. Double-click the field, type in the value, and press Enter to complete. This group name is local to this PC and is not visible on other PCs or laptops using DeviceInstaller.
Comments	Configurable field. Enter comments for the EDS1100/2100. Double-click the field, type in the value, and press Enter to complete. This description or comment is local to this PC and is not visible on other PCs or laptops using DeviceInstaller.
Device Family	Shows the EDS1100/2100 device family type as "EDS".
Type	Shows the device type as "EDS1100" or "EDS2100".

ID	Shows the EDS1100/2100 ID embedded within the unit.
Hardware Address	Shows the EDS1100/2100 hardware (MAC) address.
Firmware Version	Shows the firmware currently installed on the EDS1100/2100.
Extended Firmware Version	Provides additional information on the firmware version.
Online Status	Shows the EDS1100/2100 status as Online, Offline, Unreachable (the EDS1100/2100 is on a different subnet), or Busy (the EDS1100/2100 is currently performing a task).
IP Address	Shows the EDS1100/2100 current IP address. To change the IP address, click the Assign IP button on the DeviceInstaller menu bar.
IP Address was Obtained	<p>Displays “Dynamically” if the EDS1100/2100 automatically received an IP address (e.g., from DHCP). Displays “Statically” if the IP address was configured manually.</p> <p>If the IP address was assigned dynamically, the following fields appear:</p> <ul style="list-style-type: none"> ◆ Obtain via DHCP with values of True or False. ◆ Obtain via BOOTP with values of True or False.
Subnet Mask	Shows the subnet mask specifying the network segment on which the EDS1100/2100 resides.
Gateway	Shows the IP address of the router of this network. There is no default.
Number of Ports	Shows the number of serial ports on this EDS1100/2100.
Supports Configurable Pins	Shows False, indicating configurable pins are available on the EDS1100/2100.
Supports Email Triggers	Shows True, indicating email triggers are available on the EDS1100/2100.
Telnet Enabled	Indicates whether Telnet is enabled on this EDS1100/2100.
Telnet Port	Shows the EDS1100/2100 port for Telnet sessions.
Web Enabled	Indicates whether Web Manager access is enabled on this EDS1100/2100.
Web Port	Shows the EDS1100/2100 port for Web Manager configuration.
Firmware Upgradable	Shows True, indicating the EDS1100/2100 firmware is upgradable as newer versions become available.

6: Configuration Using Web Manager

This chapter describes how to configure the EDS1100/2100 using Web Manager, the Lantronix browser-based configuration tool. The unit's configuration is stored in nonvolatile memory and is retained without power. All changes take effect immediately, unless otherwise noted. It contains the following sections:

- ◆ [Accessing Web Manager](#)
- ◆ [Web Manager Page Components](#)
- ◆ [Navigating the Web Manager](#)
- ◆ [Table 6-3 Summary of Web Manager Pages](#)

Accessing Web Manager

Note: You can also access the Web Manager by selecting the Web Configuration tab on the DeviceInstaller window.

To access Web Manager, perform the following steps:

1. Open a standard web browser. Lantronix supports the latest version of Internet Explorer, Mozilla Suite, Mozilla Firefox, Safari, Chrome or Opera.
2. Enter the IP address of the EDS1100/2100 in the address bar. The IP address may have been assigned manually using DeviceInstaller (see the *EDS1100/2100 Quick Start Guide*) or automatically by DHCP.
3. Enter your username and password. The factory-default username is "admin" and the factory-default password is "PASS." The Device Status web page shown in [Figure 6-1](#) displays configuration, network settings, line settings, tunneling settings, and product information.

Note: The Logout button is available on any web page. Logging out of the web page would force re-authentication to take place the next time the web page is accessed.

Device Status Page

The Device Status page is the first page that appears after you log into the Web Manager. It also appears when you click **Status** in the Main Menu.

Figure 6-1 Web Manager Home Page

EDS2100

Powered by Evolution OS™

LANTRONIX™

EVOLUTION OS™

Status

CLI

Diagnostics

DNS

Email

Filesystem

FTP

Host

HTTP

IP Address Filter

Line

LPD

Modbus

Network

PPP

Protocol Stack

Query Port

RSS

SNMP

SSH

SSL

Syslog

System

Terminal

TFTP

Tunnel

VIP

XML

Device Status

Product Information		
Product Type:	Lantronix EDS2100	
Firmware Version:	5.2.0.0R17	
Build Date:	Nov 8 2010 (09:06:35)	
Serial Number:	07101057G6KRMO	
Uptime:	1 days 20:33:39	
Permanent Config:	Saved	
Network Settings		
Interface:	eth0	
Link:	Auto 10/100 Mbps Auto Half/Full (100 Mbps Half)	
MAC Address:	00:20:4a:a8:8e:e0	
Hostname:	<None>	
IP Address:	172.19.205.6/16	
Default Gateway:	172.19.0.1	
Domain:	<None>	
Primary DNS:	<None>	
Secondary DNS:	<None>	
MTU:	1500	
VIP Conduit:	Down	
Line Settings		
Line 1:	RS232, 9600, None, 8, 1, None	
Line 2:	RS232, 9600, None, 8, 1, None	
Tunneling	Connect Mode	Accept Mode
Tunnel 1:	Disabled	Waiting
Tunnel 2:	Disabled	Waiting


[Logout]

Copyright © Lantronix, Inc. 2007-2010. All rights reserved.

Web Manager Page Components

The layout of a typical Web Manager page is below.

Figure 6-2 Components of the Web Manager Page



The menu bar always appears at the left side of the page, regardless of the page shown. The menu bar lists the names of the pages available in the Web Manager. To bring up a page, click it in the menu bar.

The main area of the page has these additional sections:

- ◆ At the very top, many pages, such as the one in the example above, enable you to link to sub pages. On some pages, you must also select the item you are configuring, such as a line or a tunnel.

- ◆ In the middle of many pages, you can select or enter new configuration settings. Some pages show status or statistics in this area rather than allow you to enter settings.
- ◆ At the bottom of most pages, the current configuration is displayed. In some cases, you can reset or clear a setting.
- ◆ The information or help area shows information or instructions associated with the page.
- ◆ A **Logout** link is available at the upper right corner of every web page. In Chrome or Safari, it is necessary to close out of the browser to logout. If necessary, reopen the browser to log back in.
- ◆ The footer appears at the very bottom of the page. It contains copyright information and a link to the Lantronix home page.

Navigating the Web Manager

The Web Manager provides an intuitive point-and-click interface. A menu bar on the left side of each page provides links you can click to navigate from one page to another. Some pages are read-only, while others let you change configuration settings.

Note: *There may be times when you must reboot the EDS1100/2100 for the new configuration settings to take effect. The chapters that follow indicate when a change requires a reboot.*

Table 6-3 Summary of Web Manager Pages

Web Manager Page	Description	See Page
Status	Shows product information and network, line, and tunneling settings.	42
CLI	Shows Command Line Interface (CLI) statistics and lets you change the current CLI configuration settings.	126
Diagnostics	Lets you perform various diagnostic procedures.	111
DNS	Shows the current configuration of the DNS subsystem and the DNS cache.	69
Email	Shows email statistics and lets you clear the email log, configure email settings, and send an email.	123
Filesystem	Shows file system statistics and lets you browse the file system to view a file, create a file or directory, upload files using HTTP, copy a file, move a file, or perform TFTP actions.	100
FTP	Shows statistics and lets you change the current configuration for the File Transfer Protocol (FTP) server.	73
Host	Lets you view and change settings for a host on the network.	68
HTTP	Shows HyperText Transfer Protocol (HTTP) statistics and lets you change the current configuration and authentication settings.	76
IP Address Filter	Lets you specify all the IP addresses and subnets that are allowed to send data to this device.	109
Line	Shows statistics and lets you change the current configuration and Command mode settings of a serial line.	42

Web Manager Page (continued)	Description	See Page
LPD	Shows LPD (Line Printer Daemon) Queue statistics and lets you configure the LPD and print a test page.	81
Modbus	Shows the current connection status of the Modbus servers listening on the TCP ports and lets you configure the Modbus settings.	97
Network	Shows status and lets you configure the network interface.	38
PPP	Lets you configure a network link using Point-to-Point Protocol (PPP) over a serial line.	70
Protocol Stack	Lets you perform lower level network stack-specific activities.	104
Query Port	Lets you change configuration settings for the query port.	110
RSS	Lets you change current Really Simple Syndication (RSS) settings.	80
SNMP	Lets you change the current Simple Network Management Protocol (SNMP) configuration settings.	72
SSH	Lets you change the configuration settings for SSH server host keys, SSH server authorized users, SSH client known hosts, and SSH client users.	84
SSL	Lets you upload an existing certificate or create a new self-signed certificate.	91
Syslog	Lets you specify the severity of events to log and the server and ports to which the syslog should be sent.	75
System	Lets you reboot device, restore factory defaults, upload new firmware, and change the device long and short names.	121
Terminal	Lets you change current settings for a terminal.	65
TFTP	Shows statistics and lets you change the current configuration for the Trivial File Transfer Protocol (TFTP) server.	74
Tunnel	Lets you change the current configuration settings for a tunnel.	46
VIP	Lets you configure Virtual IP addresses to be used in Tunnel Accept Mode and Tunnel Connect Mode.	137
XML	Lets you export XML configuration and status records, and import XML configuration records.	128

7: Network Settings

This chapter describes how to access, view, and configure network settings from the Network web page. The **Network** web page contains sub-menus that enable you to view and configure the Ethernet network interface and link.

This chapter contains the following sections:

- ◆ [Network 1 \(eth0\) Interface Status](#)
- ◆ [Network 1 \(eth0\) Interface Configuration](#)
- ◆ [Network 1 Ethernet Link](#)

Network 1 (eth0) Interface Status

This page shows the status of the Ethernet network interface.

To view the network interface status:

1. Click **Network** on the menu.
2. Then click **Network 1**, **Interface**, and **Status** at the top of the page. The Network 1 (eth0) Interface Status page appears.

Figure 7-1 Network 1 (eth0) Interface Status

Network 1		
Interface Link		
Status Configuration		
Network 1 (eth0) Interface Status		
	Current	After Reboot
BOOTP Client:	Off	Off
DHCP Client:	On [Renew]	On
IP Address:	172.19.100.199 (DHCP)	<DHCP>
Network Mask:	255.255.0.0 (DHCP)	<DHCP>
Default Gateway:	172.19.0.1 (DHCP)	<DHCP>
Hostname:	<None>	<DHCP>
Domain:	eng.lantronix.com (DHCP)	<DHCP>
DNS Suffix Search List:	eng.lantronix.com. int.lantronix.com. lantronix.com.	<DHCP>
DHCP Client ID:	[0xdc, 0x01]	<None>
MTU:	1500	<DHCP>

Network 1 (eth0) Interface Configuration

This page shows the configuration settings for the Ethernet connection and lets you change these settings.

To view and configure network interface settings:

1. Click **Network 1 > Interface > Configuration** at the top of the page. The Network 1 (eth0) Interface Configuration page appears.

Figure 7-2 Network 1 (eth0) Interface Configuration

BOOTP Client:	<input type="radio"/> On <input checked="" type="radio"/> Off
DHCP Client:	<input checked="" type="radio"/> On <input type="radio"/> Off
IP Address:	<None>
Default Gateway:	<None>
Hostname:	<input type="text"/>
Domain:	<input type="text"/>
DHCP Client ID:	<input type="text"/> <input checked="" type="radio"/> Text <input type="radio"/> Binary
Primary DNS:	<None>
Secondary DNS:	<None>
MTU:	1500

2. Enter or modify the following settings:

Table 7-3 Network 1 (eth0) Interface Configuration

Network 1 Interface Configuration Settings	Description
BOOTP Client	<p>Select On or Off. At boot up, the device will attempt to obtain an IP address from a BOOTP server.</p> <p>Notes:</p> <ul style="list-style-type: none"> ◆ Overrides the configured IP address, network mask, gateway, hostname, and domain. ◆ When DHCP is On, the system automatically uses DHCP, regardless of whether BOOTP Client is On.

Network 1 Interface Configuration Settings	Description
DHCP Client	Select On or Off . At boot up, the device will attempt to lease an IP address from a DHCP server and maintain the lease at regular intervals. <i>Note: Overrides BOOTP, the configured IP address, network mask, gateway, hostname, and domain.</i>
IP Address	Enter the device static IP address. You may enter it alone, in CIDR format, or with an explicit mask. The IP address consists of four octets separated by a period and is used if BOOTP and DHCP are both set to Off . Changing this value requires you to reboot the device. <i>Note: When DHCP is enabled, the device tries to obtain an IP address from DHCP. If it cannot, the device uses an AutoIP address in the range of 169.254.xxx.xxx.</i>
Default Gateway	Enter the IP address of the router for this network. Or, clear the field (appears as <None>). This address is only used for static IP address configuration.
Hostname	Enter the device hostname. It must begin with a letter, continue with a sequence of letters, numbers, and/or hyphens, and end with a letter or number.
Domain	Enter the device domain name.
DHCP Client ID	Enter the ID if the DHCP server uses a DHCP ID. The DHCP server's lease table shows IP addresses and MAC addresses for devices. The lease table shows the Client ID, in hexadecimal notation, instead of the device MAC address.
Primary DNS	IP address of the primary name server. This entry is required if you choose to configure DNS (Domain Name Server) servers.
Secondary DNS	IP address of the secondary name server.
MTU	When DHCP is enabled, the MTU size is (usually) provided with the IP address. When not provided by the DHCP server, or using a static configuration, this value is used. The MTU size can be from 576 to 1500 bytes.

- Click **Submit** to save changes. Some changes to the following settings require a reboot for the changes to take effect:

- ◆ BOOTP Client
- ◆ DHCP Client
- ◆ IP Address
- ◆ DHCP Client ID

Note: If DHCP or BOOTP fails, AutoIP intervenes and assigns an address. A new DHCP negotiation is attempted every 5 minutes to obtain a new IP address. When the DHCP is enabled, any configured static IP address is ignored.

Network 1 Ethernet Link

This page shows the current negotiated Ethernet settings and lets you change the speed and duplex settings.

To view and configure the Ethernet link:

1. Click **Network** on the menu bar and then click **Network 1 > Link** at the top of the page. The Network 1 (eth0) Ethernet Link page appears.
 - ◆ If coming from another Network page, click **Network 1 > Link** at the top of the page.

Figure 7-4 Network 1 Ethernet Link

Network 1

Interface Link

Network 1 (eth0) Ethernet Link

Status

Speed:	100 Mbps
Duplex:	Half

Configuration

Speed:	<input checked="" type="radio"/> Auto <input type="radio"/> 10Mbps <input type="radio"/> 100Mbps
Duplex:	<input checked="" type="radio"/> Auto <input type="radio"/> Half

The **Status** table shows the current negotiated settings. The **Configuration** table shows the current range of allowed settings.

2. Enter or modify the following settings:

Table 7-5 Network 1 Ethernet Link

Network 1-Ethernet Link Settings	Description
Speed	Select the Ethernet link speed. Default is Auto .
Duplex	Select the Ethernet link duplex mode. Default is Auto .

3. Click **Submit**. The changes take effect immediately.

Note: The following section describes the steps to view and configure Line 1 settings; these steps apply to other line instances of the device.

8: Line and Tunnel Settings

This chapter describes how to view and configure lines and tunnels. It contains the following sections:

- ◆ [Line Settings](#)
- ◆ [Tunnel Settings](#)

Note: The number of lines and tunnels available for viewing and configuration differ between Lantronix DeviceLinx products. The screenshots in this manual represent one line and tunnel, as available, for example, on an XPort Pro and EDS1100. However, other device networking products (such as EDS2100, EDS4100, XPort AR, and EDS8/16/32PR) support additional lines and tunnels.

Line Settings

You can view statistics and configure the serial interfaces (referred to as lines) by using the Line web page. When you click Line from the Main Menu, Line 1 fields display.

The following sub-menus can be used:

- ◆ **Line Statistics**—Displays statistics for the serial lines. For example, the bytes received and transmitted, breaks, flow control, parity errors, etc.
- ◆ **Line Configuration**—Enables the change of the name, interface, protocol, baud rates, and parity, etc.
- ◆ **Line Command Mode**—Enables the types of modes, wait time, serial strings, signon message, etc.


The following sections describe the steps to view and configure Line 1 settings. These instructions also apply to additional line menu options.

Line Statistics

This read-only web page shows the status and statistics for the serial line selected at the top of this page.

1. Select **Line** on the menu bar. The Line Statistics page appears.

Figure 8-1 Line 1 Statistics



Line 1		
Statistics Configuration Command Mode		
Line 1 - Statistics		
	Receiver	Transmitter
Bytes:	0	0
Breaks:	0	0
Flow control:	N/A	N/A
Parity Errors:	0	
Framing Errors:	0	
Overrun Errors:	0	
No Rx Buffer Errors:	0	
Queued Receive Bytes:	0	
Queued Transmit Bytes:	0	
CTS input:	not asserted	
RTS output:	asserted	
DSR input:	not asserted	
DTR output:	not asserted	

Line Configuration

This page shows the configuration settings for the serial line selected at the top of the page and lets you change the settings for that serial line.

To configure Line 1:

1. Click **Line 1 > Configuration** at the top of the page. The Line 1 Configuration page appears.

Table 8-2 Line 1 Configuration

Line 1

Statistics
Configuration
Command Mode

Line 1 - Configuration

	Configuration	Status
Name:	<input style="width: 100%;" type="text"/>	
Interface:	RS232 ▼	
State:	Enabled ▼	Enabled
Protocol:	Tunnel ▼	Tunnel
Baud Rate:	9600 ▼	9600
Parity:	None ▼	None
Data Bits:	8 ▼	8
Stop Bits:	1 ▼	1
Flow Control:	None ▼	None
Xon Char:	<input style="width: 100%;" type="text" value="⟨control⟩Q"/>	⟨control⟩Q
Xoff Char:	<input style="width: 100%;" type="text" value="⟨control⟩S"/>	⟨control⟩S
Gap Timer:	⟨None⟩ milliseconds	
Threshold:	56 bytes	

2. Enter or modify the following settings:

Table 8-3 Line 1 Configuration

Line - Configuration Settings	Description
Name	If the Terminal Login Menu feature is being used, enter the name for the line. Leaving this field blank will disable this line from appearing in the Terminal Login Menu. The default Name is blank. See Terminal and Host Settings on page 65 for related configuration information.
Interface	Select the interface type from the drop-down menu. The default is RS232.
State	Indicates whether the current line is enabled. To change the status, select Enabled or Disabled from the drop-down menu.
Protocol	Select the protocol from the drop-down menu. The default is Tunnel.
Baud Rate	Select the baud rate from the drop-down menu. The default is 9600.

Line - Configuration Settings (continued)	Description
Parity	Select the parity from the drop-down menu. The default is None.
Data Bits	Select the number of data bits from the drop-down menu. The default is 8.
Stop Bits	Select the number of stop bits from the drop-down menu. The default is 1.
Flow Control	Select the flow control from the drop-down menu. The default is None.
Xon Char	Specify the character to use to start the flow of data when Flow Control is set to Software. Prefix a decimal character with \ or a hexadecimal character with 0x, or provide a single printable character. The default Xon char is 0x11.
Xoff Char	Specify the character to use to stop the flow of data when Flow Control is set to Software. Prefix a decimal character with \ or a hexadecimal character with 0x, or provide a single printable character. The default Xoff char is 0x13.
Gap Timer	The driver forwards received serial bytes after the Gap Timer delay from the last character received. By default, the delay is four character periods at the current baud rate (minimum 1 ms).
Threshold	The driver will also forward received characters after Threshold bytes have been received.

3. Click **Submit**.
4. Repeat above steps as desired, according to additional line(s) available for your product.

Line Command Mode

Setting Command Mode enables the CLI on the serial line.

To configure Line 1 Command Mode:

1. Click **Line 1 > Command Mode** at the top of the page. The Line 1 Command Mode page appears.

Note: The **CP Group** option displayed in the screenshot is only supported in XPort Pro and XPort AR.

Figure 8-4 Line 1 Command Mode

Current Configuration	
Mode:	Disabled (Inactive)
Wait Time:	5000 milliseconds
Serial String:	<None>
Echo Serial String:	On
CP Group:	<None>
Signon Message:	<None>

2. Enter or modify the following settings:

Table 8-5 Line 1 Command Mode

Line – Command Mode Settings	Description
Mode	<p>Select the method of enabling Command Mode or choose to disable Command Mode.</p> <ul style="list-style-type: none"> ◆ Always = immediately enables Command Mode for the serial line. ◆ Use Serial String = enables Command Mode when the serial string is read on the serial line during boot time. ◆ Use CP Group = enables Command Mode based on the status of a CP Group. When the value matches the current value of the group, Command Mode is enabled on the serial line. ◆ Use both Serial String and CP Group = the serial string and the value of the CP group must be matched to enable Command Mode. ◆ Disabled = turns off Command Mode.
Wait Time	Enter the wait time for the serial string during boot-up in milliseconds.

Line – Command Mode Settings (continued)	Description
Serial String	<p>Enter the serial string characters. Select a string type.</p> <ul style="list-style-type: none"> ◆ Text = string of bytes that must be read on the Serial Line during boot time to enable Command Mode. It may contain a time element in x milliseconds, in the format {x}, to specify a required delay. ◆ Binary = string of characters representing byte values where each hexadecimal byte value starts with \0x and each decimal byte value starts with \.
Echo Serial String	Select Yes to enable echoing of the serial string at boot-up.
Signon Message	<p>Enter the boot-up signon message. Select a string type.</p> <ul style="list-style-type: none"> ◆ Text = string of bytes sent on the serial line during boot time. ◆ Binary = one or more byte values separated by commas. Each byte value may be decimal or hexadecimal. Start hexadecimal values with 0x. <p><i>Note: This string will be output on the serial port at boot, regardless of whether command mode is enabled or not.</i></p>

3. Click **Submit**.

Tunnel Settings

Note: The number of lines and tunnels available for viewing and configuration differ between Lantronix DeviceLinx products. The screenshots in this manual represent one line and tunnel, as available, for example, on an XPort Pro and EDS1100. However, other device networking products (such as EDS2100, EDS4100, XPort AR, and EDS8/16/32PR) support additional lines and tunnels.

Tunneling allows serial devices to communicate over a network, without “being aware” of the devices which establish the network connection between them. Tunneling parameters are configured using the Web Manager or Command Mode Tunnel Menu. See [Configuration Using Web Manager \(on page 33\)](#) or the EDS1100/2100 Command Reference for the full list of commands.

The EDS1100/2100 supports two tunneling connections simultaneously per serial port. One of these connections is Connect Mode; the other connection is Accept Mode. The connections on one serial port are separate from those on another serial port.

- ◆ **Connect Mode:** the EDS1100/2100 actively makes a connection. The receiving node on the network must listen for the Connect Mode’s connection. Connect Mode is disabled by default.
- ◆ **Accept Mode:** the EDS1100/2100 listens for a connection. A node on the network initiates the connection. Accept Mode is enabled by default.
- ◆ **Disconnect Mode:** this mode defines how an open connection stops the forwarding of data. The specific parameters to stop the connection are configurable. Once the EDS1100/2100 Disconnect Mode observes the defined event occur, it will disconnect both Accept Mode and Connect Mode connections on that port.

When any character comes in through the serial port, it gets copied to both the Connect Mode connection and the Accept Mode connection (if both are active).

You can view statistics and configure two tunnels by using the Tunnel web page. When you click Tunnel from the Main Menu, Tunnel 1 fields display. To go to Tunnel 2, click the Tunnel 2 button.

There are six sub-menus listed at the top of the Tunnel web page that you can use as follows:

- ◆ [Tunnel – Statistics](#)
- ◆ [Tunnel – Serial Settings](#)
- ◆ [Tunnel – Packing Mode](#)
- ◆ [Tunnel – Accept Mode](#)
- ◆ [Tunnel – Connect Mode](#)
- ◆ [Tunnel – Disconnect Mode](#)
- ◆ [Tunnel – Modem Emulation](#)

Tunnel – Statistics

Displays statistics for the available lines. For example, Completed Accepts, Completed Connects, Disconnects, Dropped Accepts, Dropped Connects, etc. The EDS1100/2100 logs statistics for tunneling. The **Dropped** statistic shows connections ended by the remote location. The **Disconnects** statistic shows connections ended by the EDS1100/2100.

To display the tunnel statistics, perform the following steps.

1. Click **Tunnel** on the menu bar. The Statistics page for Tunnel 1 appears.

Figure 8-6 Tunnel 1 Statistics

Tunnel 1

Statistics
 Accept Mode

Serial Settings
 Connect Mode
 Modem Emulation

Packing Mode
 Disconnect Mode

Tunnel 1 - Statistics

Aggregate Counters	
Completed Accepts:	0
Completed Connects:	0
Disconnects:	0
Dropped Accepts:	0
Dropped Connects:	0
Octets forwarded from Serial:	0
Octets forwarded from Network:	0
Accept Connection Time:	0 days 00:00:00
Connect 1 Connection Time:	0 days 00:00:00
Connect 2 Connection Time:	0 days 00:00:00
Connect 3 Connection Time:	0 days 00:00:00
Connect 4 Connection Time:	0 days 00:00:00
Connect 5 Connection Time:	0 days 00:00:00
Connect 6 Connection Time:	0 days 00:00:00
Connect 7 Connection Time:	0 days 00:00:00
Connect 8 Connection Time:	0 days 00:00:00
Connect DNS Address Changes:	0
Connect DNS Address Invalids:	0
Accept Counters	
There is no active connection.	
Connect 1 Counters	
There is no active connection.	
Connect 2 Counters	
There is no active connection.	
Connect 3 Counters	
There is no active connection.	
Connect 4 Counters	
There is no active connection.	
Connect 5 Counters	
There is no active connection.	
Connect 6 Counters	
There is no active connection.	
Connect 7 Counters	
There is no active connection.	
Connect 8 Counters	
There is no active connection.	

Tunnel – Serial Settings

Serial line settings are configurable for the corresponding serial line of the selected tunnel. Configure the buffer size to change the maximum amount of data the serial port stores. For any active connection, the device sends the data in the buffer.

The modem control signal DTR on the Line may be continuously asserted or asserted only while either an Accept Mode tunnel or a Connect Mode tunnel is connected.

To configure serial settings:

1. Click **Tunnel > Serial Settings** at the top of the page. The Tunnel 1 Serial Settings page appears.

Figure 8-7 Tunnel 1 Serial Settings

Tunnel 1

Statistics **Serial Settings** Packing Mode
Accept Mode Connect Mode Disconnect Mode
Modem Emulation

Tunnel 1 - Serial Settings

Line Settings:	RS232, 921600, None, 8, 1, Hardware
Protocol:	Tunnel
DTR:	<input type="radio"/> Unasserted <input type="radio"/> TruPort <input checked="" type="radio"/> Asserted while connected <input type="radio"/> Continuously asserted

2. View or modify the following settings:

Tunnel - Serial Settings	Description
Line Settings (display only)	Current serial settings for the line.
Protocol (display only)	The protocol being used on the line. In this case, Tunnel.
DTR	Select when to assert DTR. <ul style="list-style-type: none"> ◆ Unasserted = never asserted ◆ TruPort = asserted whenever either a connect or an accept mode tunnel connection is active with the Telnet Protocol RFC2217 saying that the remote DSR is asserted. ◆ Asserted while connected = asserted whenever either a connect or an accept mode tunnel connection is active. ◆ Continuously asserted = asserted regardless of the status of a tunnel connection.

3. Click **Submit**.

Tunnel – Packing Mode

Packing Mode takes data from the serial port, packs it together, and sends it over the network. Packing can be configured based on threshold (size in bytes, timeout (milliseconds), or a single character.

Size is set by modifying the threshold field. When the number of bytes reaches the threshold, a packet is sent immediately.

The timeout field is used to force a packet to be sent after a maximum time. The packet is sent even if the threshold value is not reached.

When Send Character is configured, a single printable character or control character read on the Serial Line forces the packet to be sent immediately. There is an optional trailing character parameter which can be specified. It can be a single printable character or a control character.

To configure the Tunnel Packing Mode:

1. Select **Tunnel > Packing Mode** at the top of the page. The Tunnel 1 Packing Mode page appears. Depending on the Mode selection, different configurable parameters are presented to the user. The following figures show the display for each of the three packing modes.

Figure 8-8 Tunnel 1 Packing Mode (Mode = Disable)

The screenshot shows the 'Tunnel 1' configuration interface. At the top, there is a tab labeled 'Tunnel 1'. Below it, a menu bar contains 'Statistics', 'Serial Settings', 'Packing Mode' (which is selected), 'Accept Mode', 'Connect Mode', 'Disconnect Mode', and 'Modem Emulation'. The main title of the page is 'Tunnel 1 - Packing Mode'. Under this title, there is a 'Mode:' label followed by three radio button options: 'Disable' (which is selected), 'Timeout', and 'Send Character'.

Figure 8-9 Tunnel 1 Packing Mode (Mode = Timeout)

Tunnel 1

Statistics
Serial Settings
Packing Mode

Accept Mode
Connect Mode
Disconnect Mode

Modem Emulation

Tunnel 1 - Packing Mode

Mode:	<input type="radio"/> Disable <input checked="" type="radio"/> Timeout <input type="radio"/> Send Character
Threshold:	<input style="width: 80px;" type="text" value="512"/> bytes
Timeout:	<input style="width: 80px;" type="text" value="1000"/> milliseconds

Submit

Figure 8-10 Tunnel 1 Packing Mode (Mode = Send Character)

Tunnel 1

Statistics
Serial Settings
Packing Mode

Accept Mode
Connect Mode
Disconnect Mode

Modem Emulation

Tunnel 1 - Packing Mode

Mode:	<input type="radio"/> Disable <input type="radio"/> Timeout <input checked="" type="radio"/> Send Character
Threshold:	<input style="width: 80px;" type="text" value="512"/> bytes
Send Character:	<input style="width: 100px;" type="text" value="⟨control⟩M"/>
Trailing Character:	<input style="width: 100px;" type="text" value="⟨None⟩"/>

Submit

2. Enter or modify the following settings:

Table 8-11 Tunnel Packing Mode

Tunnel - Packing Mode Settings	Description
Mode	<ul style="list-style-type: none"> ◆ Select Disable to disable Packing Mode completely. ◆ Select Timeout to send data after the specified time has elapsed. ◆ Select Send Character to send the queued data when the send character is received.

Tunnel - Packing Mode Settings (continued)	Description
Threshold (Appears for both Timeout and Send Character Modes)	Send the queued data when the number of queued bytes reaches the threshold. When the buffer fills to this specified amount of data in bytes (and the timeout has not elapsed), the device packs the data and sends it out; applies only if the Packing Mode is not Disabled.
Timeout (Appears for Timeout Mode)	Enter a time, in milliseconds, for the device to send the queued data after the first character was received. Specifies the time duration in milliseconds; applies only if the Packing Mode is Timeout.
Send Character (Appears for Send Character Mode)	Enter the send character (single printable or control). Upon receiving this character, the device sends out the queued data. The data is packed until the specified send character is encountered. Similar to a start or stop character, the device packs the data until it sees the send character. The device then sends the packed data and the send character in the packet. Applies only if the Packing Mode is Send Character.
Trailing Character (Appears for Send Character Mode)	Enter the trailing character (single printable or control). This character is sent immediately following the send character. This is an optional setting. If a trailing character is defined, this character is appended to data put on the network immediately following the send character.

3. Click **Submit**.

Tunnel – Accept Mode

Controls how a tunnel behaves when a connection attempt originates from the network. In Accept Mode, the EDS1100/2100 waits for a connection from the network. The configurable local port is the port the remote device connects to for this connection. There is no remote port or address. The default local port is 10001 for serial port 1 and increases sequentially for each additional serial port, if supported.

Accept Mode supports the following protocols:

- ◆ SSH (the EDS1100/2100 is the server in Accept Mode). When using this protocol, the SSH server host keys and at least one SSH authorized user must be configured.
- ◆ SSL
- ◆ TCP
- ◆ AES encryption over TCP
- ◆ Telnet (The EDS1100/2100 supports IAC codes. It drops the IAC codes when Telnetting and does not forward them to the serial port).

Accept Mode has the following states:

- ◆ Disabled (never a connection)
- ◆ Enabled (always listening for a connection)
- ◆ Active if it receives any character from the serial port
- ◆ Active if it receives a specific (configurable) character from the serial port (same start character as Connect Mode's start character)
- ◆ Modem control signal
- ◆ Modem emulation

To configure the tunnel's Accept Mode:

1. Click **Tunnel > Accept Mode** at the top of the page. The Tunnel 1 Accept Mode page appears.

Note: The **CP Output** option displayed in the screenshot is only supported in XPort Pro and XPort AR.

Figure 8-12 Tunnel 1 Accept Mode

Tunnel 1

Statistics
Accept Mode

Serial Settings
Connect Mode
Modem Emulation

Packing Mode
Disconnect Mode

Tunnel 1 - Accept Mode

Mode:	<div style="border: 1px solid black; padding: 2px;">Always</div> ▼
Local Port:	<div style="border: 1px solid black; padding: 2px;">10001</div>
Protocol:	<div style="border: 1px solid black; padding: 2px;">TCP</div> ▼
TCP Keep Alive:	<div style="border: 1px solid black; padding: 2px;">45000</div> milliseconds
Flush Serial:	<input type="radio"/> Enabled <input checked="" type="radio"/> Disabled
Block Serial:	<input type="radio"/> Enabled <input checked="" type="radio"/> Disabled
Block Network:	<input type="radio"/> Enabled <input checked="" type="radio"/> Disabled
Password:	<div style="border: 1px solid black; padding: 2px;"><None></div>
Email on Connect:	<div style="border: 1px solid black; padding: 2px;"><None></div> ▼
Email on Disconnect:	<div style="border: 1px solid black; padding: 2px;"><None></div> ▼
CP Output:	Group: <div style="border: 1px solid black; padding: 2px; width: 150px;"></div>

2. Enter or modify the following settings:

Table 8-13 Tunnel Accept Mode

Tunnel - Accept Mode Settings	Description
Mode	<p>Select the method used to start a tunnel in Accept mode. Choices are:</p> <ul style="list-style-type: none"> ◆ Disabled = do not accept an incoming connection. ◆ Always = accept an incoming connection (<i>default</i>) ◆ Any Character = start waiting for an incoming connection when any character is read on the serial line. ◆ Start Character = start waiting for an incoming connection when the start character for the selected tunnel is read on the serial line. ◆ Modem Control Asserted = start waiting for an incoming connection as long as the Modem Control pin (DSR) is asserted on the serial line until a connection is made. ◆ Modem Emulation = start waiting for an incoming connection when triggered by modem emulation AT commands. Connect mode must also be set to Modem Emulation.
Local Port	Enter the port number for use as the local port. The defaults are port 10001 for Tunnel 1. Additional tunnels, if supported, increase sequentially.
Protocol	Select the protocol type for use with Accept Mode. The default protocol is TCP. If you select TCP AES you will need to configure the AES keys.
TCP Keep Alive	Enter the time, in seconds, the device waits during a silent connection before checking if the currently connected network device is still on the network. If the unit then gets no response after 8 attempts, it drops that connection.

Tunnel - Accept Mode Settings (continued)	Description
Flush Serial Data	Select Enabled to flush the serial data buffer on a new connection.
Block Serial Data	Select On to block, or not tunnel, serial data transmitted to the device.
Block Network	Select On to block, or not tunnel, network data transmitted to the device.
Password	<p>Enter a password that clients must send to the device within 30 seconds from opening a network connection to enable data transmission.</p> <p>The password can have up to 31 characters and must contain only alphanumeric characters and punctuation. When set, the password sent to the device must be terminated with one of the following: (a) 0x0A (LF), (b) 0x00, (c) 0x0D 0x0A (CR LF), or (d) 0x0D 0x00.</p>
Email on Connect	Select whether the device sends an email when a connection is made. Select None if you do not want to send an email. Otherwise, select the Email profile to use for sending.
Email on Disconnect	Select whether the device sends an email when a connection is closed. Select None if you do not want to send an email. Otherwise, select the Email profile to use for sending.

3. Click **Submit**.
4. Repeat these steps to configure additional tunnels as applicable.

Tunnel – Connect Mode

Connect Mode defines how the device makes an outgoing connection. When enabled, Connect Mode is always on and attempting a network connection if the connection mode condition warrants it. For Connect Mode to function, it must:

- ◆ Be enabled
- ◆ Have a remote host configured
- ◆ Have a remote port is configured

Enter the remote host address as an IP address or DNS name. The EDS1100/2100 device will make a connection only if it can resolve the address. For DNS names, the EDS1100/2100 will re-evaluate the address after being established for 4 hours. If re-evaluation results in a different address, it will close the connection.

Connect Mode supports the following protocols:

- ◆ **TCP**
- ◆ **AES encryption over TCP and UDP**

When setting AES encryption, both the encrypt key and the decrypt key must be specified. The encrypt key is used for data sent out. The decrypt key is used for receiving data. Both of the keys may be set to the same value.

- ◆ **SSH**

To configure SSH, the SSH client username must be configured. In Connect Mode, the EDS1100/2100 is the SSH client. Ensure the EDS1100/2100 SSH client username is configured on the remote SSH server before using it with the EDS1100/2100.

- ◆ **SSL**

- ◆ **UDP**

Is only available in Connect Mode because it is a connectionless protocol. For Connect Mode using UDP, the EDS1100/2100 accepts packets from any device on the network. It will send packets to the last device that sent it packets.

- ◆ **Telnet**

Note: *The Local Port in Connect Mode is independent of the port configured in Accept Mode.*

There are six different connect modes:

- ◆ **Disable**
No connection is attempted.
- ◆ **Always**
A connection is always attempted.
- ◆ **Any Character**
A connection is attempted if it detects any character from the serial port.
- ◆ **Start Character**
A connection is attempted if it detects a specific and configurable character from the serial port.

Note: *While in the “Any Character” or “Start Character” connection modes, the EDS1100/2100 waits and retries the connection if the connection cannot be made. Once it makes a connection and then disconnects, it will not reconnect until it sees another character or the start character again (depending on the configured setting).*

◆ **Modem Control Asserted**

A connection is attempted when the modem control pin is asserted in the serial line.

◆ **Modem Emulation**

A connection is attempted by an ATD command.

To configure Tunnel 1 Connect Mode:

1. Select **Tunnel > Connect Mode** at the top of the page. The Tunnel 1 Connect Mode page appears.

Note: The **CP Output** option displayed in the screenshot is only supported in XPort Pro and XPort AR.

Figure 8-14 Tunnel 1 Connect Mode

Tunnel 1

Statistics
Accept Mode

Serial Settings
Connect Mode
Modem Emulation

Packing Mode
Disconnect Mode

Tunnel 1 - Connect Mode

Mode:	Disable ▼
Local Port:	<Random>
Host 1:	<None>
Reconnect Timer:	15000 milliseconds
Flush Serial Data:	<input type="radio"/> Enabled <input checked="" type="radio"/> Disabled
Block Serial:	<input type="radio"/> Enabled <input checked="" type="radio"/> Disabled
Block Network:	<input type="radio"/> Enabled <input checked="" type="radio"/> Disabled
Email on Connect:	<None> ▼
Email on Disconnect:	<None> ▼
CP Output:	Group: <input style="width: 150px;" type="text"/>

2. Enter or modify the following settings:

Table 8-15 Tunnel Connect Mode

Tunnel – Connect Mode Settings	Description
Mode	<p>Select the method to be used to attempt a connection to a remote host or device. Choices are:</p> <ul style="list-style-type: none"> ◆ Always = a connection is attempted until one is made. If the connection gets disconnected, the EDS1100/2100 retries until it makes a connection. (default) ◆ Disable = an outgoing connection is never attempted. ◆ Any Character = a connection is attempted when any character is read on the serial line. ◆ Start Character = a connection is attempted when the start character for the selected tunnel is read on the serial line. ◆ Modem Control Asserted = a connection is attempted as long as the Modem Control pin (DSR) is asserted, until a connection is made. ◆ Modem Emulation = a connection is attempted when triggered by modem emulation AT commands.
Local Port	<p>Enter the port for use as the local port. A random port is selected by default. Once you have configured a number, click the Random link in the Current Configuration to switch back to random.</p>
<p>Host</p> <p><i>Note: If security is a concern, it is highly recommended that SSH be used. When using SSH, both the SSH Server Host Keys and SSH Server Authorized Users must be configured.</i></p>	<p>Click <None> in the Host field to configure the Host parameters.</p> <ul style="list-style-type: none"> ◆ VIP = Enabling the VIP directs the tunnel to connect to a remote Lantronix Virtual IP identified by the VIP Name. When VIP is enabled, the Host 2 field displays. Default is Disabled. ◆ VIP Name = Displays configured VIP name, used only if VIP is enabled. ◆ Address = Enter the remote Host Address as an IP address or DNS name. It designates the address of the remote host to connect to. Displays configured IP address or DNS address, used only if VIP is disabled. ◆ Port = Enter the port for use as the Host Port. It designates the port on the remote host to connect to. Displays configured Port. ◆ Protocol = Select the protocol type for use with Connect Mode. The default protocol is TCP. Additional fields may need to be completed depending on protocol chosen for the host.: <ul style="list-style-type: none"> ➢ For SSH, also enter an SSH Username. ➢ For SSL, there are no additional fields to complete. ➢ For TCP, TCP AES and Telnet, use the TCP Keep Alive field to adjust the value. ➢ For TCP AES, enter the AES Encrypt and AES Decrypt Keys. Both of keys may be set to the same value. ➢ For UDP, there are no additional fields to complete. In this mode, the device accepts packets from any device on the network and sends packets to the last device that sent it packets. ➢ For UDP AES, enter the AES Encrypt and AES Decrypt Keys. ◆ SSH Username = Displays configured username, used only if SSH protocol is selected. ◆ TCP Keep Alive = Default is 45000 milliseconds. Enter zero to disable and blank the value to restore the default. ◆ AES Encrypt/Decrypt Key = Displays presence of key, used only if protocol with AES is selected.

Tunnel – Connect Mode Settings (continued)	Description
Reconnect Timer	<p>Enter the reconnect time in milliseconds. The device attempts to reconnect after this amount of time after failing a connection or exiting an existing connection. This behavior depends upon the Disconnect Mode.</p> <p>Note:</p> <ul style="list-style-type: none"> ◆ When you configure Tunnel - Connect Mode, you can specify a number of milliseconds to attempt to reconnect after a dropped connection has occurred. The default is 1500 milliseconds. ◆ The Reconnect Timer only applies if a Disconnect Mode is configured. With a Disconnect Mode set, the device server maintains a connection until the disconnect mode condition is met (at which time the device server closes the connection). If the tunnel is dropped due to conditions beyond the device server, the device server attempts to re-establish a failed connection when the specified reconnect interval reaches its limit. ◆ Any network-side disconnect is considered an error and a reconnect is attempted without regard to the Connect Mode settings. Simultaneous Connect Mode connections require some Disconnect Mode configurations or the connections will never terminate. See Tunnel – Disconnect Mode on page 61 for more information about the parameters. ◆ If Disconnect Mode is disabled and the network connection is dropped, then the re-establishment of a tunnel connection is governed by the configured Connect Mode settings.
Flush Serial Data	<p>Select whether to flush the serial line when a connection is made. Choices are:</p> <ul style="list-style-type: none"> ◆ Enabled = flush the serial line when a connection is made. ◆ Disabled = do not flush the serial line. (default)
Block Serial	<p>Select Enabled to block (not tunnel) serial data transmitted to the device. This is a debugging tool that causes serial data sent to the device to be ignored.</p>
Block Network	<p>Select Enabled to block (not tunnel) network data transmitted to the device. This is a debugging tool that causes network data sent to the device to be ignored.</p>
Email on Connect	<p>Select whether the device sends an email when a connection is made. Select None if you do not want to send an email. Otherwise, select the Email profile to use.</p>
Email on Disconnect	<p>Select whether the device sends an email when a connection is closed. Select None if you do not want to send an email. Otherwise, select the Email profile to use.</p>

3. Click **Submit**. The host is configured. A second host appears underneath the newly configured host.
4. Repeat these steps to configure additional hosts as necessary. EDS1100/2100 supports configuration of up to sixteen hosts.

Connecting Multiple Hosts

If more than one host is configured, a **Host Mode** option appears. Host Mode controls how multiple hosts will be accessed. For EDS1100/2100, the Connect Mode supports up to sixteen Hosts. Hosts may be accessed sequentially or simultaneously:

- ◆ **Sequential** – Sequential host lists establish a prioritized list of tunnels. The host specified as Host 1 will be attempted first. If that fails, it will proceed to Host 2, 3, etc, in the order they are specified. When a connection drops, the cycle starts again with Host 1 and proceeds in order. Establishing the host order is accomplished with host list promotion (see [Host List Promotion on page 60](#)). Sequential is the default Host Mode.
- ◆ **Simultaneous** – A tunnel will connect to all hosts accepting a connection. Simultaneous connections occur at the same time to all listed hosts. The device can support a maximum of 64 total aggregate connections.

Tunnel 1

Statistics
Serial Settings
Packing Mode

Accept Mode
Connect Mode
Disconnect Mode

Modem Emulation

Changed Host 1 Address to "172.19.100.6".
 Changed Host 2 Address to "172.19.100.5".
 Changed Host 3 Address to "172.19.100.7".
 The changes have been written to Flash.

Mode:	Always ▼
Local Port:	<Random>
Host 1:	172.19.100.5:<None>, TCP, 45000 msec
Host 2: ⬆	172.19.100.6:<None>, TCP, 45000 msec
Host 3: ⬆	172.19.100.7:<None>, TCP, 45000 msec
Host 4:	<None>
Host Mode:	<input checked="" type="radio"/> Sequential <input type="radio"/> Simultaneous
Reconnect Timer:	15000 milliseconds
Flush Serial Data:	<input type="radio"/> Enabled <input checked="" type="radio"/> Disabled
Block Serial:	<input type="radio"/> Enabled <input checked="" type="radio"/> Disabled
Block Network:	<input type="radio"/> Enabled <input checked="" type="radio"/> Disabled
Email on Connect:	<None> ▼
Email on Disconnect:	<None> ▼
CP Output:	Group:

Submit

Figure 8-16 Host 1, Host 2, Host 3 Exchanged

Note: The CP Output option displayed in the screenshot is only supported in XPort Pro and XPort AR.

Host List Promotion

This feature allows Host IP promotion of individual hosts in the overall sequence.

To promote a specific Host:

1. Click the ⬆ icon in the desired Host field, for example Host 2 and Host 3.
2. The selected Host(s) exchanges its place with the Host above it.
3. Click **Submit**. The hosts change sequence.

Tunnel – Disconnect Mode

Relates to the disconnect of a tunnel. Disconnect Mode ends Accept Mode and Connect Mode connections. When disconnecting, the EDS1100/2100 shuts down connections gracefully.

The following settings end a connection:


- ◆ The EDS1100/2100 receives the stop character.
- ◆ The timeout period has elapsed and no activity is going in or out of the EDS1100/2100. Both Accept Mode and Connect Mode must be idle for the time frame.
- ◆ The EDS1100/2100 observes the modem control inactive setting.

Note: To clear data out of the serial buffers upon a disconnect, enable “Flush Serial Data”.

To configure the tunnel Disconnect Mode:

1. Click **Tunnel > Disconnect Mode** at the top of the page. The Tunnel 1 Disconnect Mode page appears.

Figure 8-17 Tunnel 1 Disconnect Mode



Tunnel 1	
Statistics	Serial Settings
Accept Mode	Connect Mode
	Disconnect Mode
	Modem Emulation

Tunnel 1 - Disconnect Mode

Stop Character:	<None>
Modem Control:	<input type="radio"/> Enabled <input checked="" type="radio"/> Disabled
Timeout:	0 milliseconds
Flush Serial Data:	<input type="radio"/> Enabled <input checked="" type="radio"/> Disabled

2. Enter or modify the following settings:

Table 8-18 Tunnel Disconnect Mode

Tunnel – Disconnect Mode Settings	Description
Stop Character	Enter the stop character in ASCII, hexadecimal, or decimal notation. Select <None> to disable.
Modem Control	Select Enabled to disconnect when the modem control pin is not asserted on the serial line.
Timeout	Enter a time, in milliseconds, for the device to disconnect on a Timeout . The value 0 (zero) disables the idle timeout.
Flush Serial Data	Select Enabled to flush the serial data buffer on a disconnection.

3. Click **Submit**.

Tunnel – Modem Emulation

A tunnel in Connect Mode can be initiated using modem commands incoming from the Serial Line. This page enables you to configure the modem emulation settings when you select Modem Emulation as the Tunnel Connect Mode type.

The Modem Emulation Command Mode supports the standard AT command set. For a list of available commands from the serial or Telnet login, enter **AT?**. Use **ATDT**, **ATD**, and **ATDP** to establish a connection. All of these commands behave like a modem. For commands that are valid but not applicable to the EDS1100/2100, an "OK" message is sent (but the command is silently ignored).

The EDS1100/2100 attempts to make a Command Mode connection as per the IP/DNS/port numbers defined in Connect Mode. It is possible to override the remote address, as well as the remote port number.

The following table lists and describes the available commands.

Table 8-19 Modem Emulation Commands and Descriptions

Command	Description
+++	Switches to Command Mode if entered from serial port during connection.
AT?	Help.
ATDT<Address Info>	Establishes the TCP connection to socket (<ipaddress>:<port>).
ATDP<Address Info>	See ATDT.
ATD	Like ATDT. Dials default Connect Mode remote address and port.
ATD<Address Info>	Sets up a TCP connection. A value of 0 begins a command line interface session.
ATO	Switches to data mode if connection still exists. Vice versa to '+++'.
ATEn	Switches echo in Command Mode (off - 0, on - 1).
ATH	Disconnects the network session.
ATI	Shows modem information.
ATQn	Quiet mode (0 - enable results code, 1 - disable results code.)
ATVn	Verbose mode (0 - numeric result codes, 1 - text result codes.)
ATXn	Command does nothing and returns OK status.
ATUn	Accept unknown commands. (n value of 0 = off. n value of 1 = on.)
AT&V	Display current and saved settings.
AT&F	Reset settings in NVR to factory defaults.
AT&W	Save active settings to NVR.
ATZ	Restores the current state from the setup settings.
ATS0=n	Accept incoming connection. <ul style="list-style-type: none"> ◆ N value of 0—Disable ◆ N value of 1—Connect automatically ◆ N value of 2+—Connect with ATA command.
ATA	Answer incoming connection (if ATS0 is 2 or greater).

Table 8-19 Modem Emulation Commands and Descriptions (continued)

Command (continued)	Description
AI	Repeat last valid command.

For commands that can take address information (ATD, ATDT, ATDP), the destination address can be specified by entering the IP Address, or entering the IP Address and port number. For example, <ipaddress>:<port>. The port number cannot be entered on its own.

For ATDT and ATDP commands less than 255 characters, the EDS1100/2100 replaces the last segment of the IP address with the configured Connect Mode remote station address. It is possible to use the last two segments also, if they are under 255 characters. For example, if the address is 100.255.15.5, entering "ATDT 16.6" results in 100.255.16.6.

When using ATDT and ATDP, enter 0.0.0.0 to switch to the Command Line Interface (CLI). Once the CLI is exited by using the CLI exit command, the EDS1100/2100 reverts to modem emulation mode. By default, the +++ characters are not passed through the connection. Turn on this capability using the modem echo pluses command.

To configure modem emulation:

1. Select **Tunnel > Modem Emulation** at the top of the page. The Tunnel 1 Modem Emulation page appears.

Figure 8-20 Tunnel 1 Modem Emulation

Tunnel 1

Statistics
Serial Settings
Packing Mode

Accept Mode
Connect Mode
Disconnect Mode

Modem Emulation

Tunnel 1 - Modem Emulation

WARNING: Tunnel Connect Mode is not "Modem Emulation".

	Configuration	Status
Echo Pluses:	<input type="radio"/> Enabled <input checked="" type="radio"/> Disabled	
Echo Commands:	<input checked="" type="radio"/> Enabled <input type="radio"/> Disabled	Enabled
Verbose Response:	<input checked="" type="radio"/> Enabled <input type="radio"/> Disabled	Enabled
Response Type:	<input checked="" type="radio"/> Text <input type="radio"/> Numeric	Text
Error Unknown Commands:	<input type="radio"/> Enabled <input checked="" type="radio"/> Disabled	Disabled
Incoming Connection:	<input checked="" type="radio"/> Disabled <input type="radio"/> Automatic <input type="radio"/> Manual	Disabled
Connect String:	<input style="width: 100%;" type="text"/>	
Display Remote IP:	<input type="radio"/> Enabled <input checked="" type="radio"/> Disabled	

2. Enter or modify the following settings:

Table 8-21 Tunnel Modem Emulation

Tunnel- Modem Emulation Settings	Description
Echo Pluses	Select Enabled to echo +++ when entering modem Command Mode.
Echo Commands	Select Enabled to echo the modem commands to the console.
Verbose Response	Select Enabled to send modem response codes out on the serial line.
Response Type	Select the type of response code: Text or Numeric .
Error Unknown Commands	Select whether an ERROR or OK response is sent in reply to unrecognized AT commands. Choices are: ♦ Enabled = ERROR is returned for unrecognized AT commands. ♦ Disabled = OK is returned for unrecognized AT commands. Default is Disabled .
Incoming Connection	Select whether Incoming Connection requests will be disabled, answered automatically, or answered manually. Default is Disabled .
Connect String	Enter the connect string. This modem initialization string prepares the modem for communications. It is a customized string sent with the "CONNECT" modem response code.
Display Remote IP	Selects whether the incoming RING sent on the Serial Line is followed by the IP address of the caller. Default is Disabled .

3. Click **Submit**.

9: Terminal and Host Settings

This chapter describes how to view and configure the Terminal Login Connect Menu and associated Host configuration. It contains the following sections:

- ◆ [Terminal Settings](#)
- ◆ [Host Configuration](#)

The Terminal Login Connect Menu feature allows the EDS1100/2100 device to present a menu of predefined connections when the device is accessed via telnet, ssh, or a serial port. From the menu, a user can choose one of the presented options and the device automatically makes the predefined connection.

The Terminal page controls whether a Telnet, SSH, or serial port connection presents the CLI or the Login Connect Menu. By default, the CLI is presented when the device is accessed. When configured to present the Login Connect Menu, the hosts configured via the Hosts page, and named serial lines are presented.

Terminal Settings

This page shows configuration settings for each terminal connection method. You can configure whether each serial line or the telnet/SSH server presents a CLI or a Login Connect menu when a connection is made.

Line Terminal Configuration

To configure a line to support an attached terminal:

1. Click **Terminal** on the menu and then select the line that is connected to the terminal you want to configure. The default is **Line 1**. Configuration is automatically selected. The Terminal on Line 1 Configuration page appears.

Figure 9-1 Terminal on Line 1 Configuration

Network Line 1	
Configuration	
Terminal on Line 1 - Configuration	
Terminal Type:	UNKNOWN
Login Connect Menu:	<input type="radio"/> Enabled <input checked="" type="radio"/> Disabled
Exit Connect Menu:	<input type="radio"/> Enabled <input checked="" type="radio"/> Disabled
Send Break:	<None>
Break Duration:	500 milliseconds
Echo:	<input checked="" type="radio"/> Enabled <input type="radio"/> Disabled

2. Enter or modify the following settings:

Table 9-2 Terminal on Line 1 Configuration

Terminal on Line Configuration Settings	Description
Terminal Type	Enter text to describe the type of terminal. The text will be sent to a host via IAC. Note: IAC means, “interpret as command.” It is a way to send commands over the network such as send break or start echoing .
Login Connect Menu	Select the interface to display when the user logs in. Choices are: <ul style="list-style-type: none"> ◆ Enabled = shows the Login Connect Menu. ◆ Disabled = shows the CLI
Exit Connect Menu	Select whether to display a choice for the user to exit the Login Connect Menu and reach the CLI. Choices are: <ul style="list-style-type: none"> ◆ Enabled = a choice allows the user to exit to the CLI. ◆ Disabled = there is no exit to the CLI.
Send Break	Enter a Send Break control character, e.g., <control> Y, or blank to disable. When the Send Break control character is received from the network on its way to the serial line, it is not sent to the line; instead, the line output is forced to be inactive (the break condition).
Break Duration	Enter how long the break should last in milliseconds.
Echo	Applies only to Connect Mode Telnet connections, not to Accept Mode. Only disable Echo if your terminal echoes, in which case you will see double of each character typed.


3. Click **Submit** to save changes.

Network Terminal Configuration

To configure menu features applicable to CLI access via the network:

1. Click **Terminal > Network** at the top of the page. Configuration is automatically selected. The Terminal on Network Configuration page appears.

Figure 9-3 Terminal on Network Configuration



Terminal on Network - Configuration	
Terminal Type:	UNKNOWN
Login Connect Menu:	<input type="radio"/> Enabled <input checked="" type="radio"/> Disabled
Exit Connect Menu:	<input type="radio"/> Enabled <input checked="" type="radio"/> Disabled
Echo:	<input checked="" type="radio"/> Enabled <input type="radio"/> Disabled

2. Enter or modify the following settings:

Table 9-4 Terminal on Network Configuration

Terminal on Network Configuration Settings	Description
Terminal Type	Enter text to describe the type of terminal. The text will be sent to a host via IAC. <i>Note:</i> IAC means, "interpret as command." It is a way to send commands over the network such as send break or start echoing .
Login Connect Menu	Select the interface to display when the user logs in. Choices are: Enabled = shows the Login Connect Menu. Disabled = shows the CLI
Exit Connect Menu	Select whether to display a choice for the user to exit the Login Connect Menu and reach the CLI. Choices are: Enabled = a choice allows the user to exit to the CLI. Disabled = there is no exit to the CLI.
Echo	Applies only to Connect Mode Telnet connections, not to Accept Mode. Only disable Echo if your terminal echoes, in which case you will see double of each character typed.

3. Click **Submit** to save changes.

Host Configuration

This Host web page is where you may view and modify current settings for a remote host.

To configure a remote host, perform the following steps.

1. Click **Host** on the menu and then click the desired host at the top of the web page. Configuration is automatically selected. (Host 1 is the default.) Host Configuration page appears.

Figure 9-5 Host Configuration

2. Enter or modify the following settings:

Table 9-6 Host Configuration

Host Settings	Description
Name	Enter a name for the host. This name appears on the Login Connect Menu. To leave a host out of the menu, leave this field blank.
Protocol	Select the protocol to use to connect to the host. Choices are: <ul style="list-style-type: none"> ◆ Telnet ◆ SSH <i>Note:</i> SSH keys must be loaded or created on the SSH page for the SSH protocol to work.
SSH Username	Appears if you selected SSH as the protocol. Enter a username to select a pre-configured Username/Password/Key (configured on the SSH: Client Users page), or leave it blank to be prompted for a username and password at connect time.
Remote Address	Enter an IP address for the host to which the device will connect.
Remote Port	Enter the port on the host to which the device will connect.

3. Click **Submit** to save changes.

10: Service Settings

This chapter describes the available services and how to configure each. It contains the following sections:

- ◆ [DNS Settings](#)
- ◆ [PPP Settings](#)
- ◆ [SNMP Settings](#)
- ◆ [FTP Settings](#)
- ◆ [TFTP Settings](#)
- ◆ [Syslog Settings](#)
- ◆ [HTTP Settings](#)
- ◆ [RSS Settings](#)
- ◆ [LPD Settings](#)

DNS Settings

The primary and secondary domain name system (DNS) addresses come from the active interface. The static addresses from the Network Interface Configuration page may be overridden by DHCP or BOOTP. The DNS web page enables you to view the status and cache.

When a DNS name is resolved using a forward lookup, the results are stored in the DNS cache temporarily. The EDS1100/2100 checks this cache when performing forward lookups. Each item in the cache eventually times out and is removed automatically after a certain period, or you can delete it manually.

To view the DNS status:

1. Click **DNS** on the menu bar. The DNS page appears.

Figure 10-1 DNS Settings

DNS

Current Status	
Domain:	eng.lantronix.com
Primary DNS:	172.19.1.1 (DHCP)
Secondary DNS:	172.19.1.2 (DHCP)

Cache Entries

There are no entries in the cache.

[\[Remove All\]](#)

To find a DNS Name or IP Address:

1. Enter either a DNS name or an IP address.
2. Click **Lookup**.
 - ◆ When a DNS name is resolved, the results appear in the DNS cache.
 - ◆ When an IP address is resolved, the results appear in a text below the Lookup field.

To clear cache entries:

1. Click **Remove All** to remove all listed cache entries.
2. Click **Delete** next to a specific cache entry to remove only that one.

PPP Settings

Point-to-Point Protocol (PPP) establishes a direct connection between two nodes. It defines a method for data link connectivity between devices using physical layers (such as serial lines).

The EDS1100/2100 supports two types of PPP authentication: Password Authentication Protocol (PAP) and Challenge Handshake Authentication Protocol (CHAP). Both of these authentication methods require the configuration of a username and password.

PAP authentication offers a straightforward method for the peer to determine its identity. Upon the link establishment, the user ID and password are repeatedly sent to the authenticator until it is acknowledged or the connection is terminated. However, PAP is not a strong authentication process. There is no protection against trial-and-error attacks. The peer is responsible for the frequency of the authentication communication attempts.

CHAP is a more secure method than PAP. It works by sending a challenge message to the connection requestor. Using a one-way hash function, the requestor responds with its value. If the value matches the server's own calculations, authentication is provided. Otherwise, the connection is terminated.

Note: *RFC1334 defines both CHAP and PAP.*

The EDS1100/2100 also supports authentication scheme of "None" when no authentication is required during link negotiation.

Since the EDS1100/2100 does not support Network Address and Port Translation (NAPT), static routing table entries must be added to the serial-side and network-side devices (both of which are external devices).

Use the EDS1100/2100 Web Manager or CLI to configure a network link using PPP over a serial line. Turn off Connect Mode, Accept Mode, and Command mode before enabling PPP. The EDS1100/2100 device acts as the server side of the PPP link; it can require authentication and assign an IP address to the peer. Upon PPP configuration, IP packets are routed between Ethernet and PPP interfaces.


The EDS1100/2100 does not perform network address translation (NAT) between the serial-side network interface and the Ethernet/WLAN network interface. Therefore, to pass packets through the EDS1100/2100, a static route must be configured on both the PPP Peer device and the remote device it wishes to communicate with. The static route in the PPP Peer device must use the PPP Local IP Address as its gateway, and the static route in the remote device must use the network interface IP Address of the EDS1100/2100 as its gateway.

Note: The following section describes the steps to configure PPP 1 (PPP on serial line 1); these steps also apply to any line instance of the device.

To configure PPP:

1. Click **PPP** on the menu bar and **Line1** at the top of the page. The PPP on Line 1 – Configuration page appears.

Figure 10-2 PPP Configuration Settings



The screenshot shows the 'PPP on Line 1 - Configuration' page. At the top, there are tabs for 'Line 1' and 'Configuration'. Below the title, a yellow warning box states: 'WARNING: Serial protocol is not PPP.' The configuration fields are as follows:

Local IP Address:	<None>
Peer IP Address:	<None>
Authentication Mode:	<input type="radio"/> None <input checked="" type="radio"/> PAP <input type="radio"/> CHAP <input type="radio"/> MS-CHAP <input type="radio"/> MS-CHAPV2
Username:	
Password:	<None>

2. Enter or modify the following settings:

Table 10-3 PPP Configuration

PPP Configuration Settings	Description
Local IP Address	Enter the IP address assigned to the device's PPP interface.
Peer IP Address	Enter the IP address assigned to the peer (when requested during negotiation).
Authentication Mode	Choose the authentication mode: <ul style="list-style-type: none"> ◆ None = no authentication is required ◆ PAP = Password Authentication Protocol ◆ CHAP = Challenge Handshake Authentication Protocol ◆ MS-CHAP = Microsoft Challenge-Handshake Authentication Protocol ◆ MS-CHAPV2 = Microsoft Challenge-Handshake Authentication Protocol Version 2
Username	Enter a username if authentication is to be used on the PPP interface. The peer must be configured to use the same username.
Password	Enter a password if authentication is to be used on the PPP interface. The peer must be configured to use the same password.

3. Click **Submit**.

SNMP Settings

Simple Network Management Protocol (SNMP) is a network management tool that monitors network devices for conditions that need attention. The SNMP service responds to SNMP requests and generates SNMP Traps.

This page is used to configure the SNMP agent.

To configure SNMP:

1. Click **SNMP** on the menu bar. The SNMP page opens and shows the current SNMP configuration.

Figure 10-4 SNMP Configuration

SNMP	
State:	<input checked="" type="radio"/> Enabled <input type="radio"/> Disabled
Read Community:	<Configured>
Write Community:	<Configured>
System Contact:	
System Name:	xport_pro
System Description:	<Default> Lantronix XPort Pro V5.2.0.0R12 (07092877T7DGFL)
System Location:	
Traps State:	<input checked="" type="radio"/> Enabled <input type="radio"/> Disabled
Traps Primary Destination:	
Traps Secondary Destination:	

2. Enter or modify the following settings:

Table 10-5 SNMP

SNMP Settings	Description
State	Select Enabled to enable SNMP.
Read Community	Enter the SNMP read-only community string.
Write Community	Enter the SNMP read/write community string.
System Contact	Enter the name of the system contact.
System Name	Enter the system name.
System Description	Enter the system description.
System Location	Enter the system location.
Traps State	Select Enabled to enable the transmission of SNMP Traps. The Cold Start trap is sent on device boot up, and the Linkdown trap is sent when the device is rebooted from software control.
Traps Primary Destination	Enter the primary SNMP trap host.

SNMP Settings (continued)	Description
Traps Secondary Destination	Enter the secondary SNMP trap host.

- Click **Submit**.

FTP Settings

The FTP web page shows the current File Transfer Protocol (FTP) configuration and various statistics about the FTP server.

To configure FTP:

- Click **FTP** on the menu bar. The FTP page opens to display the current configuration.

Figure 10-6 FTP Configuration

FTP

Configuration	
State:	<input checked="" type="radio"/> Enabled <input type="radio"/> Disabled
Admin Username:	<input type="text" value="admin"/>
Admin Password:	<input type="text" value="<Configured>"/>

Statistics	
Status:	Running
Connections Rejected:	0
Connections Accepted:	0
Active Connections:	0
Last Client:	No device has connected

- Enter or modify the following settings:

FTP Settings	Description
State	Select Enabled to enable the FTP server.
Admin Username	Enter the username to use when logging in via FTP.
Admin Password	Enter the password to use when logging in via FTP.

- Click **Submit**.

TFTP Settings

In the TFTP web page, you can configure the server and view the statistics about the Trivial File Transfer Protocol (TFTP) server.

To configure TFTP:

1. Click **TFTP** on the menu bar. The TFTP page opens to display the current configuration.

Figure 10-7 TFTP Configuration

TFTP Server

Configuration	
State:	<input checked="" type="radio"/> Enabled <input type="radio"/> Disabled
Allow File Creation:	<input type="radio"/> Enabled <input checked="" type="radio"/> Disabled
Allow Firmware Update:	<input type="radio"/> Enabled <input checked="" type="radio"/> Disabled
Allow XCR Import:	<input type="radio"/> Enabled <input checked="" type="radio"/> Disabled

Statistics	
Status:	Running
Files Downloaded:	0
Files Uploaded:	0
File Not Found Errors:	0
File Read Errors:	0
File Write Errors:	0
Unknown Errors:	0
Last Client:	No device has connected

2. Enter or modify the following settings:

Table 10-8 TFTP Server

TFTP Settings	Description
State	Select Enabled to enable the TFTP server.
Allow TFTP File Creation	Select whether to allow the creation of new files stored on the TFTP server.
Allow Firmware Update	Specifies whether or not the TFTP Server is allowed to accept a firmware update for the device. An attempt to update firmware is recognized based on the name of the file. Note: TFTP cannot authenticate the client, so the device is open to malicious update.
Allow XCR Import	Specifies whether the TFTP server is allowed to accept an XML configuration file for update. An attempt to import configuration is recognized based on the name of the file. Note: TFTP cannot authenticate the client, so the device is open to malicious update.

3. Click **Submit**.

Syslog Settings

The Syslog web page shows the current configuration and statistics of the system log.

To configure the Syslog

Note: The syslog file is always saved to local storage, but it is not retained through reboots. Saving the syslog file to a server that supports remote logging services (see RFC 3164) allows the administrator to save the complete syslog history. The default port is 514.

1. Click **Syslog** on the menu bar. The Syslog page opens to display the current configuration.

Figure 10-9 Syslog

The screenshot shows the Syslog configuration page. It has a title 'Syslog' and two main sections: 'Configuration' and 'Statistics'.

Configuration

State:	<input checked="" type="radio"/> Enabled <input type="radio"/> Disabled
Host:	172.19.39.23
Local Port:	514
Remote Port:	514
Severity Log Level:	Debug

Statistics

Status:	Running
Messages Sent:	484
Messages Failed:	0

2. Enter or modify the following settings:

Table 10-10 Syslog

Syslog Settings	Description
State	Select to enable or disable the syslog.
Host	Enter the IP address of the remote server to which system logs are sent for storage.
Local Port	Enter the number of the local port on the device from which system logs are sent.
Remote Port	Enter the number of the port on the remote server that supports logging services. The default is 514 .
Severity Log Level	From the drop-down box, select the minimum level of system message the device should log. This setting applies to all syslog facilities. The drop-down list is in descending order of severity (e.g., Emergency is more severe than Alert .)

3. Click **Submit**.

HTTP Settings

Hypertext Transfer Protocol (HTTP) is the transport protocol for communicating hypertext documents on the Internet. HTTP defines how messages are formatted and transmitted. It also defines the actions web servers and browsers should take in response to different commands. HTTP Authentication enables the requirement of usernames and passwords for access to the EDS1100/2100 device.

This page has three links at the top for viewing statistics and for viewing and changing configuration and authentication settings.

- ◆ [HTTP Statistics](#)—Viewing statistics such as bytes received and transmitted, bad requests, authorizations required, etc.
- ◆ [HTTP Configuration](#)—Configuring and viewing the current configuration.
- ◆ [HTTP Authentication](#)—Configuring and viewing the authentication.

HTTP Statistics

To view HTTP statistics:

This page shows various statistics about the HTTP server.

1. Click **HTTP** on the menu bar and then **Statistics** at the top of the page. The HTTP Statistics page appears.

Figure 10-11 HTTP Statistics

<div> Statistics Configuration Authentication </div>	
HTTP Statistics	
Rx Bytes	26295
Tx Bytes	198244
200 - OK	15
301 - Moved Permanently	0
400 - Bad Request	0
401 - Authorization Required	13
404 - Not Found	0
408 - Request Timeout	0
413 - Request Too Large	0
500 - Internal Error	0
501 - Not Implemented	0
Status Unknown	0
Work Queue Full	0
Socket Error	0
Memory Error	0
Logs:	42 entries (6291 bytes) [View] [Clear]

Note: The HTTP log is a scrolling log, with the last Max Log Entries cached and viewable. You can change the maximum number of entries that can be viewed on the HTTP Configuration Page.

HTTP Configuration

On this page you may change HTTP configuration settings.

To configure HTTP:

1. Click **HTTP** on the menu bar and then **Configuration** at the top of the page. The HTTP Configuration page opens.

Figure 10-12 HTTP Configuration

Statistics Configuration Authentication	
HTTP Configuration	
State:	<input checked="" type="radio"/> Enabled <input type="radio"/> Disabled
Port:	<input type="text" value="80"/>
Secure Port:	<input type="text" value="443"/>
Secure Protocols:	<input checked="" type="checkbox"/> SSL3 <input checked="" type="checkbox"/> TLS1.0 <input checked="" type="checkbox"/> TLS1.1
Max Timeout:	<input type="text" value="10"/> seconds
Max Bytes:	<input type="text" value="40960"/>
Logging State:	<input checked="" type="radio"/> Enabled <input type="radio"/> Disabled
Max Log Entries:	<input type="text" value="50"/>
Log Format:	<input %b="" %r\"="" %s="" \"%{referer}i\"="" \"%{user-agent}i\""="" type="text" value="%h %t \"/>
Authentication Timeout:	<input type="text" value="30"/> minutes

2. Enter or modify the following settings:

Table 10-13 HTTP Configuration

HTTP Configuration Settings	Description
State	Select Enabled to enable the HTTP server.
Port	Enter the port for the HTTP server to use. The default is 80 .
Secure Port	Enter the port for the HTTPS server to use. The default is 443 . The HTTP server only listens on the HTTPS Port when an SSL certificate is configured.

HTTP Configuration Settings (continued)	Description
Secure Protocols	<p>Select to enable or disable the following protocols:</p> <ul style="list-style-type: none"> ◆ SSL3 = Secure Sockets Layer version 3 ◆ TLS1.0 = Transport Layer Security version 1.0. TLS 1.0 is the successor of SSL3 as defined by the IETF. ◆ TLS1.1 = Transport Layer Security version 1.1 <p>The protocols are enabled by default.</p> <p>Note: A server certificate and associated private key need to be installed in the SSL configuration section to use HTTPS.</p>
Max Timeout	Enter the maximum time for the HTTP server to wait when receiving a request. This prevents Denial-of-Service (DoS) attacks. The default is 10 seconds.
Max Bytes	Enter the maximum number of bytes the HTTP server accepts when receiving a request. The default is 40 kB (this prevents DoS attacks).
Logging State	Select Enabled to enable HTTP server logging.
Max Log Entries	Sets the maximum number of HTTP server log entries. Only the last Max Log Entries are cached and viewable.
Log Format	<p>Set the log format string for the HTTP server. Follow these Log Format rules:</p> <ul style="list-style-type: none"> ◆ %a - remote IP address (could be a proxy) ◆ %b - bytes sent excluding headers ◆ %B - bytes sent excluding headers (0 = '-') ◆ %h - remote host (same as '%a') ◆ %{h}i - header contents from request (h = header string) ◆ %m - request method ◆ %p - ephemeral local port value used for request ◆ %q - query string (prepend with '?' or empty '-') ◆ %t - timestamp HH:MM:SS (same as Apache '%(%H:%M:%S)t' or '%(%T)t') ◆ %u - remote user (could be bogus for 401 status) ◆ %U - URL path info ◆ %r - first line of request (same as '%m %U%q <version>') ◆ %s - return status
Authentication Timeout	The timeout period applies if the selected authentication type is either Digest or SSL/Digest . After this period of inactivity, the client must authenticate again.

3. Click **Submit**.

HTTP Authentication

HTTP Authentication enables you to require usernames and passwords to access specific web pages or directories on the EDS1100/2100's built-in web server.

To configure HTTP authentication settings:

1. Click **HTTP** on the menu bar and then **Authentication** at the top of the page. The HTTP Authentication page opens.

Figure 10-14 HTTP Authentication

Current Configuration	
URI:	/ [Delete]
Realm:	config
AuthType:	Digest
Users:	admin [Delete]

2. Enter or modify the following settings:

Table 10-15 HTTP Authentication

HTTP Authentication Settings	Description
URI	Enter the Uniform Resource Identifier (URI). Note: The URI must begin with '/' to refer to the filesystem.
Realm	Enter the domain, or realm, used for HTTP. Required with the URI field.

HTTP Authentication Settings (continued)	Description
Auth Type	<p>Select the authentication type:</p> <ul style="list-style-type: none"> ◆ None = no authentication is necessary. ◆ Basic = encodes passwords using Base64. ◆ Digest = encodes passwords using MD5. ◆ SSL = the page can only be accessed over SSL (no password is required). ◆ SSL/Basic = the page is accessible only over SSL and encodes passwords using Base64. ◆ SSL/Digest = the page is accessible only over SSL and encodes passwords using MD5. <p><i>Note: When changing the parameters of Digest or SSL Digest authentication, it is often best to close and reopen the browser to ensure it does not attempt to use cached authentication information.</i></p>
Username	<p>Enter the Username used to access the URI. More than one Username per URI is permitted.</p> <p>Click Submit and enter the next Username as necessary.</p>
Password	Enter the Password for the Username .

3. Click **Submit**.
4. To delete the URI and users, click **Delete** in the current configuration table.

***Note:** The URI, realm, username, and password are user-specified, free-form fields. The URI must match the directory created on the EDS1100/2100 file system.*

RSS Settings

Really Simple Syndication (RSS) (sometimes referred to as Rich Site Summary) is a method of feeding online content to Web users. Instead of actively searching for EDS1100/2100 configuration changes, RSS feeds permit viewing only relevant and new information regarding changes made to the EDS1100/2100 via an RSS publisher. The RSS feeds may also be stored to the file system cfg_log.txt file.

To configure RSS settings:

1. Click **RSS** on the menu bar. The RSS page opens and shows the current RSS configuration.

Figure 10-16 RSS

RSS

Configuration	
RSS Feed:	<input type="radio"/> On <input checked="" type="radio"/> Off
Persistent:	<input type="radio"/> On <input checked="" type="radio"/> Off
Max Entries:	<input type="text" value="100"/>

Statistics	
Data:	0 entries (0 bytes) View Clear

- Enter or modify the following settings:

Table 10-17 RSS

RSS Settings	Description
RSS Feed	Select On to enable RSS feeds to an RSS publisher.
Persistent	Select On to enable the RSS feed to be written to a file (cfg_log.txt) and to be available across reboots.
Max Entries	Sets the maximum number of log entries. Only the last Max Entries are cached and viewable.

- Click **Submit**.
- In the **Current Status** table, view and clear stored RSS Feed entries, as necessary.

LPD Settings

The EDS1100/2100 device acts as a print server if a printer gets connected to one of its serial ports. Clicking the Line Printer Daemon (LPD) link in the Main Menu displays the LPD web page. The LPD web page has three sub-menus for viewing print queue statistics, changing print queue configuration, and printing a test page. Because the LPD lines operate independently, you can specify different configuration settings for each.

LPD Statistics

This read-only page shows various statistics about the LPD server.

To view LPD statistics:

- Click **LPD** on the menu bar and then select the line and **Statistics** at the top of the page. The LPD page shows LPD statistics.

Figure 10-18 LPD Statistics

LPD 1	
Statistics	Configuration Print Test Page
LPD 1 - Statistics	
Jobs Printed:	0
Bytes Printed:	0
Current Client:	No device is connected.
Last Client:	No device has connected.

LPD Configuration

Here you can change LPD configuration settings.

To configure LPD settings:

1. Click **LPD** on the menu bar, select the LPD line and click **Configuration**. The LPD Configuration page appears.

Figure 10-19 LPD Configuration

LPD 1	
Statistics	Configuration Print Test Page
LPD 1 - Configuration	
WARNING: Serial protocol is not "LPD".	
Banner:	<input checked="" type="radio"/> Enabled <input type="radio"/> Disabled
Binary:	<input type="radio"/> Enabled <input checked="" type="radio"/> Disabled
Start of Job:	<input type="radio"/> Enabled <input checked="" type="radio"/> Disabled
End of Job:	<input type="radio"/> Enabled <input checked="" type="radio"/> Disabled
Formfeed:	<input type="radio"/> Enabled <input checked="" type="radio"/> Disabled
Convert Newlines:	<input type="radio"/> Enabled <input checked="" type="radio"/> Disabled
SOJ String:	<input type="text"/> <input checked="" type="radio"/> Text <input type="radio"/> Binary
EOJ String:	<input type="text"/> <input checked="" type="radio"/> Text <input type="radio"/> Binary
Queue Name:	<input type="text"/>

2. Enter or modify the following settings:

Table 10-20 LPD Configuration

LPD Configuration Settings	Description
Banner	Select Enabled to print the banner even if the print job does not specify to do so. Selected by default.
Binary	Select Enabled for the device to pass the entire file to the printer unchanged. Otherwise, the device passes only valid ASCII and valid control characters to the printer. Valid control characters include the tab, linefeed, formfeed, backspace, and newline characters. All others are stripped. Disabled by default.
Start of Job	Select Enabled to print a "start of job" string before sending the print data.
End of Job	Select Enabled to send an "end of job" string.
Formfeed	Select Enabled to force the printer to advance to the next page at the end of each print job.
Convert Newlines	Select Enabled to convert single newlines and carriage returns to DOS-style line endings.
SOJ String	If Start of Job (above) is enabled, enter the string to be sent to the printer at the beginning of a print job. The limit is 100 characters. Indicate whether the string is in text or binary format.
EOJ String	If End of Job (above) is enabled, enter the string to send at the end of a print job. The limit is 100 characters. Indicate whether the string is in text or binary format.
Queue Name	To change the name of the print queue, enter a new name. The name cannot have white space in it and is limited to 31 characters. The default is LPDQueueX (for line number X)

3. Click **Submit**.

11: Security Settings

The EDS1100/2100 device supports Secure Shell (SSH) and Secure Sockets Layer (SSL). SSH is a network protocol for securely accessing a remote device. SSH provides a secure, encrypted communication channel between two hosts over a network. It provides authentication and message integrity services.

Secure Sockets Layer (SSL) is a protocol that manages data transmission security over the Internet. It uses digital certificates for authentication and cryptography against eavesdropping and tampering. It provides encryption and message integrity services. SSL is widely used for secure communication to a web server. SSL uses certificates and private keys.

Note: *The EDS1100/2100 supports SSLv3 and its successors, TLS1.0 and TLS1.1. An incoming SSLv2 connection attempt is answered with an SSLv3 response. If the initiator also supports SSLv3, SSLv3 handles the rest of the connection.*

This chapter contains the following sections:

- ◆ [SSH Server Host Keys](#)
- ◆ [SSH Server Authorized Users](#)
- ◆ [SSH Client Known Hosts](#)
- ◆ [SSH Client User](#)
- ◆ [SSL Cipher Suites](#)
- ◆ [SSL Certificates](#)
- ◆ [SSL RSA or DSA](#)
- ◆ [SSL Certificates and Private Keys](#)
- ◆ [SSL Utilities](#)
- ◆ [SSL Configuration](#)

SSH Settings

SSH is a network protocol for securely accessing a remote device over an encrypted channel. This protocol manages the security of internet data transmission between two hosts over a network by providing encryption, authentication, and message integrity services.

Two instances require configuration: when the EDS1100/2100 is the SSH server and when it is an SSH client. The SSH server is used by the CLI (Command Mode) and for tunneling in Accept Mode. The SSH client is for tunneling in Connect Mode.

To configure the EDS1100/2100 as an SSH server, there are two requirements:

- ◆ **Defined host keys:** both private and public keys are required. These keys are used for the Diffie-Hellman key exchange (used for the underlying encryption protocol).
- ◆ **Defined users:** these users are permitted to connect to the EDS1100/2100 SSH server.

This page has four links at the top for viewing and changing SSH server host keys, SSH server authorized keys, SSH client known hosts, and SSH client users.

SSH Server Host Keys

To configure the SSH server host keys:

1. Click **SSH** on the menu bar and **SSH Server: Host Keys** at the top of the page. The SSH Server Host Keys page appears.

Figure 11-1 SSH Server: Host Keys

SSH Server: Host Keys SSH Client: Known Hosts
SSH Server: Authorized Users SSH Client: Users

SSH Server: Host Keys

Upload Keys

Private Key:

Public Key:

Key Type: ☒ RSA ☐ DSA

Create New Keys

Key Type: ☒ RSA ☐ DSA

Bit Size: ☒ 512 ☐ 768 ☐ 1024

Current Configuration

Public RSA Key:	No RSA Key Configured
Public DSA Key:	No DSA Key Configured

2. Enter or modify the following settings:

Table 11-2 SSH Server Host Keys Settings

SSH Server: Host Keys Settings	Description
Upload Keys	
Private Key	Enter the path and name of the existing private key you want to upload or use the Browse button to select the key. Be sure the private key will not be compromised in transit. This implies the data is uploaded over some kind of secure private network.
Public Key	Enter the path and name of the existing public key you want to upload or use the Browse button to select the key.
Key Type	<p>Select a key type to use:</p> <ul style="list-style-type: none"> ◆ RSA = use this key with SSH1 and SSH2 protocols. ◆ DSA = use this key with the SSH2 protocol. <p>Note: RSA is more secure.</p>

SSH Server: Host Keys Settings (continued)	Description
Create New Keys	
Key Type	Select a key type to use for the new key: <ul style="list-style-type: none"> ◆ RSA = use this key with the SSH1 and SSH2 protocols. ◆ DSA = use this key with the SSH2 protocol.
Bit Size	Select a bit length for the new key: <ul style="list-style-type: none"> ◆ 512 ◆ 768 ◆ 1024 Using a larger bit size takes more time to generate the key. Approximate times are: <ul style="list-style-type: none"> ◆ 10 seconds for a 512 bit RSA Key ◆ 15 seconds for a 768 bit RSA Key ◆ 1 minute for a 1024 bit RSA Key ◆ 30 seconds for a 512 bit DSA Key ◆ 1 minute for a 768 bit DSA Key ◆ 2 minutes for a 1024 bit DSA Key <p>Note: Some SSH clients require RSA host keys to be at least 1024 bits long. This device generates keys up to 1024 bits long. It can work with larger keys (up to 2048 bit) if they are imported or otherwise created.</p>

3. Click **Submit**.

Note: SSH keys may be created on another computer and uploaded to the EDS1100/2100. For example, use the following command using Open SSH to create a 1024-bit DSA key pair: `ssh-keygen -b 1024 -t dsa`

SSH Keys from other programs may be converted to the required EDS1100/2100 format. Use Open SSH to perform the conversion.

To convert from RFC-4716 format: `ssh-keygen -i`

For more options, look at the help from Open SSH: `ssh-keygen ?`

1. If the keys do not exist, select the **Key Type** and the key's **Bit Size** from the **Create New Keys** section. Click **Submit** to create new private and public host keys.

Note: Generating new keys with a large bit size results in longer key generation times.

2. Click **SSH >SSH Server: Authorized Users** at the top of the page. The SSH Server: Authorized Users page appears.
3. Enter the **Username** and **Password** for authorized users.
4. If available: locate the **Public RSA Key** or the **Public DSA Key** file by clicking **Browse**. Configuring a public key results in public key authentication; this bypasses password queries.

Note: When uploading the security keys, ensure the keys are not compromised in transit.

SSH Server Authorized Users

On this page you can change SSH server settings for Authorized Users. SSH Server Authorized Users are accounts on the EDS1100/2100 that can be used to log into the EDS1100/2100 using

SSH. For instance, these accounts can be used to SSH into the CLI or open an SSH connection to a device port. Every account must have a password.


The user's public keys are optional and only necessary if public key authentication is required. Using public key authentication allows a connection to be made without the password being asked.

Under **Current Configuration**, **User** has a **Delete User** link, and **Public RSA Key** and **Public DSA Key** have **View Key** and **Delete Key** links. If you click a **Delete** link, a message asks whether you are sure you want to delete this information. Click **OK** to proceed or **Cancel** to cancel the operation.

To configure the SSH server for authorized users:

1. Click **SSH** on the menu bar and then **Server Authorized Users** at the top of the page. The SSH Server: Authorized Users page appears.

Figure 11-3 SSH Server: Authorized Users



SSH Server: Host Keys SSH Client: Known Hosts
SSH Server: Authorized Users SSH Client: Users

SSH Server: Authorized Users

Username:

Password:

Public RSA Key:

Public DSA Key:

Current Configuration

No Authorized Users are currently configured for the SSH Server.

2. Enter or modify the following settings:

Table 11-4 SSH Server Authorized User Settings

SSH Server: Authorized Users Settings	Description
Username	Enter the name of the user authorized to access the SSH server.
Password	Enter the password associated with the username.
Public RSA Key	Enter the path and name of the existing public RSA key you want to use with this user or use the Browse button to select the key. If authentication is successful with the key, no password is required.
Public DSA Key	Enter the path and name of the existing public DSA key you want to use with this user or use the Browse button to select the key. If authentication is successful with the key, no password is required.

3. Click **Submit**.

SSH Client Known Hosts


On this page you can change SSH client settings for known hosts.

Note: You do not have to complete the fields on this page for communication to occur. However, completing them adds another layer of security that protects against Man-In-The-Middle (MITM) attacks.

To configure the SSH client for known hosts:

1. Click **SSH** on the menu bar and then **Client Known Hosts** at the top of the page. The SSH Client: Known Hosts page appears.

Figure 11-5 SSH Client: Known Hosts



SSH Server: Host Keys SSH Client: Known Hosts
SSH Server: Authorized Users SSH Client: Users

SSH Client: Known Hosts

Server:

Public RSA Key: Browse...

Public DSA Key: Browse...

Current Configuration

No Known Hosts are currently configured for the SSH Client.

2. Enter or modify the following settings:

Table 11-6 SSH Client Known Hosts

SSH Client: Known Hosts Settings	Description
Server	Enter the name or IP address of a known host. If you enter a server name, the name should match the name of the server used as the Remote Address in Connect mode tunneling.
Public RSA Key	Enter the path and name of the existing public RSA key you want to use with this known host or use the Browse button to select the key.
Public DSA Key	Enter the path and name of the existing public DSA key you want to use with this known host or use the Browse button to select the key.

Note: These settings are not required for communication. They protect against Man-In-The-Middle (MITM) attacks.

3. Click **Submit**.
4. In the **Current Configuration** table, delete currently stored settings as necessary.

SSH Client User

On this page you can change SSH client settings for users. To configure the EDS1100/2100 as an SSH client, an SSH client user must be both configured and also exist on the remote SSH server.

SSH client known users are used by all applications that play the role of an SSH client, specifically tunneling in Connect Mode. At the very least, a password or key pair must be configured for a user. The keys for public key authentication can be created elsewhere and uploaded to the device or automatically generated on the device. If uploading existing keys, be sure the private key will not be compromised in transit. This implies the data is uploaded over some kind of secure private network.

Note: If you are providing a key by uploading a file, make sure that the key is not password protected.

To configure the SSH client users:

1. Click **SSH** on the menu bar and then **SSH Client Users** at the top of the page. The SSH Client: Users page appears.

Figure 11-7 SSH Client: Users

SSH Server: Host Keys SSH Client: Known Hosts
SSH Server: Authorized Users **SSH Client: Users**

SSH Client: Users

Username:
 Password:
 Remote Command:
 Private Key:
 Public Key:
 Key Type: ☐ RSA ☐ DSA

Create New Keys

Username:
 Key Type: ☐ RSA ☐ DSA
 Bit Size: ☐ 512 ☐ 768 ☐ 1024

Current Configuration

No Users are currently configured for the SSH Client.

2. Enter or modify the following settings:

Table 11-8 SSH Client Users

SSH Client: Users Settings	Description
Username	Enter the name that the device uses to connect to a SSH server.
Password	Enter the password associated with the username.
Remote Command	Enter the command that can be executed remotely. Default is shell , which tells the SSH server to execute a remote shell upon connection. This command can be changed to anything the remote host can perform.
Private Key	Enter the name of the existing private key you want to use with this SSH client user. You can either enter the path and name of the key, or use the Browse button to select the key.
Public Key	<p>Enter the path and name of the existing public key you want to use with this SSH client user or use the Browse button to select the key.</p> <p>Note: If the user public key is known on the remote SSH server, the SSH server does not require a password. The Remote Command is provided to the SSH server upon connection. It specifies the application to execute upon connection. The default is a command shell.</p> <p>Note: Configuring the SSH client's known hosts is optional. It prevents Man-In-The-Middle (MITM) attacks</p>
Key Type	<p>Select the key type to be used. Choices are:</p> <ul style="list-style-type: none"> ◆ RSA = use this key with the SSH1 and SSH2 protocols. ◆ DSA = use this key with the SSH2 protocol.
Create New Keys	
Username	Enter the name of the user associated with the new key.
Key Type	<p>Select the key type to be used for the new key. Choices are:</p> <ul style="list-style-type: none"> ◆ RSA = use this key with the SSH1 and SSH2 protocols. ◆ DSA = use this key with the SSH2 protocol.
Bit Size	<p>Select the bit length of the new key:</p> <ul style="list-style-type: none"> ◆ 512 ◆ 768 ◆ 1024 <p>Using a larger Bit Size takes more time to generate the key. Approximate times are:</p> <ul style="list-style-type: none"> ◆ 10 seconds for a 512 bit RSA Key ◆ 15 seconds for a 768 bit RSA Key ◆ 1 minute for a 1024 bit RSA key ◆ 30 seconds for a 512 bit DSA key ◆ 1 minute for a 768 bit DSA key ◆ 2 minutes for a 1024 bit DSA key <p>Note: Some SSH clients require RSA host keys to be at least 1024 bits long. This device generates keys up to 1024 bits long. It can work with larger keys (up to 2048 bit) if they are imported or otherwise created.</p>

3. Click **Submit**.
4. In the **Current Configuration** table, delete currently stored settings as necessary.

SSL Settings

Secure Sockets Layer (SSL) is a protocol for managing the security of data transmission over the Internet. It provides encryption, authentication, and message integrity services. SSL is widely used for secure communication to a web server.

Certificate/Private key combinations can be obtained from an external Certificate Authority (CA) and downloaded into the unit. Self-signed certificates with associated private key can be generated by the device server itself.

For more information regarding Certificates and how to obtain them, see [SSL Certificates and Private Keys \(on page 92\)](#).

SSL uses digital certificates for authentication and cryptography against eavesdropping and tampering. Sometimes only the server is authenticated, sometimes both server and client. The EDS1100/2100 can be server and/or client, depending on the application. Public key encryption systems exchange information and keys and set up the encrypted tunnel.

Efficient symmetric encryption methods encrypt the data going through the tunnel after it is established. Hashing provides tamper detection.

Applications that can make use of SSL are Tunneling, Secure Web Server, and WLAN interface.

The EDS1100/2100 supports SSLv3 and its successors, TLS1.0 and TLS1.1.

Note: An incoming SSLv2 connection attempt is answered with an SSLv3 response. If the initiator also supports SSLv3, SSLv3 handles the rest of the connection.

SSL Cipher Suites

The SSL standard defines only certain combinations of certificate type, key exchange method, symmetric encryption, and hash method. Such a combination is called a cipher suite. Supported cipher suites include the following:

Table 11-9 Supported Cipher Suites

Certificate	Key Exchange	Encryption	Hash
DSA	DHE	3DES	SHA1
RSA	RSA	128 bits AES	SHA1
RSA	RSA	Triple DES	SHA1
RSA	RSA	128 bits RC4	MD5
RSA	RSA	128 bits RC4	SHA1
RSA	1024 bits RSA	56 bits RC4	MD5
RSA	1024 bits RSA	56 bits RC4	SHA1
RSA	1024 bits RSA	40 bits RC4	MD5

Whichever side is acting as server decides which cipher suite to use for a connection. It is usually the strongest common denominator of the cipher suite lists supported by both sides.

SSL Certificates

The goal of a certificate is to authenticate its sender. It is analogous to a paper document that contains personal identification information and is signed by an authority, for example a notary or government agency.

The principles of Security Certificate required that in order to sign other certificates, the authority uses a private key. The published authority certificate contains the matching public key that allows another to verify the signature but not recreate it.

The authority's certificate can be signed by itself, resulting in a self-signed or trusted-root certificate, or by another (higher) authority, resulting in an intermediate authority certificate. You can build up a chain of intermediate authority certificates, and the last certification will always be a trusted-root certificate.

An authority that signs another certificates is also called a Certificate Authority (CA). The last in line is then the root-CA. VeriSign is a famous example of such a root-CA. Its certificate is often built into web browsers to allow verifying the identity of website servers, which need to have certificates signed by VeriSign or another public CA. Since obtaining a certificate signed by a CA that is managed by another company can be expensive, it is possible to have your own CA. Tools exist to generate self-signed CA certificates or to sign other certificates.

A certificate request is a certificate that has not been signed and only contains the identifying information. Signing it makes it a certificate. A certificate is also used to sign any message transmitted to the peer to identify the originator and prevent tampering while transported.

When using HTTPS, SSL Tunneling in Accept mode, and/or EAP-TLS, the EDS1100/2100 needs a personal certificate with a matching private key to identify itself and sign its messages. When using SSL Tunneling in Connect mode and/or EAP-TLS, EAP-TTLS or PEAP, the EDS1100/2100 needs the authority certificate that can authenticate users with which it wishes to communicate.

SSL RSA or DSA

As mentioned above, the certificates contain a public key. Different key exchange methods require different public keys and thus different styles of certificate. The EDS1100/2100 supports key exchange methods that require a RSA-style certificate and key exchange methods that require a DSA-style certificate. If only one of these certificates is stored in the EDS1100/2100, only those key exchange methods that can work with that style certificate are enabled. RSA is sufficient in most cases.

SSL Certificates and Private Keys

You can obtain a certificate by completing a certificate request and sending it to a certificate authority that will create a certificate/key combo, usually for a fee. Or generate your own. A few utilities exist to generate self-signed certificates or sign certificate requests. The EDS1100/2100 also has the ability to generate its own self-signed certificate/key combo.

You can use XML to export the certificate in PEM format, but you cannot export the key. Hence the internal certificate generator can only be used for certificates that are to identify that particular EDS1100/2100.

Certificates and private keys can be stored in several file formats. Best known are PKCS12, DER and PEM. Certificate and key can be in the same file or in separate files. The key can be encrypted with a password or not. The EDS1100/2100 currently only accepts separate PEM files. The key needs to be unencrypted.

SSL Utilities

Several utilities exist to convert between the formats.

OpenSSL

Open source set of SSL related command line utilities. It can act as server or client. It can generate or sign certificate requests. It can convert all kinds of formats. Executables are available for Linux and Windows. To generate a self-signed RSA certificate/key combo use the following commands in the order shown:

```
openssl req -x509 -nodes -days 365 -newkey rsa:1024 -keyout
mp_key.pem -out mp_cert.pem
```

Note: *Signing other certificate requests is also possible with OpenSSL. See www.openssl.org or www.madboa.com/geek/openssl for more information.*

Steel Belted Radius

Commercial radius server by Juniper Networks that provides a GUI administration interface. It also provides a certificate request and self-signed certificate generator. The self-signed certificate has extension .sbrpvk and is in the PKCS12 format. OpenSSL can convert this into a PEM format certificate and key by using the following commands in the order shown:

```
openssl pkcs12 -in sbr_certkey.sbrpvk -nodes -out sbr_certkey.pem
```

The sbr_certkey.pem file contains both certificate and key. If loading the SBR certificate into EDS1100/2100 as an authority, you will need to edit it.

1. Open the file in any plain text editor.
2. Delete all info before the following: "----- BEGIN CERTIFICATE-----"
3. Delete all info after the following: "----- END CERTIFICATE-----"
4. Save as sbr_cert.pem. SBR accepts trusted-root certificates in the DER format.
5. Again, OpenSSL can convert any format into DER by using the following commands in the order shown:

```
openssl x509 -inform pem -in mp_cert.pem -outform der -out
mp_cert.der
```

Note: *With SBR, when the identity information includes special characters such as dashes and periods, SBR changes the format it uses to store these strings and becomes incompatible with the current EDS1100/2100 release. We will add support for this and other formats in future releases. Free Radius—Linux open-source Radius server. It is versatile, but complicated to configure.*

FreeRadius

Free Radius is a Linux open-source Radius server. It is versatile, but complicated to configure.

SSL Configuration

To configure SSL settings:

1. Click **SSL** from the main menu. The SSL page appears.

Figure 11-10 SSL

SSL

Upload Certificate

New Certificate:

New Private Key:

Upload Authority Certificate

Authority:

Create New Self-Signed Certificate

Country (2 Letter Code):

State/Province:

Locality (City):

Organization:

Organization Unit:

Common Name:

Expires: mm/dd/yyyy

Key length: ☒ 512 bit ☐ 768 bit ☐ 1024 bit

Type: ☐ RSA ☐ DSA

Current SSL Certificates

<None>

Current Certificate Authorities

<None>

2. Enter or modify the following settings:

Table 11-11 SSL

SSL Settings	Description
Upload Certificate	
New Certificate	<p>This certificate identifies the device to peers. It is used for HTTPS and SSL Tunneling.</p> <p>Enter the path and name of the certificate you want to upload, or use the Browse button to select the certificate.</p> <p>RSA or DSA certificates with 512 to 1024 bit public keys are allowed.</p> <p>The format of the file must be PEM. The file must start with "-----BEGIN CERTIFICATE-----" and end with "-----END CERTIFICATE-----". Some Certificate Authorities add comments before and/or after these lines. Those need to be deleted before upload.</p>
New Private Key	<p>Enter the path and name of the private key you want to upload, or use the Browse button to select the private key. The key needs to belong to the certificate entered above.</p> <p>The format of the file must be PEM. The file must start with "-----BEGIN RSA PRIVATE KEY-----" and end with "-----END RSA PRIVATE KEY-----". Read DSA instead of RSA in case of a DSA key. Some Certificate Authorities add comments before and/or after these lines. Those need to be deleted before upload.</p>
Upload Authority Certificate	
Authority	<p>One or more authority certificates are needed to verify a peer's identity. It is used for SSL Tunneling. These certificates do not require a private key.</p> <p>Enter the path and name of the certificate you want to upload, or use the Browse button to select the certificate.</p> <p>RSA or DSA certificates with 512 to 1024 bit public keys are allowed.</p> <p>The format of the file must be PEM. The file must start with "-----BEGIN CERTIFICATE-----" and end with "-----END CERTIFICATE-----". Some Certificate Authorities add comments before and/or after these lines. Those need to be deleted before upload.</p>
Create New Self-Signed Certificate	
Country (2 Letter Code)	<p>Enter the 2-letter country code to be assigned to the new self-signed certificate.</p> <p>Examples: US for United States and CA for Canada</p>
State/Province	Enter the state or province to be assigned to the new self-signed certificate.
Locality (City)	Enter the city or locality to be assigned to the new self-signed certificate.
Organization	<p>Enter the organization to be associated with the new self-signed certificate.</p> <p>Example: If your company is called Widgets, and you are setting up a web server for the Sales department, enter Widgets for the organization.</p>
Organization Unit	<p>Enter the organizational unit to be associated with the new self-signed certificate.</p> <p>Example: If your company is setting up a web server for the Sales department, enter Sales for your organizational unit.</p>

SSL Settings (continued)	Description
Common Name	<p>Enter the same name that the user will enter when requesting your web site.</p> <p>Example: If a user enters http://www.widgets.abccompany.com to access your web site, the Common Name would be www.widgets.abccompany.com.</p>
Expires	<p>Enter the expiration date, in mm/dd/yyyy format, for the new self-signed certificate.</p> <p>Example: An expiration date of May 9, 2010 is entered as 05/09/2010.</p>
Key length	<p>Select the bit size of the new self-signed certificate. Choices are:</p> <ul style="list-style-type: none"> ◆ 512 bits ◆ 768 bits ◆ 1024 bits <p>The larger the bit size, the longer it takes to generate the key. Approximate times are:</p> <ul style="list-style-type: none"> ◆ 10 seconds for a 512-bit RSA key ◆ 30 seconds for a 768-bit RSA key ◆ 1 minute for a 1024-bit RSA key ◆ 30 seconds for a 512-bit DSA key ◆ 2 minutes for a 768-bit DSA key ◆ 6 minute for a 1024-bit DSA key
Type	<p>Select the type of key:</p> <ul style="list-style-type: none"> ◆ RSA = Public-Key Cryptography algorithm based on large prime numbers, invented by Rivest Shamir and Adleman. Used for encryption and signing. ◆ DSA = Digital Signature Algorithm also based on large prime numbers, but can only be used for signing. Developed by the US government to avoid the patents on RSA.

3. Click **Submit**.

12: Modbus

Modbus ASCII/RTU based serial slave devices can be connected via the ethernet through an existing Modbus TCP/IP network. Any device having access to a given Modbus implementation will be able to perform full range of operations that the implementation supports. Modbus/TCP use a reserved TCP port of 502 and include a single byte function code (1=255) preceded by a 6 byte header:

Table 12-1 6 Byte Header of Modbus Application Protocol

Transaction ID (2 bytes)	Identification of request/response transaction - copied by slave
Protocol ID (2 bytes)	0 - Modbus protocol
Length (2 bytes)	Number of following bytes includes the unit identifier
Address (1 byte)	Identification of remove slave

Serial Transmission Mode

Evolution products can be set up to communicate on standard Modbus networks using either RTU or ASCII. Users select the desired mode and serial port communication parameters (baud rate, parity mode, etc) during the line configuration.

Table 12-2 Modbus Transmission Modes

RTU	ASCII
<ul style="list-style-type: none">◆ Address: 8 bits (0 to 247 decimal, 0 is used for broadcast)◆ Function: 8 bits (1 to 255, 0 is not valid)◆ Data: N X 8 bits (N=0 to 252 bytes)◆ CRC Check: 16 bits	<ul style="list-style-type: none">◆ Address: 2 CHARS◆ Function: 2 CHARS◆ Data: N CHARS (N=0 to 252 CHARS)◆ LRC Check: 2 CHARS

The Modbus web pages allow you to check Modbus status and make configuration changes. This chapter contains the following sections:

- ◆ [Modbus Statistics](#)
- ◆ [Modbus Configuration](#)

Modbus Statistics

This read-only web page displays the current connection status of the Modbus servers listening on the TCP ports. When a connection is active, the remote client information is displayed as well as the number of PDUs that have been sent and received. Additionally, a **Kill** link will be present which can be used to kill the connection.

To view modbus statistics:

1. Click **Modbus** on the menu bar and click **Statistics** at the top of the page. The Modbus Statistics page appears.

Figure 12-3 Modbus Statistics

<div> <div>Statistics</div> <div>Configuration</div> </div>	
Modbus Statistics	
TCP Server	
State:	Up
Port:	502
Last Connection:	local:502 <- 172.19.205.10:3903
Uptime:	0 days 02:38:20
Total PDUs In:	0
Total PDUs Out:	0
Total Connections:	1
Current Connections:	local:502 <- 172.19.205.10:3903 [Kill] Uptime: 0 days 02:36:48 PDUs In: 0 PDUs Out: 0
Additional TCP Server	
State:	Up
Port:	505
Last Connection:	<None>
Uptime:	0 days 02:35:53
Total PDUs In:	0
Total PDUs Out:	0
Total Connections:	0
Current Connections:	<None>
Local Slave	
Total PDUs In:	0
Total PDUs Out:	0
Exception Count:	0


Modbus Configuration

This web page shows the current negotiated Modbus settings and allows configuration changes.

To view and configure the Modbus Server:

1. Click **Modbus** on the menu bar and then click **Configuration** at the top of the page. The Modbus Configuration page appears.

Figure 12-4 Modbus Configuration



Statistics Configuration	
Modbus Configuration	
TCP Server State:	<input type="radio"/> On <input checked="" type="radio"/> Off
Additional TCP Server Port:	<input type="text" value="<None>"/>
Response Timeout:	<input type="text" value="3000"/> milliseconds
RSS Trace Input	<input type="radio"/> On <input checked="" type="radio"/> Off

2. Enter or modify the following settings:

Table 12-5 Modbus Configuration

Modbus Configuration Settings	Description
TCP Server State	If On , the Modbus server is active on TCP 502.
Additional TCP Server Port	If present, is used in addition to TCP port 502.
Response Timeout	The number of milliseconds to wait for a response on the serial side. The device returns exception code 11 to the network master controller if the slave serial device fails to reply within this time out.
RSS Trace Input	If On , each PDU received on the Modbus serial line creates a non-persistent descriptive item in the RSS feed.

3. Click **Submit**. The changes take effect immediately.

Note: The serial line protocol must also be configured for Modbus, in addition to configuring the Modbus server. See [Chapter 8: Line and Tunnel Settings on page 42](#) for details.

13: Maintenance and Diagnostics Settings

This chapter describes maintenance and diagnostic methods and contains the following sections:

- ◆ [Filesystem Settings](#)
- ◆ [Protocol Stack Settings](#)
- ◆ [IP Address Filter](#)
- ◆ [Query Port](#)
- ◆ [Diagnostics](#)
- ◆ [System Settings](#)

Filesystem Settings

The EDS1100/2100 uses a flash filesystem to store files. Use the Filesystem option to view current file statistics or modify files. There are two subsections: Statistics and Browse.

The Statistics section of the Filesystem web page shows current statistics and usage information of the flash filesystem. In the Browse section of the Filesystem web page, you can create files and folders, upload files, copy and move files, and use TFTP.

Filesystem Statistics

This page shows various statistics and current usage information of the flash filesystem.

Figure 13-1 Filesystem Statistics

<div>Statistics Browse</div>	
Filesystem Statistics	
Filesystem Size:	7.500000 Mbytes (7864320 bytes)
Available Space:	7.474250 Mbytes (7837320 bytes) (99%)
Clean Space:	7.336588 Mbytes (7692972 bytes) (97%)
Dirty Space:	140.964 Kbytes (144348 bytes) (1%)
File & Dir Space Used:	26.367 Kbytes (27000 bytes) (0%)
Data Space Used:	22.650 Kbytes (23194 bytes)
Number of Files:	0
Number of Dirs:	0
Number of System Files:	2
Opened Files:	0
Locked Files:	0
Opened for Sharing:	0
Current Bank:	B
FW Sectors:	02 - 07, 9 erase cycles
Bank A Sectors:	08 - 67, 0 erase cycles
Bank B Sectors:	68 - 127, 2 erase cycles
Busy:	No
Actions:	[Compact] [Format]

To view filesystem statistics or to compact or format the filesystem:

1. Back up all files as necessary.
2. Click **Filesystem** on the menu bar. The Filesystem page opens and shows the current filesystem statistics and usage.
3. To compact the files, click **Compact** in the Actions row.

Note: *The compact should not be needed under normal circumstances as the system manages this automatically.*

4. Back up all files before you perform the next (Format) step, because all user files get erased in that step.
5. Click **Format** in the Actions row. The configuration gets retained.

Filesystem Browser

To browse the filesystem:

1. Click **Filesystem** on the menu bar and then **Browse** at the top of the page. The Filesystem Browser page opens.

Figure 13-2 Filesystem Browser

Statistics
Browse

Filesystem Browser

/

Create

File: Create

Directory: Create

Upload File

Browse...

Upload

Copy File

Source:

Destination:

Copy

Move

Source:

Destination:

Move

TFTP

Action: ☐ Get ☐ Put

Mode: ☐ ASCII ☐ Binary

Local File:

Remote File:

Host:

Port:

Transfer

2. Click a filename to view the contents.
3. Click the **X** next to a filename to delete the file or directory. You can only delete a directory if it is empty.
4. Enter or modify the following settings:

Note: Changes apply to the current directory view. To make changes within other folders, click the folder or directory and then enter the parameters in the settings listed below.

Table 13-3 Filesystem Browser

Filesystem Browser Settings	Description
Create	
File	Enter the name of the file you want to create, and then click Create .
Directory	Enter the name of the directory you want to create, and then click Create .
Upload File	Enter the path and name of the file you want to upload by means of HTTP/HTTPS or use the Browse button to select the file, and then click Upload .
Copy File	
Source	Enter the location where the file you want to copy resides.
Destination	Enter the location where you want the file copied. After you specify a source and destination, click Copy to copy the file.
Move	
Source	Enter the location where the file you want to move resides.
Destination	Enter the location where you want the file moved. After you specify a source and destination, click Move to move the file.
TFTP	
Action	Select the action that is to be performed via TFTP: Get = a “get” command will be executed to store a file locally. Put = a “put” command will be executed to send a file to a remote location.
Mode	Select a TFTP mode to use. Choices are: ◆ ASCII ◆ Binary
Local File	Enter the name of the local file on which the specified “get” or “put” action is to be performed.
Remote File	Enter the name of the file at the remote location that is to be stored locally (“get”) or externally (“put”).
Host	Enter the IP address or name of the host involved in this operation.
Port	Enter the number of the port involved in TFTP operations on which the specified TFTP get or put command will be performed. Click Transfer to perform the TFTP transfer.

Protocol Stack Settings


In the Protocol Stack web page, you can configure TCP, IP, ICMP, SMTP and ARP.

TCP Settings

To configure the TCP network protocol:

1. Click **Protocol Stack** on the menu bar.
2. Click **TCP**.

Figure 13-4 TCP Protocol



TCP	
<div>TCP IP ICMP ARP SMTP</div>	
TCP	
Configuration	
Send RSTs:	<input checked="" type="radio"/> Enabled <input type="radio"/> Disabled
Ack Limit:	<input type="text" value="3"/> packets
Send Data:	<input checked="" type="radio"/> Standard <input type="radio"/> Expedited
Max Retrans:	<input type="text" value="12"/>
Max Retrans Syn/Ack:	<input type="text" value="2"/>
Max Timeout:	<input type="text" value="60"/> seconds
Statistics	
Total Out RSTs:	1
Total In RSTs:	5

3. Modify the following settings:

Table 13-5 TCP Settings

Protocol Stack TCP Settings	Description
Send RSTs	<p>Click Enabled to send RSTs or Disabled to stop sending RSTs. TCP contains six control bits, with one or more defined in each packet. RST is one of the control bits. The RST bit is responsible for telling the receiving TCP stack to end a connection immediately.</p> <p>Note: Setting the RSTs may pose a security risk.</p>
Ack Limit	<p>Enter a number to limit how many packets get received before an ACK gets forced. If there is a large amount of data to acknowledge, an ACK gets forced. If the sender TCP implementation waits for an ACK before sending more data even though the window is open, setting the Ack Limit to 1 packet improves performance by forcing immediate acknowledgements.</p>
Send Data	<p>The Send Data selection governs when data may be sent into the network. The Standard implementation waits for an ACK before sending a packet less than the maximum length. Select Expedited to send data whenever the window allows it.</p>

Table 13-5 TCP Settings

Protocol Stack TCP Settings	Description
Max Retrans	Enter the maximum number of retransmissions of a packet that will be attempted before failing.
Max Retrans Syn/Ack	Enter the maximum number of retransmissions of a SYN that will be attempted before failing. It is lower than "Max Retrans" to thwart denial-of-service attacks.
Max Timeout	Enter the maximum time between retransmissions.

4. Click **Submit**.

IP Settings

1. Click **Protocol Stack** on the menu bar.
2. Click **IP**.

Figure 13-6 IP Protocol

The screenshot shows the IP Protocol configuration window. The 'IP' tab is selected in the top menu. The 'Configuration' section contains two settings: 'IP Time to Live' set to 64 hops and 'Multicast Time to Live' set to 1 hops.

3. Modify the following settings:

Table 13-7 IP Settings

Protocol Stack IP Settings	Description
IP Time to Live	This value typically fills the Time To Live in the IP header. SNMP refers to this value as "ipDefaultTTL". Enter the number of hops to be transmitted before the packet is discarded.
Multicast Time to Live	This value fills the Time To Live in any multicast IP header. Normally this value will be one so the packet will be blocked at the first router. It is the number of hops allowed before a Multicast packet is discarded. Enter the value to be greater than one to intentionally propagate multicast packets to additional routers.

4. Click **Submit**.

ICMP Settings

To configure the ICMP network protocol:

1. Click **Protocol Stack** on the menu bar.
2. Click **ICMP**.

Figure 13-8 ICMP Protocol

TCP IP **ICMP** ARP SMTP

ICMP

Configuration

State: ☒ Enabled ☐ Disabled

3. Select the appropriate state.

Table 13-9 ICMP Settings

Protocol Stack ICMP Settings	Description
State	The State selection is used to turn on/off processing of ICMP messages. This includes both incoming and outgoing messages. Choose Enabled or Disabled .

4. Click **Submit**.

ARP Settings

To configure the ARP network protocol:

1. Click **Protocol Stack** on the menu bar.
2. Click **ARP**.

Figure 13-10 ARP Protocol Page

TCP IP ICMP ARP SMTP

ARP

Configuration

ARP Timeout:

0

1

0

hours

minutes

seconds

ARP Cache

IP Address:
 MAC Address:

Address	Age Sec	MAC Address	Type	Interface
172.19.100.3 [Remove]	8.0	00:16:76:b1:e3:50	Dynamic	1
172.19.217.2 [Remove]	43.3	00:25:11:8b:c1:f3	Dynamic	1
172.19.39.20 [Remove]	41.8	00:04:23:0e:19:36	Dynamic	1
172.19.1.1 [Remove]	18.4	00:1b:21:0e:3d:f4	Dynamic	1
172.19.0.1 [Remove]	7.7	00:d0:04:02:c0:00	Dynamic	1
172.19.250.250 [Remove]	0.0	00:25:11:3f:47:4d	Dynamic	1
172.19.100.181 [Remove]	15.7	00:15:17:4a:6d:51	Dynamic	1
172.19.39.23 [Remove]	6.2	00:17:31:47:19:71	Dynamic	1

[\[Remove All\]](#)

3. Modify the following settings:

Table 13-11 ARP Settings

Protocol Stack ARP Settings	Description
ARP Timeout	This is the maximum duration an address remains in the cache. Enter the time, in hours , minutes and seconds .
IP Address	Enter the IP address to add to the ARP cache.

Table 13-11 ARP Settings

Protocol Stack ARP Settings (continued)	Description
MAC Address	Enter the MAC address to add to the ARP cache.

Note: Both the IP and MAC addresses are required for the ARP cache.

- Click **Submit** for ARP or **Add** after supplying both address fields for ARP cache.
- Remove entries from the ARP cache, as desired:
 - Click **Remove All** to remove all entries in the ARP cache.
OR
 - Click **Remove** beside a specific entry to remove it from the ARP cache.

SMTP Settings

SMTP is configuration for a basic SMTP proxy. An SMTP proxy in this sense is a simple forwarding agent.

Note: Lantronix does not support SMTP AUTH or any other authentication or encryption schemes for email.

To configure the SMTP network protocol:

- Click **Protocol Stack** on the menu bar.
- Click **SMTP**.

Figure 13-12 SMTP

- Modify the following settings:

Table 13-13 SMTP Settings

Protocol Stack SMTP Settings	Description
Relay Address	Address of all outbound email messages through a mail server. Can contain either a hostname or an IP address.
Remote Port	Port utilized for the delivery of outbound email messages.

- Click **Submit**.

IP Address Filter

The IP address filter specifies the hosts and subnets permitted to communicate with the EDS1100/2100.

Note: If using DHCP/BOOTP, ensure the DHCP/BOOTP server is in this list.

To configure the IP address filter:

1. Click **IP Address Filter** on the menu bar. The IP Address Filter page opens to display the current configuration.

Figure 13-14 IP Address Filter Configuration



Note: Be aware not to assign your network IP address as "filtered." Doing so will prevent you from accessing the EDS1100/2100. You will have to then access the EDS1100/2100 from a different computer to reset the configuration.

2. Enter or modify the following settings:

Table 13-15 IP Address Filter Settings

IP Address Filter Settings	Description
IP Address	Enter the IP address to add to the IP filter table.
Network Mask	Enter the IP address' network mask in dotted notation.

3. Click **Add**.

Note: In the Current State table, click **Remove** to delete any existing settings, as necessary.

Query Port

The query port (0x77FE) is used for the automatic discovery of the device by the DeviceInstaller utility. Only 0x77FE discover messages from DeviceInstaller are supported. For more information on DeviceInstaller, see [Using DeviceInstaller \(on page 31\)](#).

To configure the query port server:

1. Click **Query Port** on the menu bar. The Query Port page opens to display the current configuration.

Figure 13-16 Query Port Configuration

Current Configuration and Statistics	
Query Port Status:	On (running)
In Valid Queries:	135
In Unknown Queries:	124
In Erroneous Packets:	0
Out Query Replies:	135
Out Errors:	0
Last Connection:	172.19.229.50:28683

2. Select **On** to enable the query port server.
3. Click **Submit**.

Diagnostics

The EDS1100/2100 has several tools to perform diagnostics and view device statistics. These include information on:

- ◆ Hardware
- ◆ MIB-II
- ◆ IP Sockets
- ◆ Ping
- ◆ Traceroute
- ◆ Log
- ◆ Memory
- ◆ Buffer Pools
- ◆ Processes

Hardware

This read-only page shows the current device's hardware configuration.

To display hardware diagnostics:

1. Click **Diagnostics** on the menu bar. The Diagnostics: Hardware page opens and shows the current hardware configuration.

Figure 13-17 Diagnostics: Hardware

The screenshot shows the 'Diagnostics: Hardware' page. At the top, there is a navigation menu with the following items: Hardware (selected), MIB-II, IP Sockets, Ping, Traceroute, Log, Memory, Buffer Pools, and Processes. Below the menu, the page title 'Diagnostics: Hardware' is displayed, followed by the section title 'Current Configuration'. A table lists the following hardware specifications:

CPU Type:	DSTniFX
CPU Speed:	166.666666 MHz
CPU Instruction Cache:	4.000 Kbytes (4096 bytes)
CPU Data Cache:	4.000 Kbytes (4096 bytes)
RAM Size:	8.000000 Mbytes (8388608 bytes)
Flash Size:	16.000000 Mbytes (16777216 bytes)
Flash Sector Size:	128.000 Kbytes (131072 bytes)
Flash Sector Count:	128
Flash ID:	0x1


MIB-II Statistics

The MIB-II Network Statistics page shows the various SNMP-served Management Information Bases (MIBs) available on the EDS1100/2100.

To view MIB-II statistics:

1. Click **Diagnostics** on the menu bar and then **MIB-II** at the top of the page menu. The MIB-II Network Statistics page opens.

Figure 13-18 MIB-II Network Statistics



2. Click any of the available links to open the corresponding table and statistics. For more information, refer to the table below:

Table 13-19 Requests for Comments (RFCs)

RFC 1213	Original MIB-II definitions.
RFC 2011	Updated definitions for IP and ICMP.
RFC 2012	Updated definitions for TCP.
RFC 2013	Updated definitions for UDP.
RFC 2096	Definitions for IP forwarding.

IP Sockets

To display open IP sockets:

1. Click **Diagnostics** on the menu bar and then **IP Sockets** at the top of the page. The IP Sockets page opens and shows all of the open IP sockets on the device.

Figure 13-20 IP Sockets

<div> <div>Hardware</div> <div>Ping</div> <div>Memory</div> </div> <div> <div>MIB-II</div> <div>Traceroute</div> <div>Buffer Pools</div> </div> <div> <div>IP Sockets</div> <div>Log</div> <div>Processes</div> </div>					
IP Sockets					
Protocol	RxQ	TxQ	LocalAddr:Port	RemoteAddr:Port	State
UDP	0	0	172.19.100.199:161	255.255.255.255:0	
TCP	0	0	172.19.100.199:21	255.255.255.255:0	LISTEN
UDP	0	0	172.19.100.199:69	255.255.255.255:0	
UDP	0	0	172.19.100.199:514	172.19.39.23:514	ESTABLISHED
TCP	0	0	172.19.100.199:80	255.255.255.255:0	LISTEN
UDP	0	0	172.19.100.199:30718	172.19.220.50:32770	ESTABLISHED
TCP	0	0	172.19.100.199:23	255.255.255.255:0	LISTEN
TCP	0	0	172.19.100.199:22	255.255.255.255:0	LISTEN
TCP	0	4	172.19.100.199:80	172.19.250.250:1844	ESTABLISHED

Ping

EDS1100/2100 uses 56 bytes of data in a ping packet. Ping size is not configurable.

To ping a remote device or computer:

1. Click **Diagnostics** on the menu bar and then **Ping** at the top of the page. The Diagnostics: Ping page opens.

Figure 13-21 Diagnostics: Ping

<div> <div>Hardware</div> <div>Ping</div> <div>Memory</div> </div> <div> <div>MIB-II</div> <div>Traceroute</div> <div>Buffer Pools</div> </div> <div> <div>IP Sockets</div> <div>Log</div> <div>Processes</div> </div>		
Diagnostics: Ping		
Host:	<input type="text"/>	
Count:	<input type="text" value="3"/>	
Timeout:	<input type="text" value="5"/>	seconds
<input type="button" value="Submit"/>		

2. Enter or modify the following settings:

Table 13-22 Diagnostics: Ping

Diagnostics: Ping Settings	Description
Host	Enter the IP address or host name for the device to ping.
Count	Enter the number of ping packets the device should attempt to send to the Host . The default is 3 .
Timeout	Enter the time, in seconds, for the device to wait for a response from the host before timing out. The default is 5 seconds.

3. Click **Submit**. The results of the ping display in the page.

Traceroute

Here you can trace a packet from the EDS1100/2100 to an Internet host, showing how many hops the packet requires to reach the host and how long each hop takes. If you visit a web site whose pages appear slowly, you can use traceroute to determine where the longest delays are occurring.

To use Traceroute:

1. Click **Diagnostics** on the menu bar and then **Traceroute** at the top of the page. The Diagnostics: Traceroute page opens.

Figure 13-23 Diagnostics: Traceroute

Traceroute Results		
1	172.19.0.1	2 ms

2. Enter or modify the following setting:

Table 13-24 Diagnostics: Traceroute

Diagnostics: Traceroute Settings	Description
Host	Enter the IP address or DNS hostname. This address is used to show the path between it and the device when issuing the traceroute command.

3. Click **Submit**. The results of the traceroute display in the page.

Log

Here you can enable a diagnostics log of configuration items:

To use diagnostics logging:

1. Click **Diagnostics** on the menu bar and then **Log** at the top of the page. The Diagnostics: Log page opens.

Figure 13-25 Diagnostics: Log

The screenshot shows the 'Diagnostics: Log' page. At the top, there is a navigation bar with links: Hardware, MIB-II, IP Sockets, Ping, Traceroute, Log (highlighted), Memory, Buffer Pools, and Processes. Below this, the 'Diagnostics: Log' title is displayed. Under the 'Configuration' section, there is a label 'Output:' followed by a dropdown menu currently set to 'Disable'.

2. Click the **Output** type and select one of the following:
 - ◆ Disable (default)
 - ◆ Filesystem
 - ◆ Line1

Figure 13-26 Diagnostics: Log (Filesystem)

The screenshot shows the 'Diagnostics: Log (Filesystem)' page. It has the same navigation bar as Figure 13-25. Below the title, the 'Configuration' section contains three rows of settings: 'Output:' with a dropdown set to 'Filesystem', 'Max Length:' with a text input '50' and the unit 'Kbytes', and 'Severity Level:' with a dropdown set to 'Debug'. A 'Submit' button is located at the bottom of the configuration section.

Figure 13-27 Diagnostics: Log (Line 1)

Hardware	MIB-II	IP Sockets
Ping	Traceroute	Log
Memory	Buffer Pools	Processes

Diagnostics: Log

Configuration	
Output:	Line 1
Severity Level:	Notice

Submit

3. If you selected Filesystem or Line1 Output types also complete additional selections:
 - ◆ **Max Length** (for Filesystem only) limits the size in Kbytes of the log (/log.txt).
 - ◆ **Severity Level** specifies the level of system message to be logged.
4. Click **Submit**.


Memory

This read-only web page shows the total memory and available memory (in bytes), along with the number of fragments, allocated blocks, and memory status.

To display memory statistics:

1. Click **Diagnostics** on the menu bar and then **Memory** at the top of the page. The Diagnostics: Memory page appears.

Figure 13-28 Diagnostics: Memory




Buffer Pools

Several parts of the EDS1100/2100 system use private buffer pools to ensure deterministic memory management.

To display the buffer pools:

1. Click **Diagnostics** on the menu bar and then **Buffer Pools** at the top of the page. The Diagnostics: Buffer Pools page opens.

Figure 13-29 Diagnostics: Buffer Pools



Processes


The Processes web page shows all the processes currently running on the system. It shows the Process ID (PID), the percentage of total CPU cycles a process used within the last three seconds, the total stack space available, the maximum amount of stack space used by the process since it started, and the process name.

To display the processes running and their associated statistics:

1. Click **Diagnostics** on the menu bar and then **Processes** at the top of the page.

Note: The Adobe SVG plug-in is required to view the CPU Load Graph.

Figure 13-30 Diagnostics: Processes




System Settings

The EDS1100/2100 System web page allows for rebooting the device, restoring factory defaults, uploading new firmware, configuring the short and long name, and viewing the current system configuration.

To configure system settings:

1. Click **System** on the menu bar. The System page opens.

Figure 13-31 System



System

Reboot Device

Restore Factory Defaults

Upload New Firmware

Name

Short Name:

Long Name:

Current Configuration

Firmware Version:	5.2.0.0R12
Short Name:	my_device_server
Long Name:	Lantronix DeviceLinx

2. Configure the following settings:

Table 13-32 System

System Settings	Description
Reboot Device	Click Reboot to reboot the device. The system refreshes and redirects the browser to the device home page.
Restore Factory Defaults	Click Factory Defaults to restore the device to the original factory settings. All configurations will be lost. The device automatically reboots upon setting back to the defaults.

System Settings (continued)	Description
Upload New Firmware	<p>Click Browse to locate the firmware file location. Click Upload to install the firmware on the device. The device automatically reboots upon the installation of new firmware.</p> <p><i>Note:</i> Close and reopen the web manager browser upon a firmware update.</p>
Name	<p>Enter a new Short Name and a Long Name (if necessary). The Short Name maximum is 32 characters. The Long Name maximum is 64 characters.</p> <p>Click Submit. Changes take place upon the next reboot.</p>

14: Advanced Settings

This chapter describes the configuration of Email, CLI, and XML. It contains the following sections:

- ◆ [Email Settings](#)
- ◆ [Command Line Interface Settings](#)
- ◆ [XML Settings](#)

Email Settings

The EDS1100/2100 allows you to view and configure email alerts relating to the events occurring within the system.

Note: The following section describes the steps to configure Email 1; these steps also apply to the other Email instances.

Email Statistics

This read-only page shows various statistics and current usage information about the email subsystem. When you transmit an email, the transmission to the SMTP server gets logged and displayed in the bottom portion of the page.

1. Click **Email 1** and **Statistics** at the top of the page to view its statistics.
2. Click **Clear** to clear the log.

Email 1Email 2Email 3Email 4

StatisticsConfigurationSend Email

Email 1 - Statistics

Sent successfully:	1
Retries:	0
Not sent due to excessive errors:	0
In transmission queue:	0

Log [Clear]

```
120:15:49 220 2putt.int.lantronix.com Microsoft ESMTTP MAIL
Service, Version: 6.0.3
120:15:49 EHLO eng.lantronix.com
120:15:49 250-2putt.int.lantronix.com Hello [172.19.100.129]
120:15:49 250-TURN
120:15:49 250-SIZE
120:15:49 250-ETRN
120:15:49 250-PIPELINING
120:15:49 250-DSN
120:15:49 250-ENHANCEDSTATUSCODES
120:15:49 250-8bitmime
120:15:49 250-BINARYMIME
120:15:49 250-CHUNKING
120:15:49 250-VRFY
120:15:49 250-X-EXPS GSSAPI NTLM LOGIN
120:15:49 250-X-EXPS=LOGIN
120:15:49 250-AUTH GSSAPI NTLM LOGIN
120:15:49 250-AUTH=LOGIN
120:15:49 250-X-LINK2STATE
120:15:49 250-XEXCH50
120:15:49 250 OK
120:15:49 MAIL FROM:<skuppuswamy@lantronix.com>
120:15:49 250 2.1.0 skuppuswamy@lantronix.com...Sender OK
120:15:49 RCPT TO:<skuppuswamy@lantronix.com>
120:15:49 250 2.1.5 skuppuswamy@lantronix.com
120:15:49 DATA
120:15:49 354 Start mail input; end with <CRLF>.<CRLF>
120:15:49 .
120:15:49 250 2.6.0
<2PUTTmopQeXr0kaK9Gt000002ac@2putt.int.lantronix.com> Queued
m
120:15:49 QUIT
```

Figure 14-1 Email Statistics

Email Configuration

The EDS1100/2100 allows you to view and configure email alerts relating to the events occurring within the system.

To configure email settings:

1. Click **Email** on the menu bar and then **Email 1** and **Configuration** at the top of the page. The Email 1 - Configuration page opens to display the current Email configuration.

Figure 14-2 Email Configuration

Note: The **Trigger Email Send** option displayed in the screenshot is only supported in XPort Pro and XPort AR.

2. Enter or modify the following settings:

Table 14-3 Email Configuration

Email – Configuration Settings	Description
To	Enter the email address to which the email alerts will be sent. Multiple addresses are separated by semicolon (;). Required field if an email is to be sent.
CC	Enter the email address to which the email alerts will be copied. Multiple addresses are separated by semicolon (;).
From	Enter the email address to list in the From field of the email alert. Required field if an email is to be sent.

Email – Configuration Settings (continued)	Description
Reply-To	Enter the email address to list in the Reply-To field of the email alert.
Subject	Enter the subject for the email alert.
Message File	Enter the path of the file to send with the email alert. This file appears within the message body of the email.
Overriding Domain	Enter the domain name to override the current domain name in EHLO (Extended Hello).
Server Port	Enter the SMTP server port number. The default is port 25 .
Local Port	Enter the local port to use for email alerts. The default is a random port number.
Priority	Select the priority level for the email alert.

3. Click **Submit**.
4. To test your configuration, you can send an email immediately by clicking **Send Email** at the top of the page. Refer back to the Statistics page for a log of the transaction.

Command Line Interface Settings

The Command Line Interface (CLI) web page enables you to view statistics about the CLI servers listening on the Telnet and SSH ports and to configure CLI settings.

CLI Statistics

This read-only page shows the current connection status of the CLI servers listening on the Telnet and SSH ports. When a connection is active, the following display:

- ◆ Remote client information
- ◆ Number of bytes that have been sent and received
- ◆ A **Kill** link to terminate the connection

To view the CLI Statistics:

1. Click **CLI** on the menu bar. The Command Line Interface Statistics page appears.

Statistics Configuration	
Command Line Interface Statistics	
Telnet	
Server Status:	Waiting
Last Connection:	<None>
Uptime:	0 days 19:20:38
Total Bytes In:	0
Total Bytes Out:	0
Current Connections:	<None>
SSH	
Server Status:	Waiting
Last Connection:	<None>
Uptime:	0 days 19:20:38
Total Bytes In:	0
Total Bytes Out:	0
Current Connections:	<None>

Figure 14-4 CLI Statistics

CLI Configuration

On this page you can change CLI settings.

To configure the CLI:

1. Click **CLI** on the menu and then **Configuration** at the top of the page. The Command Line Interface Configuration page appears.

Figure 14-5 CLI Configuration

Statistics Configuration	
Command Line Interface Configuration	
Login Password:	<None>
Enable Level Password:	<None>
Quit Connect Line:	<control>L
Inactivity Timeout:	15 minutes
Telnet State:	<input checked="" type="radio"/> Enabled <input type="radio"/> Disabled
Telnet Port:	23
Telnet Max Sessions:	3
SSH State:	<input checked="" type="radio"/> Enabled <input type="radio"/> Disabled
SSH Port:	22
SSH Max Sessions:	3

- Enter or modify the following settings:

Table 14-6 CLI Configuration

Command Line Interface Configuration Settings	Description
Login Password	Enter the password for Telnet access.
Enable Level Password	Enter the password for access to the Command Mode Enable level. There is no password by default.
Quit Connect Line	Enter a string to terminate a connect line session and resume the CLI. Type <control> before any key the user must press when holding down the Ctrl key. An example of such a string is <control>L .
Inactivity Timeout	Set an Inactivity Timeout value so the CLI session will disconnect if no data is received after the designated time period. Default is 15 minutes. Enter a value of 0 to disable.
Telnet State	Select Disabled to disable Telnet access. Telnet is enabled by default.
Telnet Port	Enter the Telnet port to use for Telnet access. The default is 23 .
Telnet Max Sessions	Maximum number of simultaneous Telnet sessions.
SSH State	Select Disabled to disable SSH access. SSH is enabled by default.
SSH Port	Enter the SSH port to use for SSH access. The default is 22 .
SSH Max Sessions	Maximum number of simultaneous SSH sessions.

- Click **Submit**.

XML Settings

The EDS1100/2100 allows for the configuration of devices by using XML configuration records (XCRs). You can export an existing configuration for use on other EDS1100/2100 devices or import a saved configuration file.

On the XML: Export Configuration web page, you can export the current system configuration in XML format. The generated XML file can be imported later to restore a configuration. It can also be modified and imported to update the configuration on this EDS1100/2100 unit or another. The XML data can be exported to the browser window or to a file on the file system.

By default, all groups are selected except those pertaining to the network configuration. This is so that if you later import the entire XML configuration, it will not break your network connectivity. You may select or clear the checkbox for any group.

In the XML: Import System Configuration Page you can import a system configuration from an XML file. The XML data can be imported from a file on the file system or uploaded using HTTP. The groups to import can be specified by toggling the respective group item or entering a filter string. When toggling a group item, all instances of that group will be imported. The filter string can be used to import specific instances of a group. The text format of this string is:

```
<g>:<i>;<g>:<i>...
```

For example, if you only wanted to import the line 1 setting from an XCR, use a filter string of line:1.

Each group name <g> is followed by a colon and the instance value <i>. Each <g>:<i> value is separated with a semicolon. If a group has no instance, specify the group name <g> only.

Note: The number of lines available for importing and exporting differ between Lantronix DeviceLinux products. The screenshots in this manual represent one line, as available, for example, on an XPort Pro and EDS1100. However, other device networking products (such as EDS2100, EDS4100, XPort AR, and EDS8/16/32PR) support additional lines and tunnels.

XML: Export Configuration

On this web page you can export the current system configuration in XML format.

To export the system configuration:

1. Click **XML** on the menu bar. The **XML: Export Configuration** page appears.

Figure 14-7 XML: Export Configuration

Export Configuration
Export Status
Import Configuration

XML: Export Configuration

☒ Export to browser
☐ Export to local file

☐ Export secrets (use only with extreme caution) ☐ Comments

Lines to Export: [\[Clear All\]](#) [\[Select All\]](#)

☒ 1 ☒ network

Groups to Export: [\[Clear All\]](#) [\[Select All but Networking\]](#)

<input checked="" type="checkbox"/> arp	<input checked="" type="checkbox"/> cli	<input checked="" type="checkbox"/> cp group
<input checked="" type="checkbox"/> device	<input checked="" type="checkbox"/> diagnostics	<input checked="" type="checkbox"/> email
<input checked="" type="checkbox"/> ethernet: eth0	<input checked="" type="checkbox"/> ftp server	<input checked="" type="checkbox"/> host
<input checked="" type="checkbox"/> http authentication uri	<input checked="" type="checkbox"/> http server	<input checked="" type="checkbox"/> icmp
<input type="checkbox"/> interface: eth0	<input checked="" type="checkbox"/> ip	<input checked="" type="checkbox"/> ip filter
<input checked="" type="checkbox"/> line	<input checked="" type="checkbox"/> lpd	<input checked="" type="checkbox"/> ManageLinux
<input checked="" type="checkbox"/> modbus	<input checked="" type="checkbox"/> ppp	<input checked="" type="checkbox"/> query port
<input checked="" type="checkbox"/> rss	<input checked="" type="checkbox"/> serial command mode	<input checked="" type="checkbox"/> smtp
<input checked="" type="checkbox"/> snmp	<input checked="" type="checkbox"/> ssh	<input checked="" type="checkbox"/> ssh client
<input checked="" type="checkbox"/> ssh server	<input checked="" type="checkbox"/> ssl	<input checked="" type="checkbox"/> syslog
<input checked="" type="checkbox"/> tcp	<input checked="" type="checkbox"/> telnet	<input checked="" type="checkbox"/> terminal
<input checked="" type="checkbox"/> tftp server	<input checked="" type="checkbox"/> tunnel accept	<input checked="" type="checkbox"/> tunnel connect
<input checked="" type="checkbox"/> tunnel disconnect	<input checked="" type="checkbox"/> tunnel modem	<input checked="" type="checkbox"/> tunnel packing
<input checked="" type="checkbox"/> tunnel serial	<input checked="" type="checkbox"/> vip	<input checked="" type="checkbox"/> xml import control

2. Enter or modify the following settings:

Table 14-8 XML Export Configuration

XML Export Configuration Settings	Description
Export to browser	Select this option to export the XCR data in the selected fields to a web browser.
Export to local file	Select this option to export the XCR data to a file on the device. If you select this option, enter a file name for the XML configuration record.
Export secrets	Only use this with extreme caution. If selected, secret password and key information will be exported. Use only with a secure link, and save only in secure locations.

XML Export Configuration Settings (continued)	Description
Lines to Export	Select the instances you want to export in the line, LPD, PPP, tunnel, and terminal groups.
Groups to Export	Check the configuration groups that are to be exported to the XML configuration record.

- Click **Export**. The groups display if exporting the data to the browser. If exporting the data to a local file, the file is stored on the file system.

Note: Most browsers will interpret and display the XML data without the XML tags. To view the raw XML, choose the view file source feature of your browser.

XML: Export Status

To export the system status:

On this page you can export the current system status in XML format. The XML data can be exported to the browser page or to a file on the file system.

- Click **XML** on menu bar and then **Export Status** at the top of the page. The XML: Export Status page appears.
- Enter or modify the following settings:

Export Configuration
Export Status
Import Configuration

XML: Export Status

☒ Export to browser
☐ Export to local file

Lines to Export:
[Clear All]
[Select All]

☒ 1
☒ network

Groups to Export:
[Clear All]
[Select All]

<input checked="" type="checkbox"/> arp	<input checked="" type="checkbox"/> buffer pool	<input checked="" type="checkbox"/> cp group
<input checked="" type="checkbox"/> cps	<input checked="" type="checkbox"/> device	<input checked="" type="checkbox"/> email
<input checked="" type="checkbox"/> email log	<input checked="" type="checkbox"/> filesystem	<input checked="" type="checkbox"/> ftp
<input checked="" type="checkbox"/> hardware	<input checked="" type="checkbox"/> http	<input checked="" type="checkbox"/> http log
<input checked="" type="checkbox"/> icmp	<input checked="" type="checkbox"/> interface: eth0	<input checked="" type="checkbox"/> ip
<input checked="" type="checkbox"/> ip sockets	<input checked="" type="checkbox"/> line	<input checked="" type="checkbox"/> lpd
<input checked="" type="checkbox"/> memory	<input checked="" type="checkbox"/> modbus local slave	<input checked="" type="checkbox"/> modbus tcp server: additional
<input checked="" type="checkbox"/> modbus tcp server: permanent	<input checked="" type="checkbox"/> processes	<input checked="" type="checkbox"/> query port
<input checked="" type="checkbox"/> rss	<input checked="" type="checkbox"/> sessions	<input checked="" type="checkbox"/> ssh
<input checked="" type="checkbox"/> syslog	<input checked="" type="checkbox"/> tcp	<input checked="" type="checkbox"/> telnet
<input checked="" type="checkbox"/> tftp	<input checked="" type="checkbox"/> tunnel	<input checked="" type="checkbox"/> udp
<input checked="" type="checkbox"/> vip	<input checked="" type="checkbox"/> xsr	

Export

Figure 14-9 XML: Export Status

Table 14-10 XML Export Status

XML: Export System Status Settings	Description
Export to browser	Select this option to export the XML status record to a web browser.
Export to local file	Select this option to export the XML status record to a file on the device. If you select this option, enter a file name for the XML status record.
Lines to Export	Select the instances you want to export in the line, LPD, PPP, tunnel, and terminal groups.
Groups to Export	Check the configuration groups that are to be exported into the XML status record.

- Click **Export**. The groups display if exporting the data to the browser. If exporting the data to a local file system, the file is stored on the file system.

Note: Most browsers will interpret and display the XML data without the XML tags. To view the raw XML, choose the view file source feature of your browser.

XML: Import Configuration

Here you can import a system configuration from an XML file.

The XML data can be imported from a file on the file system or uploaded using HTTP. The groups to import can be specified by toggling the respective group item or entering a filter string. When toggling a group item, all instances of that group will be imported. The filter string can be used to import specific instances of a group. The text format of this string is:

```
<g>:<i>;<g>:<i>;...
```

Each group name <g> is followed by a colon and the instance value <i>. Each <g> :<i> value is separated with a semicolon. If a group has no instance, specify the group name <g> only.

To import a system configuration:

- Click **XML** on the menu bar and then **Import Configuration** at the top of the page. The XML: Import Configuration web page appears.

Figure 14-11 XML: Import Configuration

Export Configuration Export Status **Import Configuration**

XML: Import Configuration

Import:

- ☐ Configuration from External file
- ☐ Configuration from Filesystem
- ☐ Line(s) from single line Settings on the Filesystem

- Click one of the following radio buttons:
 - ◆ Configuration from External file. [See Import Configuration from External File on page 132.](#)

- ◆ Configuration from Filesystem. [See Import Configuration from the Filesystem on page 133.](#)
- ◆ Line(s) from single line Settings on the Filesystem. [See Import Line\(s\) from Single Line Settings on the Filesystem on page 135.](#)

Import Configuration from External File

This selection shows a field for entering the path and file name of the entire external XCR file you want to import. You can also browse to select the XCR file.

Figure 14-12 XML: Import Configuration from External File

The screenshot shows a software interface for importing configuration. At the top, there is a horizontal bar with three tabs: 'Export Configuration', 'Export Status', and 'Import Configuration'. The 'Import Configuration' tab is selected. Below the tabs, the title 'XML: Import Configuration' is displayed. Underneath the title, the text 'Import configuration from (entire) external XCR file:' is followed by a text input field and a 'Browse...' button. At the bottom left of the dialog, there is an 'Import' button.

Import Configuration from the Filesystem

This selection shows a page for entering the filesystem and your import requirements – groups, lines, and instances.

Figure 14-13 XML: Import from Filesystem

Export Configuration Export Status **Import Configuration**

XML: Import Configuration

Import configuration from the filesystem:

Filename

Lines to Import: [\[Clear All\]](#) [\[Select All\]](#)

☒ 1 ☒ network

Whole Groups to Import: [\[Clear All\]](#) [\[Select All but Networking\]](#)

<input checked="" type="checkbox"/> arp	<input checked="" type="checkbox"/> cli	<input checked="" type="checkbox"/> cp group
<input checked="" type="checkbox"/> device	<input checked="" type="checkbox"/> diagnostics	<input checked="" type="checkbox"/> email
<input checked="" type="checkbox"/> ethernet	<input checked="" type="checkbox"/> execute	<input checked="" type="checkbox"/> exit cli
<input checked="" type="checkbox"/> ftp server	<input checked="" type="checkbox"/> host	<input checked="" type="checkbox"/> http authentication uri
<input checked="" type="checkbox"/> http server	<input checked="" type="checkbox"/> icmp	<input type="checkbox"/> interface
<input checked="" type="checkbox"/> ip	<input checked="" type="checkbox"/> ip filter	<input checked="" type="checkbox"/> line
<input checked="" type="checkbox"/> lpd	<input checked="" type="checkbox"/> ManageLinux	<input checked="" type="checkbox"/> modbus
<input checked="" type="checkbox"/> ppp	<input checked="" type="checkbox"/> query port	<input checked="" type="checkbox"/> rss
<input checked="" type="checkbox"/> serial command mode	<input checked="" type="checkbox"/> smtp	<input checked="" type="checkbox"/> snmp
<input checked="" type="checkbox"/> ssh	<input checked="" type="checkbox"/> ssh client	<input checked="" type="checkbox"/> ssh server
<input checked="" type="checkbox"/> ssl	<input checked="" type="checkbox"/> syslog	<input checked="" type="checkbox"/> tcp
<input checked="" type="checkbox"/> telnet	<input checked="" type="checkbox"/> terminal	<input checked="" type="checkbox"/> tftp server
<input checked="" type="checkbox"/> tunnel accept	<input checked="" type="checkbox"/> tunnel connect	<input checked="" type="checkbox"/> tunnel disconnect
<input checked="" type="checkbox"/> tunnel modem	<input checked="" type="checkbox"/> tunnel packing	<input checked="" type="checkbox"/> tunnel serial
<input checked="" type="checkbox"/> vip	<input checked="" type="checkbox"/> xml import control	

Text List

1. Enter or modify the following settings.

Figure 14-14 XML: Import Configuration from Filesystem

Import Configuration from Filesystem Settings	Description
Filename	Enter the name of the file on the device (local to its filesystem) that contains XCR data.
Lines to Import	<p>Select the lines or network whose settings you want to import. Click the Select All link to select all the serial lines and the network lines. Click the Clear All link to clear all of the checkboxes. By default, all line instances are selected.</p> <p>Only the selected line instances will be imported in the line, LPD, PPP, tunnel, and terminal groups.</p>
Whole Groups to Import	<p>Select the configuration groups to import from the XML configuration record. This option imports all instances of each selected group unless it is one of the Lines to Import.</p> <p><i>Note: By default, all groups are checked except those pertaining to the network configuration; this is so that import will not break your network connectivity.</i></p> <p>You may check or uncheck any group to include or omit that group from import. To import all of the groups, click the Select All but Networking link to import all groups. To clear all the checkboxes, click the Clear All link.</p>
Text List	<p>Enter a string to import specific instances of a group. The textual format of this string is:</p> <p><code><g>:<i>;<g>:<i>;...</code></p> <p>Each group name <code><g></code> is followed by a colon and the instance value <code><i></code> and each <code><g>:<i></code> value is separated by a semi-colon. If a group has no instance, then specify the group name <code><g></code> only.</p> <p>Use this option for groups other than those affected by Lines to Import.</p>

2. Click **Import**.

Import Line(s) from Single Line Settings on the Filesystem

This selection copies line settings from the single line instance in the input file to selected lines. The import file may only contain records from a single line instance; this is done by selecting a single **Line to Export** when exporting the file.

To modify Single Line Settings on the Filesystem:

Figure 14-15 XML: Import Line(s) from Single Line Settings on the Filesystem

Export Configuration
Export Status
Import Configuration

XML: Import Configuration

Import Line(s) from single line settings on the filesystem:

Filename

Lines to Import: [\[Clear All\]](#) [\[Select All\]](#)

☒ 1 ☒ network

Whole Groups to Import: [\[Clear All\]](#) [\[Select All but Networking\]](#)

<input checked="" type="checkbox"/> arp	<input checked="" type="checkbox"/> cli	<input checked="" type="checkbox"/> cp group
<input checked="" type="checkbox"/> device	<input checked="" type="checkbox"/> diagnostics	<input checked="" type="checkbox"/> email
<input checked="" type="checkbox"/> ethernet	<input checked="" type="checkbox"/> execute	<input checked="" type="checkbox"/> exit cli
<input checked="" type="checkbox"/> ftp server	<input checked="" type="checkbox"/> host	<input checked="" type="checkbox"/> http authentication uri
<input checked="" type="checkbox"/> http server	<input checked="" type="checkbox"/> icmp	<input type="checkbox"/> interface
<input checked="" type="checkbox"/> ip	<input checked="" type="checkbox"/> ip filter	<input checked="" type="checkbox"/> line
<input checked="" type="checkbox"/> lpd	<input checked="" type="checkbox"/> ManageLinx	<input checked="" type="checkbox"/> modbus
<input checked="" type="checkbox"/> ppp	<input checked="" type="checkbox"/> query port	<input checked="" type="checkbox"/> rss
<input checked="" type="checkbox"/> serial command mode	<input checked="" type="checkbox"/> smtp	<input checked="" type="checkbox"/> snmp
<input checked="" type="checkbox"/> ssh	<input checked="" type="checkbox"/> ssh client	<input checked="" type="checkbox"/> ssh server
<input checked="" type="checkbox"/> ssl	<input checked="" type="checkbox"/> syslog	<input checked="" type="checkbox"/> tcp
<input checked="" type="checkbox"/> telnet	<input checked="" type="checkbox"/> terminal	<input checked="" type="checkbox"/> tftp server
<input checked="" type="checkbox"/> tunnel accept	<input checked="" type="checkbox"/> tunnel connect	<input checked="" type="checkbox"/> tunnel disconnect
<input checked="" type="checkbox"/> tunnel modem	<input checked="" type="checkbox"/> tunnel packing	<input checked="" type="checkbox"/> tunnel serial
<input checked="" type="checkbox"/> vip	<input checked="" type="checkbox"/> xml import control	

1. Enter of modify the following settings:

Table 14-16 XML: Import Line(s) from Single Line Settings

Import Line(s) Settings	Description
Filename	Provide the name of the file on the device (local to its file system) that contains XCR data.
Lines to Import	Select the line(s) whose settings you want to import. Click the Select All link to select all the serial lines and the network lines. Click the Clear All link clear all of the checkboxes. By default, all serial line instances are selected.
Whole Groups to Import	<p>Select the configuration groups to import from the XML configuration record.</p> <p>Note: <i>By default, all groups are checked except those pertaining to the network configuration; this is so that import will not break your network connectivity.</i></p> <p>You may check or uncheck any group to include or omit that group from import. To import all of the groups, click the Select All but Networking link to import all groups. To clear all the checkboxes, click the Clear All link.</p>

2. Click **Import**.

15: VIP Settings

VIP (Virtual IP) takes advantage of the Lantronix ManageLinx technology that solves the access-through-firewall problem. ManageLinx utilizes existing network infrastructure to create a virtual device network (VDN). The VDN provides direct access to only authorized equipment, behind firewalls, from anywhere via the net.

ManageLinx is a secure and totally transparent remote access solution. The VDN technology enables you to create dedicated TCP/IP connections between any two devices, using easily deployed hardware appliances. There is no client software to install. No changes are required to network software or applications at either end of the connection.

The VDN hardware consists of a publicly accessible Device Services Manager (DSM) and individual Device Services Controller (DSC) appliances in multiple locations. Together, these two components enable you to set up and manage individual Virtual IP (VIP) addresses and routes.

The EDS1100/2100, with VIP enabled, takes the place of a DSC and provides direct access to your equipment.

The EDS1100/2100 supports both Accept and Connect Mode tunneling through VIPs. Configuring an EDS1100/2100 to use VIP Access involves:

- ◆ [Obtaining a Bootstrap File](#)
- ◆ [Importing the Bootstrap File](#)
- ◆ [Enabling VIP](#)
- ◆ [Configuring Tunnels to Use VIP](#)

Once the EDS1100/2100 is configured and enabled to use VIPs, it will immediately attempt to establish a conduit with the ManageLinx DSM. Once the conduit is up, tunneling via VIP Access is ready to go. This chapter also contains the following VIP sections:

- ◆ [Virtual IP \(VIP\) Statistics](#)
- ◆ [Virtual IP \(VIP\) Counters](#)
- ◆ [Virtual IP \(VIP\) Configuration](#)

Obtaining a Bootstrap File

The ManageLinx XML bootstrap file is an XML file that contains the information required to contact and authenticate to a DSM. This file must be generated and sent to you by the DSM administrator. See the ManageLinx documentation for more details.

Importing the Bootstrap File

To configure an EDS1100/2100 to use VIP Access, import the bootstrap file as you would any XML Configuration Record (XCR). For instructions on importing XCRs see [Advanced Settings \(on page 123\)](#).

Enabling VIP

Once the bootstrap file has been imported, VIP Access can be enabled and a conduit with the DSM will be established. The VIP Statistics shows the current state of the conduit. When configured correctly, a conduit with the DSM will be maintained at all times.

Configuring Tunnels to Use VIP

Configuring Connect Mode tunnels to use VIP is a simple matter of configuring a tunnel as is normally done, but also enabling VIP in the Tunnel Host settings, and using a VIP Name for the address.

VIP Accept Mode tunnels do not require special configuration. If VIP access is enabled (in the VIP configuration page), then VIP Accept Mode requests from a ManageLinux device will be accepted.

Virtual IP (VIP) Statistics

To view the EDS1100/2100 VIP Statistics:

1. Click **VIP** from the main menu. The VIP Status page appears.

Figure 15-1 VIP Status


<div> <div>Status</div> <div>Counters</div> <div>Configuration</div> </div>	
Virtual IP (VIP) Status	
Config Name:	EDS2100-213-200
Current DSM IP Address:	
Current Tunnel Port:	0
DSM IP Address List:	172.19.38.1
Tunnel Port List:	22,80,443
Conduit Status:	Disabled
Conduit Uptime:	0 days 00:00:00
Time of Last Replication:	Fri Oct 22 10:41:51 PDT 2010
Replication Period:	900 seconds
Tunnel Proxy Host:	
Tunnel Proxy Port:	
VIP Pools:	0
Network Interfaces:	EDS2100 EDS32PR EDS4100
Local Dna ID:	dna.dev.rnd:d6642facf
Tunnel User:	TUN58baf
Tunnel HTTP Port List:	80,443

Virtual IP (VIP) Counters

To view EDS1100/2100 VIP settings:

1. Click **VIP > Counters** from the main menu. The VIP Counters page displays.

Figure 15-2 VIP Counters



	Receive	Transmit
Data Bytes:	0	0
UDP Packet Queue:	N/A	0
UDP Packets:	0	0

Table 15-3 VIP Counters


VIP Counters	Description
Data Bytes	Total bytes in the TCP packets (not the UDP packets)
UDP Packet Queue	The number of packets queued for transmission.
UDP Packets	The number of packets transmitted. <i>Note: UDP counts are packet based, and do not record the number of data bytes.</i>

Virtual IP (VIP) Configuration

To configure the EDS1100/2100 VIP settings:

1. Click **VIP > Configuration** from the main menu. The VIP Configuration page displays.

Figure 15-4 VIP Configuration Page



State: ☒ Enabled ☐ Disabled

2. Click **Enabled/Disabled** to use/turn off VIP addresses in Tunnel Accept Mode and Tunnel Connect Mode. The default is disabled.
3. Click **Submit** save a changed state.

16: Branding the EDS1100/2100

This chapter describes how to brand your EDS1100/2100 by using Web Manager and Command Line Interface (CLI). It contains the following sections on customization:

- ◆ [Web Manager Customization](#)
- ◆ [Short and Long Name Customization](#)

Web Manager Customization

Customize the Web Manager's appearance by modifying index.html and style.css. The style (fonts, colors, and spacing) of the Web Manager is controlled with style.css and the text and graphics are controlled with index.html.

The Web Manager files are hidden and are incorporated directly into the firmware image but may be overridden by placing the appropriate file in the appropriate directory on the EDS1100/2100 file system.

Web Manager files can be retrieved and overridden with the following procedure:

1. FTP to the EDS1100/2100 device.
2. Make a directory (**mkdir**) and name it http/config
3. Change to the directory (**cd**) that you created in step 2. (http/config)
4. Get the file by using **get** <filename>
5. Modify the file as required or create a new one with the same name
6. Put the file by using **put** <filename>
7. Type **quit**. The overriding files appear in the file system's http/config directory.
8. Restart any open browser to view the changes.
9. If you wish to go back to the default files in the firmware image, simply delete the overriding files from the file system.

Short and Long Name Customization

You can customize the short and long names in Web Manager. The names display in the CLI show command and in the System web page in the Current Configuration table. The short name is used for the show command. Both names display in the CLI Product Type field in the following example:

```
(enable)# show
```

The long and short names appear in the Product Type field in the following format:

```
Product Type: <long name> (<short name>)
```

For example:

```
(enable)# show EDS
Product Information:
Product Type: Lantronix EDS1100/2100 (EDS)
```

To change the short and long names with the web manager:

1. Click **System** in the menu bar. The System page opens.

Figure 16-1 System Branding

System

Reboot Device

Restore Factory Defaults

Upload New Firmware

Name

Short Name:

Long Name:

2. In the **Short Name** field, enter the new short name for the device (up to 32 characters).
3. In the **Long Name** field, enter the new long name for the device (up to 64 characters).
4. Click **Submit**.
5. Click **Reboot** to display the names.

17: Updating Firmware

Obtaining Firmware

Obtain up-to-date firmware and release notes for the unit from the Lantronix web site (<http://www.lantronix.com/support/downloads>) or by using anonymous FTP (<ftp://ftp.lantronix.com/>).


Loading New Firmware

Reload the firmware using the device web manager Filesystem page.

To upload new firmware:

1. Click **System** in the menu bar. The **Filesystem** page appears.

Figure 17-1 Update Firmware



The screenshot shows the 'System' page of a device web manager. It contains several sections: 'Reboot Device' with a 'Reboot' button; 'Restore Factory Defaults' with a 'Factory Defaults' button; 'Upload New Firmware' which is highlighted with an orange oval and contains a file input field, a 'Browse...' button, and an 'Upload' button; and 'Name' with 'Short Name' and 'Long Name' input fields and a 'Submit' button.

2. Click **Browse** to browse to the firmware file.
3. Highlight the file and click **Open**.
4. Click **Upload** to install the firmware on the EDS1100/2100. The device automatically reboots on the installation of new firmware.
5. Close and reopen the web manager internet browser to view the device's updated web pages.

Note: Alternatively, firmware may be updated by sending the file to the EDS1100/2100 over a FTP or TFTP connection.

Appendix - Technical Support

If you are unable to resolve an issue using the information in this documentation, please contact Technical Support:

Technical Support US

Check our online knowledge base or send a question to Technical Support at <http://www.lantronix.com/support>.

Technical Support Europe, Middle East, Africa

Phone: +33 13 930 4172

Email: eu_techsupp@lantronix.com or eu_support@lantronix.com

Firmware downloads, FAQs, and the most up-to-date documentation are available at <http://www.lantronix.com/support>.

When you report a problem, please provide the following information:

- ◆ Your name, and your company name, address, and phone number
- ◆ Lantronix model number
- ◆ Lantronix serial number
- ◆ Firmware version (on the first screen shown when you Telnet to the device and type show)
- ◆ Description of the problem
- ◆ Status of the unit when the problem occurred (please try to include information on user and network activity at the time of the problem)
- ◆ Additionally, it may be useful to export and submit the XML Configuration and XML Status files

Appendix - Binary to Hexadecimal Conversions

Many of the unit's configuration procedures require you to assemble a series of options (represented as bits) into a complete command (represented as a byte).

The resulting binary value must be converted to a hexadecimal representation.

Use this chapter to learn to convert binary values to hexadecimal or to look up hexadecimal values in the tables of configuration options. The tables include:

- ◆ Command Mode (serial string sign-on message)
- ◆ AES Keys

Converting Binary to Hexadecimal

Conversion Table

Hexadecimal digits have values ranging from 0 to F, which are represented as 0-9, A (for 10), B (for 11), etc. To convert a binary value (for example, 0100 1100) to a hexadecimal representation, treat the upper and lower four bits separately to produce a two-digit hexadecimal number (in this case, 4C). Use the following table to convert values from binary to hexadecimal.


Table 19-1 Binary to Hexadecimal Conversion Table

Decimal	Binary	Hex
0	0000	0
1	0001	1
2	0010	2
3	0011	3
4	0100	4
5	0101	5
6	0110	6
7	0111	7
8	1000	8
9	1001	9
10	1010	A
11	1011	B
12	1100	C
13	1101	D
14	1110	E
15	1111	F


Scientific Calculator

Another simple way to convert binary to hexadecimal is to use a scientific calculator, such as the one available on the Windows operating systems. For example:

1. On the Windows Start menu, click **Programs > Accessories > Calculator**.
2. On the View menu, select **Scientific**. The scientific calculator appears.
3. Click **Bin** (Binary), and type the number you want to convert.



4. Click **Hex**. The hexadecimal value appears.



Appendix - Compliance

(According to ISO/IEC Guide 17050-1, 17050-2 and EN 45014)

Manufacturer's Name & Address:

Lantronix 167 Technology Drive, Irvine, CA 92618 USA

Product Name Model:

EDS1100/2100 Device Server

Conforms to the following standards or other normative documents:

Radiated and Conducted Emissions

FCC Part 15 Subpart B
Industry Canada ICES-003 Issue 4 2004
CISPR 22: 2005 Information Technology Equipment
VCCI V-3/2009.04
AS/NZS CISPR 22: 2006
EN55022: 2006
EN61000-3-2: 2006
EN61000-3-3: 1995 + A1: 2001 + A2: 2005

Immunity

EN55024: 1998 + A1: 2001 + A2: 2003

Direct & Indirect ESD

EN61000-4-2: 1995 + A2:2001

RF Electromagnetic Field Immunity

EN61000-4-3: 2006 + A1:2008

Electrical Fast Transient/Burst Immunity

EN61000-4-4: 2004

Surge Immunity

EN61000-4-5: 2006

RF Common Mode Conducted Susceptibility

EN61000-4-6: 2007

Power Frequency Magnetic Field Immunity

EN61000-4-8: 1994 +A1: 2001

Voltage Dips and Interrupts

EN61000-4-11: 2004

Safety

UL 60950-1
CAN/CSA-C22.2 No. 60950-1-03
EN 60950-1:2001, Low Voltage Directive (73/23/EEC)

Manufacturer's Contact:

Lantronix
167 Technology Drive, Irvine, CA 92618 USA
Tel: 949-453-3990
Fax: 949-450-7249

RoHS Notice

All Lantronix products in the following families are China RoHS-compliant and free of the following hazardous substances and elements:

Product Family Name	Toxic or hazardous Substances and Elements					
	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent Chromium (Cr (VI))	Polybrominated biphenyls (PBB)	Polybrominated diphenyl ethers (PBDE)
UDS1100 and 2100	0	0	0	0	0	0
EDS	0	0	0	0	0	0
MSS100	0	0	0	0	0	0
IntelliBox	0	0	0	0	0	0
XPress DR & XPress-DR+	0	0	0	0	0	0
SecureBox 1101 & 2101	0	0	0	0	0	0
WiBox	0	0	0	0	0	0
UBox	0	0	0	0	0	0
MatchPort	0	0	0	0	0	0
SLC	0	0	0	0	0	0
XPort	0	0	0	0	0	0
WiPort	0	0	0	0	0	0
SLB	0	0	0	0	0	0
SLP	0	0	0	0	0	0
SCS	0	0	0	0	0	0
SLS	0	0	0	0	0	0
DSC	0	0	0	0	0	0

O: toxic or hazardous substance contained in all of the homogeneous materials for this part is below the limit requirement in SJ/T11363-2006.

X: toxic or hazardous substance contained in at least one of the homogeneous materials used for this part is above the limit requirement in SJ/T11363-2006.

Index

A

- Accept Mode 46
- Accept Mode 53
- Accessing XPort b/g Pro 31
- Additional Documentation 14
- Additional TCP Server Port 99
- Address
 - Ethernet 19
 - Hardware 19, 20
 - IP 19
 - MAC 19, 20
- Advanced Settings
 - Email Configuration 124
 - XML Configuration 128
- Advanced Settings 123
- AES 16
- Allow Firmware Update 74
- Allow TFTP File Creation 74
- Allow XCR Import 74
- Applications 15
- ARP 16
- ARP Settings 107, 108
- ASCII 97
- Auth Type 80
- Authentication Mode 71
- Authentication Type 80
- Authority 95
- AutoIP 16

B

- Banner 83
- Bar Code 19
- Bin 145
- Binary 83, 144
- Binary to Hexadecimal Conversions 144
- Binary to Hexadecimal Conversions 144
- Block Network 55, 59
- Block Serial 59
- Block Serial Data 55
- BOOTP 16, 39
- Branding 140
 - Web Manager Customization 140
- Break Duration 66

C

- Challenge Handshake Authentication Protocol 70
- CHAP 70
- CLI 17
- CLI Configuration 126
- CLI Statistics 126
- Command Line Interface Settings 126
- Command Mode 18
- Command-Line Interface 17
- Common Name 96
- Compliance 146
- Configuration Methods 18
- Configuration Settings 69
- Configuring Tunnels to Use VIP 138
- Connect Mode 46
- Connect Mode 56
- Controller 15
- Convert Newlines 83
- Count 114
- Create New Keys 90
- Create New Self-Signed Certificate 95

D

- DB25 Connector 21
- DB25M-to-DB9F Serial Cable 21
- DB9F-to-DB9F Serial Null Modem Cable 26
- Default Gateway 40
- Default Server Port Numbers 19
- Device Control 17
- Device Details 31
- Device Details Summary 31
- Device Management 18
- DeviceInstaller 31
- DHCP 16, 40
- Diagnostic Toolset 18
- Diagnostics 111
 - Buffer Pools 118
 - Hardware 111
 - IP Sockets 113
 - Memory 118
 - MIB-II Statistics 112
 - Ping 113
 - Processes 119
- Diagnostics Log 116
- Diagnostics Settings 100
- Direct & Indirect ESD 146
- Disconnect Mode 46
- Disconnect Mode 61
- DNS 16, 40
- DNS Settings 69
- DTE Device 21

E

- Echo 66, 67
- EDS1100 installation 21
 - back panel 23
 - device top LEDs 24
 - ethernet LEDs 23
 - hardware components 22
 - installation steps 24
 - package contents 21
 - reset button 23
 - rs-232 pinout configuration 22
 - rs-422 pinout configuration 22
 - rs-485 pinout configuration 22
 - user-supplied items 21
- EDS2100 installation 26
 - back panel 28
 - device top LEDs 28
 - ethernet port LEDs 28
 - hardware components 26
 - installation steps 29
 - package contents 26
 - reset button 28
 - rs-232 pinout configuration 27
 - rs-422 pinout configuration 27
 - rs-485 pinout configuration 27
 - user-supplied items 26
- Electrical 146
- Electrical Fast Transient/Burst Immunity 146
- Email on Connect 55, 59
- Email on Disconnect 55, 59
- Enable Level Password 127
- Encryption 18
- End of Job 83
- Enterprise-Grade Security 17
- EOJ String 83
- Ethernet 15
- Ethernet address 19
- Evolution OS 16
- Evolution OS™ 16
- Exit Connect Menu 66, 67
- Expires 96
- Export Secrets 129
- Export to Browser 129, 131
- Export to Local File 129, 131

F

- File System
 - Browser 101
 - Statistics 100
- Filename 134, 136
- Filesystem 36, 142

- Firewall 137
- Firmware 142
- Flush Serial Data 55, 59
- Formfeed 83
- FreeRadius 93
- FTP 16, 142
- FTP Configuration 73

G

- Groups to Export 130, 131

H

- Hardware Address 19, 20
- Hazardous Substance 147
- Help Area 35
- Hex 145
- Hexadecimal 144
- Host 58, 103, 114, 115
- Host Configuration 68
- Host Configuration 68
- Host IP Promotion 60
- Hostname 40
- HTTP 16
 - Authentication 79
 - Change Configuration 77
 - Configuration 76
 - Statistics 76

I

- ICMP 16
- ICMP Settings 105
- Immunity 146
- Import Configuration from External File 132
- Import Configuration from the Filesystem 133
- Import Line(s) from Single Line Settings on the Filesystem 135
- Inactivity Timeout 127
- Interface Signals 15
- IP 16
 - Address 19
 - Address Filter 109
 - Settings 105
- ISO/IEC Guide 146

K

- Key Features 15
- Key Length 96
- Key Type 86, 90

L

- Label 19
- Lantronix Discovery Protocol 19
- Line 1
 - Configuration 43
 - Statistics 42
- Line Settings 42
- Lines to Export 130, 131
- Lines to Import 134, 136
- Loading New Firmware 142
- Local IP Address 71
- Local Port 54, 58
- Login Connect Menu 66, 67
- Login Password 127
- Logout 35
- Long Name 141
- LPD
 - Configuration Page 82
 - Settings 81
- LPD Statistics 81

M

- MAC Address 19, 20
- Maintenance and Diagnostics Settings
 - Protocol Stack 104
- Maintenance Settings 100
- ManageLinx 137
- Manufacturer's Contact 147
- Manufacturer's Name & Address 146
- Max Entries 81
- Max Length 117
- Memory 15
- Modbus Configuration 99
- Modbus Statistics 98
- Modbus 97
- Mode 58
- Modem Emulation 16
- Modem Emulation 62
- MTU 40
- Multiple Hosts 60

N

- Name 122
- NAT 70
- Network 1 (eth0) Interface Configuration 39
- Network 1 Ethernet Link 41
- Network Address Translation 70
- Network Settings
 - Network 1 Interface Configuration 39
 - Network 1 Interface Status 38
- Network Settings 38
- New Certificate 95
- New Private Key 95

O

- Obtaining a Bootstrap File 137
- Obtaining Firmware 142
- Organization Unit 95

P

- Packing Mode 50
- PAP 70
- Part Number 19
- Password 55, 71, 90
- Password Authentication Protocol 70
- PBX 18
- Peer IP Address 71
- Persistent 81
- Point-to-Point Protocol 70
- Port 19, 103
- Port Numbers 19
- Ports
 - Serial and Telnet 18
- Power Cube 21, 26
- Power Frequency Magnetic Field Immunity 146
- Power Supply 15
- PPP 16
- PPP Peer Device 70
- PPP Settings 70
- Private Branch Exchange 18
- Private Key 85, 90
- Product ID 19
- Product Information Label 19
- Product Name Model 146
- Product Revision 19
- Protocol 54, 68
- Protocol Support 16
- Public Key 85, 90

Q

- Query Port 110
- Queue Name 83
- Quick Start Guide 21, 26
- Quit Connect Line 127

R

- Radiated and Conducted Emissions 146
- Read Community 72
- Really Simple Syndication 17
- Reboot Device 121
- Reconnect Timer 59
- Remote Address 68
- Remote Command 90
- Remote Port 68
- Response Timeout 99
- Restore Factory Defaults 121
- RF Common Mode Conducted Susceptibility 146
- RF Electromagnetic Field Immunity 146
- RFC1334 70
- RoHS Notice 147
- RS232 15
- RS-232/422/485 Serial Device 21
- RS-232/422/485 serial device 21
- RS-232/422/485 Serial Devices 26
- RSS 16, 17
- RSS Feed 81
- RSS Settings 80
- RSS Trace Input 99
- RTU 97

S

- Safety 146
- Scientific 145
- Scientific Calculator 145
- SCPR 18
- Secure Com Port Redirector 18
- Secure Shell 84
- Secure Sockets Layer 84, 91
- Security
 - Enterprise-Grade 17
 - Settings 84
- Security Settings 84
 - SSL Certificates and Private Keys 92
 - SSL Cipher Suites 91
 - SSL RSA or DSA 92
 - SSL Utilities 93
- Send Break 66
- Send Character 52

- Serial Port 15
- Serial Settings 49
- Serial Transmission Mode 97
- Services Settings 69
 - CHAP Authentication 70
 - LPD 81
- Severity Level 117
- Short and Long Name Customization 140
- Short Name 141
- SMTP 16
- SNMP 16
- SNMP Configuration 72
- SNMP Management 17
- SOJ String 83
- SSH 16, 84
 - Client Known Hosts 88
 - Server Authorized Users 86
 - Server Host Keys 85
 - Settings 84
- SSH Client Known Hosts 88
- SSH Client User Configuration 89
- SSH Max Sessions 127
- SSH Port 127
- SSH Server Authorized Users 86
- SSH Server Host Keys 85
- SSH State 127
- SSH Username 68
- SSL 16, 84, 91
 - Settings 91
- SSL Certificates 92
- SSL Cipher Suites 91
- SSL Configuration 94
- SSL RSA or DSA 92
- SSL Utilities 93
- Start of Job 83
- State 106
- Steel Belted Radius 93
- Surge Immunity 146
- Syslog 16
- Syslog Configuration 75
- System 141
- System Branding 141
- System Contact 72
- System Description 72
- System Location 72
- System Name 72
- System Settings 121

T

- TCP 16
- TCP Keep Alive 54
- TCP Server State 99

- TCP Settings 104
- TCP/IP 97
- Technical Support 143
- Telnet 16
- Telnet Max Sessions 127
- Telnet Port 127
- Telnet State 127
- Terminal
 - Server 18
 - Settings 65
- Terminal Type 66, 67
- Text List 134
- TFTP 16, 142
- TFTP Configuration 74
- Threshold 52
- Timeout 52, 114
- TLS 16
- Traceroute 115
- Trailing Character 52
- Traps Primary Destination 72
- Traps Secondary Destination 73
- Traps State 72
- Troubleshooting 18
- Troubleshooting Capabilities 18
- Tunnel – Accept Mode 53
- Tunnel – Connect Mode 56
- Tunnel – Disconnect Mode 61
- Tunnel – Packing Mode 50
- Tunnel 1 – Statistics 47
- Tunnel Settings
 - Connect Mode 56
 - Modem Emulation
 - Command Mode 62
 - Packing Mode 50
- Tunnel Settings 46
- Type 96

U

- UDP 16
- Uniform Resource Identifier 79
- Updating Firmware 142
- Upload Authority Certificate 95
- Upload Certificate 95
- Upload Keys 85
- Upload New Firmware 122
- URI 79
- Username 71, 90

V

- VIP Access 17
- VIP Configuration 139
- VIP Statistics 138
- VIP Settings 137
- Voltage Dips and Interrupts 146

W

- Web Manager
 - Device Status Web Page 34
 - Navigating 36
 - Page Components 35
 - Page Summary 36
- Web Manager Customization 140
- Web Manager 33
- Web-Based Configuration 16
- Whole Groups to Import 134, 136
- WLAN
 - Settings
 - Network 1 Ethernet Link 41
- Write Community 72

X

- XML 18
 - Export Configuration 128
 - Export Status 130
 - Import System Configuration 131
- XML Settings 128
- XML-Based Architecture 17