

## SecureLinx Product Shipment Contents

SecureLinx™ console managers, Remote KVM™ and remote power managers are shipped with a variety of power supply, cable and adapter options depending on the product type and application space for which they were designed. This reference list details the contents of a standard shipment for each product. This information can also be found in the “What’s In the Box” section of the Quick Start Guide included with SecureLinx console managers.

### SecureLinx Management Appliance

Management Appliance	Contents Description (Part Number, If Applicable)
<b>Part Number:</b> <b>SLM25612N-01</b> SecureLinx Management Appliance	<ul style="list-style-type: none"> <li>• Cable: null modem, DB9F TO DB9F, 6FT (500-164)</li> <li>• Power cord: One (1) AC power cord (500-041)</li> <li>• SLM Rack Slide Rail Kit (SLMRKIT1-01)</li> </ul>
	Note: Can be used with the following power cords, ordered separately - European power cord (500-119), UK power cord (500-120)

### SecureLinx SLC Console Managers:

Single AC Power Supply	Contents Description (Part Number, If Applicable)
<b>Part Number:</b> <b>SLC01612N-02</b> (16 Port, Single AC Power Supply Secure Console Manager) <b>SLC03212N-02</b> (32 Port, Single AC Power Supply Secure Console Manager) <b>SLC04812N-02</b> (48 Port, Single AC Power Supply Secure Console Manager)	<ul style="list-style-type: none"> <li>• Adapter: DB25M (DCE) to RJ45 (200.2066A)</li> <li>• Adapter: DB25F (DCE) to RJ45 (200.2067A)</li> <li>• Adapter: DB9M (DCE) to RJ45 (200.2069A)</li> <li>• Adapter: DB9F (DCE) to RJ45 (200.2070A)</li> <li>• Adapter: RJ45 to RJ45 (200.2225)</li> <li>• Cable: RJ45 to RJ45, 6.6 ft/2 m (200.0063)</li> <li>• Cable: Loopback (500-153)</li> <li>• Power Cord: One AC power cord (500-041)</li> </ul>
	Note: Can be used with the following power cords, ordered separately - European power cord (500-119), UK power cord (500-120)

Dual AC Power Supply	Contents Description (Part Number, If Applicable)
<b>Part Number:</b> <b>SLC01622N-02</b> (16 Port, Dual AC Power Supply Secure Console Manager) <b>SLC03222N-02</b> (32 Port, Dual AC Power Supply Secure Console Manager) <b>SLC04822N-02</b> (48 Port, Dual AC Power Supply Secure Console Manager)	<ul style="list-style-type: none"> <li>• Adapter: DB25M (DCE) to RJ45 (200.2066A)</li> <li>• Adapter: DB25F (DCE) to RJ45 (200.2067A)</li> <li>• Adapter: DB9M (DCE) to RJ45 (200.2069A)</li> <li>• Adapter: DB9F (DCE) to RJ45 (200.2070A)</li> <li>• Adapter: RJ45 to RJ45 (200.2225)</li> <li>• Cable: RJ45 to RJ45, 6.6 ft/2 m (200.0063)</li> <li>• Cable: Loopback (500-153)</li> <li>• Power Cord: Two AC power cords (500-041)</li> </ul>
	Note: Can be used with the following power cords, ordered separately - European power cord (500-119), UK power cord (500-120)

### SecureLinux SLC Console Managers (Continued)

Dual DC Power Supply	Contents Description (Part Number, If Applicable)
<b>Part Number:</b> <b>SLC01624T-02</b> (16 Port, Dual DC Power Supply Secure Console Manager) <b>SLC03224T-02</b> (32 Port, Dual DC Power Supply Secure Console Manager) <b>SLC04824T-02</b> (48 Port, Dual DC Power Supply Secure Console Manager)	<ul style="list-style-type: none"> <li>• Adapter: DB25M (DCE) to RJ45 (200.2066A)</li> <li>• Adapter: DB25F (DCE) to RJ45 (200.2067A)</li> <li>• Adapter: DB9M (DCE) to RJ45 (200.2069A)</li> <li>• Adapter: DB9F (DCE) to RJ45 (200.2070A)</li> <li>• Adapter: RJ45 to RJ45 (200.2225)</li> <li>• Cable: RJ45 to RJ45, 6.6 ft/2 m (200.0063)</li> <li>• Cable: Loopback (500-153)</li> <li>• Power Cord: accessory kit w/ DC plug connectors for dual DC models (083-011)</li> </ul>
	Note: Can be used with the following power cords, ordered separately - European power cord (500-119), UK power cord (500-120)

### SecureLinux SLK Remote KVM™:

Model: SLK1	Contents Description (Part Number, If Applicable)
<b>Part Number:</b> <b>SLK00112N-01</b> (1-port Remote KVM/IP)	<ul style="list-style-type: none"> <li>• User Guide</li> <li>• Power Cord, AC Shielded, 6FT US (500-041)</li> <li>• Cable, 3-in-1, 6FT (500-165)</li> <li>• SLK Serial Y Cable; miniDIN8 to RJ11/DB9F, 9 In. (SLKCHY001-01)</li> </ul>
Model: SLK8	Contents Description (Part Number, If Applicable)
<b>Part Number:</b> <b>SLK00812N-01</b> (8-port Remote KVM/IP)	<ul style="list-style-type: none"> <li>• User Guide</li> <li>• Power Cord, AC Shielded, 6FT US (500-041)</li> <li>• SLK Serial Y Cable; miniDIN8 to RJ11/DB9F, 9 In. (SLKCHY001-01)</li> </ul>

	<ul style="list-style-type: none"> <li>• Rack Mount Bracket Kit (SLKB08000-01)</li> </ul>
--	---

<b>Model: SLK16</b>	<b>Contents Description (Part Number, If Applicable)</b>
<b><u>Part Number:</u></b> <b>SLK01612N-01</b> (16-port Remote KVM/IP)	<ul style="list-style-type: none"> <li>• User Guide</li> <li>• Power Cord, AC Shielded, 6FT US (500-041)</li> <li>• Rack Mount Bracket Kit (SLKB16000-01)</li> </ul>

**SecureLinux SLP Remote Power Manager:**

<b>Model: SLP8 (US)</b>	<b>Contents Description (Part Number, If Applicable)</b>
<b><u>Part Number:</u></b> <b>SLPH0811E-02</b> (REMOTE POWER MGR; 1U, 8-PORT, NEMA, 100-120VAC)	<ul style="list-style-type: none"> <li>• Serial Interface Connector</li> <li>• RJ45 Cable</li> <li>• CD with User Guide</li> <li>• Rack Mount Bracket Kit</li> </ul>
	<b>Note:</b> Power cords are not included; please specify separately when ordering.

<b>Model: SLP8 (INTL)</b>	<b>Contents Description (Part Number, If Applicable)</b>
<b><u>Part Number:</u></b> <b>SLPH0812E-02</b> (REMOTE POWER MGR; 1U, 8-PORT, IEC320, 208-230VAC)	<ul style="list-style-type: none"> <li>• Serial Interface Connector</li> <li>• RJ45 Cable</li> <li>• CD with User Guide</li> <li>• Rack Mount Bracket Kit</li> </ul>
	<b>Note:</b> Power cords are not included; please specify separately when ordering.

<b>Model: SLP16 (US)</b>	<b>Contents Description (Part Number, If Applicable)</b>
<b><u>Part Number:</u></b> <b>SLPV1611E-02</b> (REMOTE POWER MGR; 0U, 16-PORT, NEMA, 100-120VAC)	<ul style="list-style-type: none"> <li>• Serial Interface Connector</li> <li>• RJ45 Cable</li> <li>• CD with User Guide</li> <li>• Rack Mount Bracket Kit</li> </ul>
	<b>Note:</b> Power cords are not included; please specify separately when ordering.

<b>Model: SLP16 (INTL)</b>	<b>Contents Description (Part Number, If Applicable)</b>
<b>Part Number:</b> <b>SLPV1612E-02</b> (REMOTE POWER MGR; 0U, 16-PORT, IEC320, 208- 230VAC)	<ul style="list-style-type: none"> <li>• Serial Interface Connector</li> <li>• RJ45 Cable</li> <li>• CD with User Guide</li> <li>• Rack Mount Bracket Kit</li> </ul>
	<p><b>Note:</b> Power cords are not included; please specify separately when ordering.</p>

© 2006 Lantronix, Inc. All rights reserved.

Lantronix is a registered trademark, and SecureLinux and Remote KVM are trademarks of Lantronix, Inc.