



**xPort<sup>®</sup> Pro**  
**Embedded Device Server**  
**Integration Guide**

## Copyright and Trademark

© 2024 Lantronix, Inc. All rights reserved. No part of the contents of this publication may be transmitted or reproduced in any form or by any means without the written permission of Lantronix.

*Lantronix* and *xPort* are registered trademarks of Lantronix, Inc. in the United States and other countries. *Evolution OS* is registered trademark of Lantronix, Inc. in the United States. *DeviceInstaller* is a trademark of Lantronix, Inc.

*Windows* and *Internet Explorer* are registered trademarks of Microsoft Corporation. *Mozilla* and *Firefox* are registered trademarks of the Mozilla Foundation. *Chrome* is a trademark of Google. *Opera* is a trademark of Opera Software ASA. *Freescale* is a registered trademark of Freescale Semiconductor, Inc. Broadcom is a registered trademark of Broadcom Corporation. All other trademarks and trade names are the property of their respective holders.

## Warranty

For details on the Lantronix warranty policy, please go to our Web site at [www.lantronix.com/support/warranty](http://www.lantronix.com/support/warranty).

## Contacts

### Lantronix, Inc. Corporate Headquarters

48 Discovery, Suite 250  
Irvine, CA 92618, USA

Toll Free: 800-526-8766  
Phone: 949-453-3990  
Fax: 949-453-3995

### Technical Support

Online: [www.lantronix.com/technical-support/](http://www.lantronix.com/technical-support/).

### Sales Offices

For a current list of our domestic and international sales offices, go to the Lantronix web site at [www.lantronix.com/about-us/contact/](http://www.lantronix.com/about-us/contact/).

## Disclaimer and Revisions

Operation of this equipment in a residential area is likely to cause interference, in which case the user, at his or her own expense, will be required to take whatever measures may be required to correct the interference.

**Note:** *This product has been designed to comply with the limits for a Class B digital device pursuant to Part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with this guide, may cause harmful interference to radio communications.*

Changes or modifications to this device not explicitly approved by Lantronix will void the user's authority to operate this device.

**Note:** *With the purchase of Lantronix® xPort® Pro embedded device server, the OEM agrees to an OEM firmware license agreement that grants the OEM a non-exclusive, royalty-free firmware license to use and distribute the binary firmware image provided, only to the extent necessary to use the xPort Pro hardware. For further details, please see the xPort Pro OEM firmware license agreement.*

## Revision History

Date	Rev.	Comments
September 2009	A	Initial Draft
December 2010	B	Updated Lantronix address/contact information.
March 2011	C	Updated SDRAM number information.
April 2011	D	Updated part number information.
September 2011	E	Updated compliance information.
April 2012	F	Updated Pin 4 state and part number information.
August 2012	G	Updated recommended operating condition and part number information.
June 2016	H	Updated to include the xPort Pro Lx6 part number and unit of measurement information.
August 2017	J	Updated part number SKU information.
August 2024	K	Updated xPort Pro drawings Figure 2-4, Figure 2-5, and Figure 2-6

## Table of Contents

Copyright and Trademark	2
Disclaimer and Revisions	2
Revision History	3
Table of Contents	4
List of Figures	4
List of Tables	4
<b>1. Introduction</b>	<b>6</b>
About the Integration Guide	6
Additional Documentation	6
<b>2. Description and Specifications</b>	<b>7</b>
The xPort Pro Features	7
xPort Pro Block Diagram	8
PCB Interface	9
Ethernet Interface	10
LEDs	10
Dimensions	11
Recommended PCB Layout	12
Product Information Label	13
Electrical Specifications	13
Functional Specifications	14
<b>A: xPort Pro 485 Connection Diagram</b>	<b>16</b>
<b>B: Compliance Information</b>	<b>17</b>
RoHS, REACH and WEEE Compliance Statement	17

## List of Figures

Figure 2-1. Side View of the xPort Pro	8
Figure 2-2. xPort Pro Block Diagram	8
Figure 2-3. xPort Pro LEDs	10
Figure 2-4. Front View	11
Figure 2-5. Bottom View	11
Figure 2-6. Side View	11
Figure 2-7. PCB Layout	12
Figure 2-8. Product Label	13

## List of Tables

Table 2-1 xPort Pro Part Numbers	7
Table 2-2 PCB Interface Signals	9
Table 2-3 Ethernet Interface Signals (Industry Standards)	10

Table 2-4 Absolute Maximum Ratings _____	13
Table 2-5 Recommended Operating Conditions _____	13
Table 2-6 Technical Specifications _____	14

# 1. Introduction

## About the Integration Guide

This guide provides the information needed to integrate the Lantronix Port® Pro embedded device server into a customer printed circuit board. This manual is intended for engineers responsible for integrating the xPort Pro into their product.

**Note:** This document covers xPort Pro Embedded Device Server versions XPP1004000-02R, XPP1002000-01R, XPP100200S-01R, XPP1002000-02R, XPP100200S-02R, XPP1003000-01R, XPP100300S-01R, XPP1003000-04R and XPP100300S-04R.

## Additional Documentation

Visit the Lantronix web site at [www.lantronix.com/support/documentation](http://www.lantronix.com/support/documentation) for the latest documentation and the following additional documentation.

Document	Description
<b><i>xPort Pro Embedded Device Server User Guide</i></b>	Provides information needed to configure, use, and update the xPort Pro firmware.
<b><i>xPort Pro Lx6 Embedded Device Server User Guide</i></b>	Provides information needed to configure, use, and update the xPort Pro Lx6 firmware.
<b><i>xPort Embedded Device Server Universal Demo Board Quick Start</i></b>	Provides the steps for getting the xPort Pro up and running.
<b><i>xPort Embedded Device Server Universal Demo Board User Guide</i></b>	Provides information needed to use the xPort Pro on the demo board.
<b><i>DeviceInstaller User Guide</i></b>	Provides instructions for using the Windows-based utility to configure the xPort Pro and other Lantronix device servers.
<b><i>Com Port Redirector User Guide</i></b>	Provides information on using the Windows-based utility to create a virtual com port.

## 2. Description and Specifications

The xPort Pro embedded device server is Lantronix's most powerful, self-contained embedded networking module. Footprint compatible with the popular xPort product and running either Linux or the Lantronix Evolution OS® operating systems, the xPort Pro eliminates the complexity of designing network connectivity into a product and allows you to deploy advanced applications on the edge device itself. The thumb-sized xPort Pro provides everything you need in a single embedded solution. It effortlessly handles demanding applications with the power of a high-speed, advanced architecture 32-bit processor. The ample built-in memory allows virtually unlimited flexibility for customization and application enablement.

xPort Pro provides bullet-proof security by offering a variety of robust data encryption and authentication options. What's more, the option to run Linux, with IPv6 built in, enables you to deploy custom applications and take advantage of the large feature libraries available for Linux developers. Critical agency certification has already been completed by Lantronix, reducing your test time and speeding time-to-market.

### The xPort Pro Features

The xPort Pro contains a 32-bit Freescale® processor, with 8/16 megabytes (MB) of SDRAM (see [Table 2-1](#)), 16 MB of Flash and an integrated Broadcom® 10/100 PHY.

**Table 2-1 xPort Pro Part Numbers**


Part Numbers	SDRAM	Operating System
XPP1002000-01R	8 MB	Evolution
XPP100200S-01R	8 MB	Evolution
XPPDK1000-EVO-01	8 MB	Evolution
XPP1002000-02R	16 MB	Evolution
XPP100200S-02R	16 MB	Evolution
XPPDK1000-EVO-02	16 MB	Evolution
XPP1003000-01R	8 MB	Linux
XPP100300S-01R	8 MB	Linux
XPPDK1000-LNX-01	8 MB	Linux
XPP1003000-04R	16 MB	Linux
XPP100300S-04R	16 MB	Linux
XPPDK1000-LNX-02	16 MB	Linux
XPP1004000-02R	16 MB	Linux

The xPort Pro also contains the following:

- ♦ 3.3-volt serial interface
- ♦ All I/O pins are 3.3V tolerant
- ♦ Ethernet magnetics
- ♦ Power supply filters
- ♦ Reset circuit
- ♦ +1.5V regulator
- ♦ Crystals and Ethernet LEDs

The xPort Pro requires +3.3-volt power and is designed to operate in an extended temperature range (see technical data).


Figure 2-1. Side View of the xPort Pro



## xPort Pro Block Diagram

The following drawing is a block diagram of the xPort Pro showing the relationships of the components.

Figure 2-2. xPort Pro Block Diagram



## PCB Interface

The xPort Pro has a serial port compatible with data rates up to 921600 bps. The serial signals (pins 4–8) are 3.3V CMOS logic level. The serial interface pins include +3.3V, ground, and reset. The serial signals connect to an internal UART driven at 3.3V. For applications requiring an external cable running with RS-232 or RS422/485 voltage levels, the xPort Pro must interface to a serial transceiver chip. We supply an RS-232 transceiver on the xPort Universal Demo Board for this purpose.

**Note:** The standard baud rate of 460800 bps is not supported.

**Table 2-2 PCB Interface Signals**

Signal Name	xPort Pro Pin #	Primary Function
GND	1	Circuit ground
3.3V	2	+3.3V power in
Reset	3	External reset in
Data Out <sup>1</sup>	4	Serial data out (driven by built-in UART)
Data In	5	Serial data in (input to built-in UART)
CP1/RTS (Configurable Pin 1)	6	CP1 can be configured as follows: <ul style="list-style-type: none"> <li>• <b>Flow control:</b> RTS (Request to Send) <b>output</b> driven by the built-in UART for connection to CTS of attached device.</li> <li>• <b>Programmable input/output:</b> CP1 can be driven or read through software control, independent of serial port activity.</li> <li>• <b>RS485 Transmit Enable:</b> In RS485 mode, CP1 is driven by the built-in UART for connection to the transmit enable pin of an RS485 Transceiver.</li> </ul>
CP2/DTR (Configurable Pin 2)	7	CP2 can be configured as follows: <ul style="list-style-type: none"> <li>• <b>Modem control:</b> DTR (Data Terminal Ready) <b>output</b> driven by the built-in UART for connection to DCD of attached device.</li> <li>• <b>Programmable input/output:</b> CP2 can be driven or read through software control, independent of serial port activity.</li> </ul>
CP3/CTS/DCD (Configurable Pin 3)	8	CP3 can be configured as follows: <ul style="list-style-type: none"> <li>• <b>Flow control:</b> CTS (Clear to Send) input read by the built-in UART for connection to RTS of attached device.</li> <li>• <b>Modem control:</b> DCD (Data Carrier Detect) <b>input</b> read by the built-in UART for connection to DTR of attached device.</li> <li>• <b>Programmable input/output:</b> CP3 can be driven or read through software control, independent of serial port activity.</li> </ul>

<sup>1</sup> Data out will float during and immediately after power up or assertion of RESET on Pin 3. Pin 4 can be pulled up to +3.3V with a 10K ohm or larger resistor to hold the pin high during reset.

## Ethernet Interface

The Ethernet interface magnetics, RJ45 connector, and Ethernet status LEDs are all in the device server shell. The xPort Pro PHY is Auto MDIX capable allowing connection to either straight through or cross over Ethernet cables.

**Table 2-3 Ethernet Interface Signals (Industry Standards)**


Signal Name	DIR	Contact	Primary Function
TX+	Out	1	Differential Ethernet transmit data +
TX-	Out	2	Differential Ethernet transmit data -
RX+	In	3	Differential Ethernet receive data +
RX-	In	6	Differential Ethernet receive data -
Not used		4	Terminated
Not used		5	Terminated
Not used		7	Terminated
Not Used		8	Terminated
SHIELD			Chassis ground

## LEDs

The xPort Pro contains the following LEDs:

- ♦ Link (solid green, left LED)
- ♦ Activity (blinking amber, right LED)

**Figure 2-3. xPort Pro LEDs**



# Dimensions

The xPort Pro dimensions are shown in the following drawings.

Figure 2-4. Front View




Figure 2-5. Bottom View





Figure 2-6. Side View



## Recommended PCB Layout


The hole pattern and mounting dimensions for the xPort Pro device server are shown in the following drawing. For proper heat dissipation, it is recommended that the PCB have approximately 1 square inch of copper attached to the shield tabs. The shield tabs are an important source of heat sinking for the device.

The xPort Pro shield is considered “chassis ground” and should be separate from “signal ground”. ESD near the xPort Pro at the panel opening will likely jump to the shield.

We recommend using high voltage (~200V), low ESR, 0.01 uF capacitors to connect chassis ground to both signal ground and 3.3V. This will cause any voltage spike from ESD to be imparted equally to both signal ground and 3.3V with no net voltage increase between 3.3V and signal ground. For the highest level of ESD protection of the xPort Pro, it is recommended that the shield not be directly connected to signal GND. The metal shield fingers around the xPort Pro’s RJ45 should physically contact the product housing when the housing is metal, or metallic coated.

The shield is also a heat sink for the internal 32-bit Processor. As in all heat sinking applications, the more copper connected to the heat sink the better. Adding 1 inch square inch of copper flood on the PCB is adequate to allow the xPort Pro to work up to +85°C. If the application does not expect to see temperatures up to +85°C the heat sink may be smaller than 1 square inch.


Figure 2-7. PCB Layout



## Product Information Label

The product information label contains important information about your specific unit, such as its product ID (name), bar code, part number, and Ethernet (MAC) address.

Figure 2-8. Product Label



## Electrical Specifications

**Caution:** Stressing the device above the rating listed in this table may cause permanent damage to the xPort Pro. Exposure to Absolute Maximum Rating conditions for extended periods may affect the xPort Pro's reliability.

Table 2-4 Absolute Maximum Ratings

Parameter	Symbol	Min	Max	Units
Supply Voltage	V <sub>CC</sub>	0	3.6	Vdc
CPx, Reset, Data In, Data Out Voltage	V <sub>CP</sub>	-0.3	V <sub>CC</sub> +0.05	Vdc
Operating Temperature		-40	85	°C
Storage Temperature		-40	85	°C

Table 2-5 Recommended Operating Conditions

Parameter	Symbol	Min	Typical	Max	Units
Supply Voltage	V <sub>CC</sub>	3.15	3.3	3.46	Vdc
Supply Voltage Ripples	V <sub>CC_PP</sub>			2	%
100Base-TX Active (Evolution)	I <sub>CC</sub>		225	270	mA
100Base-TX Active (Linux)	I <sub>CC</sub>		200	270	mA
100Base-TX Idle (Evolution)	I <sub>CC</sub>		215		mA
100Base-TX Idle (Linux)	I <sub>CC</sub>		175		mA
10Base-T Active (Evolution)	I <sub>CC</sub>		145	250	mA
10Base-T Active (Linux)	I <sub>CC</sub>		130	250	mA

Parameter	Symbol	Min	Typical	Max	Units
10Base-T Idle (Evolution)	I <sub>CC</sub>		130		mA
10Base-T Idle (Linux)	I <sub>CC</sub>		110		mA
Supply Reset Threshold	V <sub>RST</sub>	2.85	2.93	3.00	V <sub>dc</sub>
CP2, CP3 Pull-ups	R <sub>PU</sub>		100		Kohm
CP1 Pull-up	R <sub>PU</sub>		10		Kohm
CPx, RX Input Low Voltage	V <sub>CP_IL</sub>			0.8	V <sub>dc</sub>
CPx, RX Input High Voltage	V <sub>CP_IH</sub>	2			V <sub>dc</sub>
CPx, TX Output Low Voltage (I <sub>OL</sub> = 4 mA)	V <sub>CP_OL</sub>			0.4	V <sub>dc</sub>
CPx, TX Output High Voltage (I <sub>OH</sub> = -4 mA)	V <sub>CP_OH</sub>	V <sub>CC</sub> -0.4			V <sub>dc</sub>

**Note:** All pins are not 5V tolerant.

## Functional Specifications


**Table 2-6 Technical Specifications**

Category	Description
CPU, Memory	Freescale 32-bit Coldfire, 8/16 MB SDRAM (see <b>Error! Reference source not found.</b> ), 16 MB flash,
Firmware	Upgradeable via TFTP, FTP, and serial port
Reset Circuit	Internal 140ms minimum power-up reset pulse. Power-drop reset triggered at 2.95V. External reset input causes an internal 140ms minimum reset.
Serial Interface	CMOS (Asynchronous) 3.3V-level signals Rate is software selectable and customizable: 300 bps to 921600 bps <b>Note:</b> The standard baud rate of 460800 bps is not supported.
Serial Line Formats	Data bits: 7 or 8 Stop bits: 1 or 2 Parity: odd, even, none
Modem Control	DTR, DCD
Flow Control	XON/XOFF (software), CTS/RTS (hardware), None
Programmable I/O	3 PIO pins (software selectable), sink or source 4mA max.
Network Interface	RJ45 Ethernet 10Base-T or 100Base-TX (auto-sensing)
Compatibility	Ethernet: Version 802.3u
Protocols Supported	ARP, UDP/IP, TCP/IP, Telnet, ICMP, SNMP, DHCP, BOOTP, TFTP, FTP, Auto IP, SMTP, HTTPS, and HTTP
LEDs	10Base-T and 100Base-TX Link Activity
Management	Internal web server, SNMP (read only) Serial login, Telnet login, DeviceInstaller utility, SSH
Security	Password protection, locking features, optional Rijndael 256-bit encryption
Internal Web Server	Serves static web pages and Java applets Storage capacity: 1MB
Weight	0.34 oz (9.6 grams)
Material	Metal shell, thermoplastic case
Temperature	Operating range: -40°C to +85°C (-40°F to 185°F)
Shock/Vibration	Non-operational shock: 500 g's Non-operational vibration: 20 g's
Warranty	Two year limited warranty

Category	Description
Included Software	Windows® 98/NT/2000/XP-based Lantronix® DeviceInstaller™ configuration software and Windows®-based Com Port Redirector
Compliance	<p data-bbox="553 298 802 327"><b>Regulatory Approvals</b></p> <ul style="list-style-type: none"> <li data-bbox="553 333 922 363">♦ FCC Part 15, Subpart B, Class B</li> <li data-bbox="553 367 932 396">♦ ICES-003 Issue 4 (2004), Class B</li> <li data-bbox="553 401 1162 430">♦ EN55022:2006 and EN55024:1998 + A1:2001 + A2:2003</li> <li data-bbox="553 434 831 464">♦ AS/NZS CISPR22:2006</li> <li data-bbox="553 468 776 497">♦ VCCI V-3/2009.04</li> <li data-bbox="553 501 1187 531">♦ EN61000-3-2:2006, EN 61000-3-3:1995+A1:2001+A2:2005</li> <li data-bbox="553 535 1224 564">♦ EN61000-4-2 (+/-4kV Contact Discharge, +/-8kV Air Discharge)</li> <li data-bbox="553 569 1390 598">♦ EN61000-4-3 (3 V/m (Unmodulated R.M.S.), 80 MHz - 1 GHz, 80% AM (1 kHz))</li> <li data-bbox="553 602 1110 632">♦ EN61000-4-4 (Ethernet Port: ±0.5 kV (Peak), 5 kHz)</li> <li data-bbox="553 636 1409 690">♦ EN61000-4-6 (Signal Port(s):3 V (Unmodulated R.M.S), 0.15 MHz - 80 MHz, 80% AM (1 kHz)</li> <li data-bbox="553 695 987 724">♦ EN61000-4-8 (50 Hz, 1.0 A/m (R.M.S.))</li> </ul>

## A: xPort Pro 485 Connection Diagram

The following example illustrates a connection between the xPort Pro embedded device server and an external transceiver IC:



## ***B: Compliance Information***

(According to ISO/IEC Guide 22 and EN 45014)

### **Manufacturer's Name & Contact Information:**

Lantronix, Inc.  
7535 Irvine Center Drive  
Suite 100  
Irvine, CA 92618, USA  
Toll Free: 800-526-8766  
Phone: 949-453-3990  
Fax: 949-453-3995

*Declares that the following product:*

**Product Name Models:** xPort® Pro Embedded Device Server  
xPort® Pro Lx6 Embedded Device Server

*Conforms to the following standards or other normative documents:*

### **Electromagnetic Emissions/Immunity:**

- ♦ FCC Part 15, Subpart B, Class B
- ♦ ICES-003 Issue 4 (2004), Class B
- ♦ EN55022:2006 and EN55024:1998 + A1:2001 + A2:2003
- ♦ AS/NZS CISPR22:2006
- ♦ VCCI V-3/2009.04
- ♦ EN61000-3-2:2006, EN 61000-3-3:1995+A1:2001+A2:2005
- ♦ EN61000-4-2 (+/-4kV Contact Discharge, +/-8kV Air Discharge)
- ♦ EN61000-4-3 (3 V/m (Unmodulated R.M.S.), 80 MHz - 1 GHz, 80% AM (1 kHz))
- ♦ EN61000-4-4 (Ethernet Port: ±0.5 kV (Peak), 5 kHz)
- ♦ EN61000-4-6 (Signal Port(s):3 V (Unmodulated R.M.S), 0.15 MHz - 80 MHz, 80% AM (1 kHz)
- ♦ EN61000-4-8 (50 Hz, 1.0 A/m (R.M.S.)

## ***RoHS, REACH and WEEE Compliance Statement***

Please visit <http://www.lantronix.com/legal/rohs/> for Lantronix's statement about RoHS, REACH and WEEE compliance.